


Devildom
Tripod



使用说明
Use Instructions
01h-AB201

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

CAUTION

RISK OF EXPLOSION BATTERY IS RE-PLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS
















SRRC

RoHS

CE

CCC

The product has many Chinese and English patents

Devildom Instructions 制造商: Manufacturer: 产品名称: Product name: 产品型号: 01h-AB201 Product model: 01h-AB201 发布日期: Date of manufacture: 产地: 中国 Origin: China 额定电压: 3.7V Rated voltage: 额定电流: 8mA Rated current: 工作温度: -10℃~+50℃ Working temperature: 无线频率: Wireless parameter 频率: 2.4GHz Frequency: 2.4GHz 调制方式: FSK Modulation scheme: FSK 无线功率: Output power: Class 2 (40dBm PAV < 40dBm)	开关机说明 Switch on and off  将手机安装在手机支架内并固定好,长按电源键3秒开启蓝牙绿灯闪烁,打开手机蓝牙,搜索蓝牙设备(SEAJIE)等待5秒,绿灯长亮表示蓝牙连接成功,即可使用自拍杆拍照键进行拍照 Put the mobile phone in the mobile phone support. Inside and secure, press the photo key for 3 seconds to open Bluetooth green light flicker, turn on the phone Bluetooth, search The discover Bluetooth device (seace) waits for 5 seconds, The green light shows the Bluetooth.	遥控器分离说明 Remote control separation instructions  向下拨动遥控器解锁开关 Press the remote control down to unlock the switch	遥控器分离说明 Remote control separation instructions  取出蓝牙遥控器,操控遥控器进行拍照 Take out the Bluetooth remote control, and take pictures with the control remote control.	遥控器分离说明 Remote control separation instructions  将遥控器如上所示放入槽位 Place the remote control in the slot as shown above.	遥控器分离说明 Remote control separation instructions  并将遥控器固定与自拍杆中 Place the remote control in the slot as shown above.
Devildom Instructions 自拍杆操作说明 Instructions for selfie stick operation  拉起支架拉杆 Pull up the support and pull the lever	Devildom Instructions 自拍杆操作说明 Instructions for selfie stick operation  拉起支架上脚垫 Pull up the foot cushion on the support.	Devildom Instructions 自拍杆操作说明 Instructions for selfie stick operation  放入手机 Push into the mobile phone	Devildom Instructions 自拍杆操作说明 Instructions for selfie stick operation  拔出尾盖 Pull out the tailcap	Devildom Instructions 自拍杆操作说明 Instructions for selfie stick operation  拉出所有伸缩脚架 Pull out all retractable feet	Devildom Instructions 自拍杆操作说明 Instructions for selfie stick operation  平放尾盖 Place the end cover horizontally
Devildom Instructions 横屏旋转说明 Horizontal vertical screen switching instructions  取下手机 Take off the phone	Devildom Instructions 横屏旋转说明 Horizontal vertical screen switching instructions  将手机支架如上所示下推至最下面 Push the phone holder to the bottom as shown above.	Devildom Instructions 横屏旋转说明 Horizontal vertical screen switching instructions  将手机支架纵向旋转至最低位 Rotate the mobile phone holder vertically to the lowest position.	Devildom Instructions 横屏旋转说明 Horizontal vertical screen switching instructions  将手机支架横向旋转90° Rotate the mobile phone holder 90 degrees horizontally.	Devildom Instructions 横屏旋转说明 Horizontal vertical screen switching instructions  将手机支架调整与拉杆垂直的角度 Adjust the angle of the cell phone holder perpendicular to the rod. Degree	Devildom Instructions 横屏旋转说明 Horizontal vertical screen switching instructions  将旋转头横向移动到手机支架中心位置 Move the rotary head horizontally to the center of the mobile phone support.