料号：Z2020B40175W0
品名：AB204 幻影- 标准版（组合款）说明书(中英文)
展开尺寸：325x140mm(±2mm)；折后尺寸：65x140mm
材质：105g铜版纸
颜色：双面单黑印刷+风琴折页

正面

HANDLE TYPE
MULTI-FUNCTIONAL BRACKET

手柄式多功能支架
Handle type multi-functional bracket

USER MANUAL

① 产品介绍 Product introduction

调焦款 Focusing Model Oth-AB204

无需下载APP功能轻易调焦 Focus as you wish without downloading the App
注意：摄像头切换键 短按或连接多头可以切换（部分手机为摄像与拍照切换）
Note: Camera switch button: Short press the front and rear camera for switching (shooting and photographing switch for some mobile phones)

全景款 Panoramic Model Oth-AB204YT

电动云台专属监控，拍摄轻松
Exclusive remote control by electric platform for easy shooting

② 手机夹和电动云台介绍 Intro of mobile phone clip and electric platform

组合式 Assorted tripod

展开模式 (Extended mode)

合拢模式 (Folding mode)

单臂支架 Single tripod

电动云台 Electric platform

组合式支架 Assorted tripod

本产品采用创新一体式三机位手机夹设计，可同时搭载3台手机，支持多平台直播，专为网络主播量身定制，可搭载螺丝口式补光灯使用。

This product adopts an ingenious integrated three stand mobile phone clip, capable of carrying three phones simultaneously and supporting multi-platform live streaming. It is tailored to web anchors, with a supplementary screw type fill-in light.

单臂支架 Single tripod

本产品采用创新可拆卸式单支架手机夹，滑轨式设计，无需取下手机即可实现360度自由旋转。

This product adopts the detachable monopod styled mobile phone clip with sliding channels to realize 360-degree free rotation without removing the mobile phone.

电动云台 Electric platform

① 打开多功能支架固定盖，直接将电动云台螺丝孔位对准自拍杆的螺丝端口，并顺时针转拧紧电动云台。

Open the cover of the Multi-function bracket, align the screw socket of the electric platform to the screw stud of the stick and tighten it clockwise.

② 再将电动云台的盖子打开，把可拆卸式夹型手机夹装入电动云台，电动云台内置旋转马达，无需手机调节，只需启动开机键通过专属蓝牙遥控器，便可实现全景拍摄。

Open the cover of the electric platform and put the detachable mobile phone clip into the platform. A built in rotary motor works to adjust, so you just need to press the power button to realize the panoramic shooting through bluetooth remote control.

③ 适用于360相机、微单相机、Gropro/手机等多种数码设备。

It is Suitable for a variety of digital devices such as 360 Camera, mirrorless cameras, Gropro/mobile phones.

③ 遥控器分离/充电说明 instruction of remote controller separation / charging

取出遥控器:
从遥控器顶端向下按出遥控器

Remove the remote control:
Pull the remote control downwards from the top

安装遥控器:
先固定住遥控器底端再向下压入

Fit the remote control:
Fix the bottom of the remote control firstly and press down

④ 开关机说明 (Switch on and off)

将手机固定在手机支架上，长按开关机键3秒至绿灯闪烁开启蓝牙配对模式；打开手机蓝牙设置，搜索并连接"SEAJIC"连接第1次先识别是安卓系统还是苹果系统，连接第2次成功后绿灯长亮；即可按下自拍杆的拍照键进行拍照，只有调焦款需要连接2次，全景款只需连接1次。

Fix the phone on the holder, Long press start on/off and hold the camera button for 3 s until the green light flashes to turn on the Bluetooth pairing mode; search and connect to "SEAJIC" in Bluetooth setting. Connect for the first time to identify the Android or iOS system and the green light will turn on after the second connection; press the camera button to take photos. Only the focusing models need to connect twice and the panoramic models do it once.

背面

① 打开三脚架 Open tripod operation instructions

首先：按下产品底部的三角形按钮可开启展开模式。

Step 1: Press the triangle button on the bottom of the product to turn into the extended mode.

然后：一只手握住自拍杆中部位置，另一手捏住自拍杆拉杆的顶盖，将拉杆拉出。

Step 2: Hold the middle of the selfie stick with one hand and pinch the cover of the stick with the other hand to pull the extensible rod out.

最后：用手捏住已拉开的拉杆，每拉开一节往左扭动一次锁紧一节拉杆，再往右扭动一次是松开拉杆，可自由调节适合的长度。

Step 3: Hold the extended rod, you can twist left to lock the rod and twist right to loosen the rod at each joint. The length of the stick is adjustable.





备注：拉出拉杆时，底部三脚支架会同时自动打开，请勿用手强行打开底部的三脚支架以免造成产品损伤。

Note: When pulling out the pull pole, the bottom tripod bracket will open automatically at the same time, please do not open forcibly the bottom tripod bracket with your hand, avoiding to cause product damage.

② 收起三脚架 Put away the tripod

一只手握住自拍杆中部位置，另一只手将拉杆往右扭动解锁拉杆，再逐节推回手柄套筒内。

Hold the middle of the selfie stick with one hand, twist the rod to the right with the other hand to unlock the rod and retract it into the handle sleeve.

备注：
收缩拉杆时，三脚架会**自动合拢，**请勿将手直接放在三脚支架上面，以防夹伤。

Note: when pushing the pull pole, the tripod will be closed automatically. Please do not put your hand directly on the tripod bracket to prevent clamping injury.

③ 使用支架云台和360度万向转接平台 Use the bracket head and 360-degree universal connection platform

① 打开支架云台上的盖子，直接将一体式三机位手机夹螺丝孔对准本产品螺丝端口并顺时针旋转扭紧手机夹，即可使用本产品支架云台功能，手动调节360度万向转接印，可实现360度旋转拍摄。

Open the cover of the bracket head, align the screw hole of the inte grated mobile phone clip to the screw stud, rotate clockwise and tighten the clip to activate the bracket head function. Adjust the 360-degree universal button manually to realize 360-degree shooting.

② 适用于Gropro/微单/卡片机/投影仪/单反等多种数码产品设备，使用时将数码产品的 1/4 英寸螺丝口对准本产品的螺丝端口，并顺时针旋转扭紧数码产品，即可使用本产品支架云台功能，手动调节 360 度万向转接印，可实现 360 度旋转拍摄，尽情享受科技带来的快乐。

It is suitable for a variety of digital products such as Gropro/mirrorless cameras/pocket cameras/projectors/SLR. Align the 1/4" screw socket to the screw stud of this product, rotate clockwise and tighten it to activate the bracket head function. Adjust the 360-degree universal button manually to realize 360-degree shooting and enjoy the fun fully.

④ 转接软管 Transfer hose

当周围环境较暗时，可将补光灯放置在转接软管顶部，打开补光灯电源，可达到补充光线效果。

When the surrounding environment is dim, you can place the fill-in light on the top of the transfer hose and turn on the light to achieve a complementary light effect.

⑤ 规格参数 Specifications

多功能支架规格/Multi-function bracket size	35.5x43x355mm
多功能支架重量/Multi-function bracket weight	622g
组合式支架重量/Assorted tripod weight	175g
单臂支架重量/Single tripod weight	52g
电动云台重量/Electric platform weight	59g
调焦款/Focusing Model & 全景款/Panoramic Model 容量/Capacity	65mAh
电动云台容量 /Electric platform Capacity	110mAh
多功能支架合拢尺寸/ multi-functional bracket pole closing size	355mm
多功能支架展开尺寸/ multi-functional bracket pole expansion size	1850mm(±10mm)
支架合拢尺寸/Bracket folding size	355mm
支架展开尺寸/Bracket expansion size	1850mm(±10mm)
材质/Material	铝合金拉杆/Aluminum Rod

⑥ 备注 Notes

当电量不足时，请先取出遥控器和电动云台，使用Micro接口给遥控器充电即可。

When the battery is low, please take out the remote control and electric platform, and charge the remote control through Micro interface.

注意：摄像头切换也有部分手机不兼容

Note: The camera switching is not compatible with some phones

配备专用的皮套，方便随身携带。

Equipped with a special leather case, easy to carry with you.

包装图片仅供参考，产品（颜色及大小），请以实物为准

The product picture of the package is for reference only. The product color and dimension bases on real-product unit.

FCC Requirement

changes or modifications not expressly approved by the party responsible for compliance could void the user' s authority to operate the equipment.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.