

iTECH

ACTIVE 2

FITNESS TRACKER



FIND OUR APP
IN YOUR STORE



QUICK START GUIDE

CHARGING YOUR WATCH

We recommend plugging the USB charger into your computer to charge your watch.



CHARGING YOUR WATCH

Align the metal pins on the charger to the back of the watch. Clip the charger into place.



HOW TO TURN ON/OFF

Power on: Tap and hold the one-touch button for 3 seconds.

Power Off: Navigate to the settings menu, tap and hold to enter this section. Next, navigate to the 'Power Off' screen. Once there, simply tap and hold the one touch button on the 'Power Off' screen to turn off your device.



ENJOYING YOUR ITOUCH ACTIVE 2

To navigate through the features of your device, tap on the one touch button. Simply tap and hold the one touch button to activate a feature.



FCC Caution

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

iTECH

ACTIVE 2



Scan the QR Code to download the smartwatch app. Follow instructions in the app to begin connecting your smartwatch.

SYSTEM REQUIREMENTS

(Android 9.0 and up) (iOS 13.0 and up)
Make sure your phone's Bluetooth is turned on and enabled.

For user manuals, please visit
<https://www.itechwearables.com/>