

Led&Buzzer state description

LED Light	Description
Left blue LED 1	Flash briefly if scanning successfully
Right blue LED 2	Wireless connection
Red LED	Charging
Blue 2 off, blue 1 Flash quickly	2.4G pairing mode
Blue 1 off, Blue 2 Flash quickly	SPP pairing mode
Blue 1 and Blue2 alternately flash	HID pairing mode
Blue 1 and Blue 2 Synchronize flash quickly	BLE pairing mode

Buzzer	Description
A long Sound	Power ON/OFF
A short sound(low frequency)	Scan common barcode, or paired, wireless connection success
3 short sound(low frequency)	Wireless transmission failor buffer full
5 short sound(low frequency) and stop scanning	Battery without electricity
2 short sound(low frequency)	Wireless disconnection
2 short sound(high frequency)	Setup code scanning is not work

SZSC-9DS03.E120

Sound&Vibration Settings

a: Start the scanner and scan "Enter Setup Mode" barcode



b: Select the desired to turn on / off the sound or vibrate the barcode



c: Scan" Exit Setup Mode" barcode



Sleep time settings

a: Start the scanner and scan "Enter Setup Mode" barcode



b: Select the sleep interval barcode



c: Scan" Exit Setup Mode" barcode



Language settings

a: Start the scanner and scan "Enter Setup Mode" barcode



b: Select the desired keyboard language barcode



c: Scan" Exit Setup Mode" barcode



c: Double click for close IOS keyboard
★Double Click For Close IOS keyboard

d: Android System keyboard call out to the supplier to obtain the Bluetooth input method APP

Communication mode switching (optional)

a: Start the scanner and scan "Enter Setup Mode" barcode



b: Select the desired communication mode barcode



c: scan" Exit Setup Mode" barcode



c: Scan the "Paired With Dongle" barcode, enter the pair state. The left and right blue light will flash alternately. (Or click the button double times to exit setup mode, back to the scanning state.)



d: Open Bluetooth in the device and search for the Barcode scanner HID

e: Click the Bluetooth device to enter the match status

f: Match success "Di" sound, the right blue light is always bright

g: Scan "Exit Setup Mode" barcode



★Out Or Hide

b: Double click for out IOS keyboard



Match with Bluetooth terminal
FOR Bluetooth matching steps, support Android, IOS system phone or PC with Bluetooth enabled PC terminal)

Method 1:
a: Start the scanner, long press the button 8s, enter the Bluetooth HID pairing mode. The left and right blue light will flash alternately.

b: Turn on Bluetooth in the device and search for the Barcode scanner HID

c: Click the Bluetooth device to enter the pairing state

d: Match success "Di" sound, the right blue light is always bright

Method 2:
a: Start the scanner and scan "Enter Setup Mode" barcode




b: Scan the "Bluetooth HID mode" barcode



★Clear Data

Match with the computer (2.4G)
FOR 2.4G matching steps, support xp, win7, win8, win10, etc.

a: Start the scanner, scan "Enter Setup Mode" barcode



b: Scan 2.4G mode barcode




c: Scan the "Paired With Dongle" barcode, enter the pair state, the left blue light will flash.



d: Insert the receiver, hear a sound. It means pairing is successful. The right blue light will always bright.




If the internal storage is full, the scanner will send three low-frequency short tone alarm.



By scanning this " Sum Data" barcode, user can check the barcode quantity in the internal memory of the scanner.




★Sum Data
Upload the stored data by scanning the "Data Upload" barcode. After the data is uploaded, the barcode stored in the barcode scanner is not automatically deleted. The user uploads the storage data multiple times.



Note: Please ensure that the wireless signal connection is good when the data is uploading. Or user can upload the data by using the cable.

By scanning the "clear data" barcode to clear the storage area of the barcode data, bar code will not be able to upload after the clear,please confirm whether the data has been uploaded.



Wireless Operating Mode


The barcode scanner has two operating modes: Synchronous Mode and storage mode, through a different set code to operate the mode switch:

a: First scan "Enter setup mode " barcode

b: Scan the required operating mode barcode

c: Scan "Exit Set mode" barcode to switch the desired mode of operation

Synchronous mode, the scanning data directly through the cable or wireless transmission to the computer, after the success of the scanning, it will issue a low frequency short tone. If the transmission fails, issue a 3-channel low-frequency tone to alert. In normal mode, if the transmission fails, the sweep of the bar code will be lost.



If the barcode scanner works beyond the transmission range, it is recommended to use storage mode In storage mode ; The scanned data is stored in the internal memory of the scanner. After scanning a barcode, barcode scanner will send a short sound. The scanned barcode will storage in the internal memory of the scanner automatically.

Use instructions

All the functions of this barcode scanner are set by scanning the setting barcodes. First, scan "enter setup mode" barcode, and then scan the function barcode to be set, then scan the "exit setup mode" barcode after finishing setting. Some common function barcodes can scan the function barcode directly to complete the setting. This kind of barcode identification is ★, such as "★ power display".



Restore Wireless Parameters

If in use of the process, accidentally scan to other function settings code, which led to the scanning function can not be used normally, through the scan initialization barcode to restore to the initialization state.



Wireless Barcode Scanner Quick Start Guide

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.