




User Guide




Press and hold the Power Button for about a second and the Power Indicator will light up. Prelude X will go into standby mode for 2 minutes. After that, your Prelude X is ready to go!

Prelude X will automatically turn off if there is no action for 2 minutes or by pressing the Power Button for 3 seconds.

If the battery power is too low for output, the Power Indicator will blink red. Please fully charge it.







The fold-out stand can be unfolded and used as a phone stand.



Fully charge Prelude X before using for the first time

Gently attach Prelude X Wireless Charging Area 2 onto powered Prelude XS Power Adapter (not included).

* If the Wireless Charging Area 2 was used for output charging, please turn off Prelude X (by pressing the Power Button for 3 seconds) before wireless charging it with Prelude XS.



After the Prelude X is fully charged, you can use it to charge your wireless or non-wireless devices.

1.

Press the Power Button for about a second. Then Power Indicator will light up and Prelude X is ready for use.


2. Gently attach Prelude X Wireless Charging Area 1 onto your iPhone wireless charging area.

*When in the Sandwich Charging Mode (Prelude X wirelessly charges the iPhone while it is being wirelessly charged). Please make sure that Prelude X has more than 30% battery power (blue light). Only then, the system will charge the iPhone.


3. Wireless charging is in progress




1. Press the Power Button for about a second. Then Power Indicator will light up and Prelude X is ready for use.




- (blinking) 0% - 10%
- 10% - 30%
- 30% - 100%



1. Press the Power Button for about a second. Then Power Indicator will light up and Prelude X is ready for use.



- (blinking) 0% - 10%
- 10% - 30%
- 30% - 100%



1. Keep wireless charging unit dry and away from liquids. Do not use on wet surfaces.
2. Do not attempt to disassemble or modify charger.
3. Always disconnect power supply before cleaning charger.
4. Keep away from high heat. Use in the temperature range between -5 and 45 degrees Celsius (23 and 113 degrees Fahrenheit).
5. Don't place credit cards, security badges, passports or key fobs between your iPhone and Prelude X. This may damage magnetic strips or chips on those items.
6. If you have a case that holds any of these sensitive items, remove them before charging or make sure that they aren't between the back of your device and the Prelude X.
7. Your iPhone or Prelude X might get slightly warmer while your iPhone charges. To extend the lifespan of your battery, if the battery gets too warm, software might limit charging for up until 80 percent only.
8. If you keep your iPhone in a leather case while charging with your Prelude X, the case might show imprints from compression of the leather. This is not a defect. If you'd like to avoid this, we suggest using a non-leather case.

compliance could avoid the user's authority to operate the equipment.

This equipment is designed and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment does not contain any FCC radio frequency emission limits set forth for an uncontrolled environment.

Battery Capacity	5Vdc/3100mAh, 9Vdc/1600mAh
Wireless Input	5V $\approx$ 1A, 9V $\approx$ 1.2A
USB-C Input	5V $\approx$ 3A, 9V $\approx$ 2.2A
Wireless Output 1	5W / 7.5W / 10W / 15W
Wireless Output 2	3W
USB-C Output	5V $\approx$ 3A, 9V $\approx$ 2.2A

USB-C Input + Wireless Output	USB-C Input : 5V = 3A Wireless Output : 5V = 3A (15W)
----------------------------------	--

Prelude X Wireless Power Bank	X1
USB-C Cable	X1
User Manual	X1

Learn more about BEZALEL and our full line of wireless charging products at bezalel.co.
Contact us at support@bezalel.co.



VE.1.7