

对折 双面印刷
正面

Specifications

Product model: HT CLIP
Bluetooth solutions: AB5756C
Bluetooth version: V6.0
Frequency response: 20Hz-20KHz
Speaker size: 11mm
Speaker impedance (speaker unit): $30\Omega \pm 15\%$
Effective distance: 10m
Earphones battery capacity: 30mAh
Charging case battery capacity: 250mAh
Charging port: Type C
Charging voltage/current: 5V/0.25A

Warning

Please read the warnings below carefully. Store this manual with product packaging. The safety precaution manual reduce the risk of fire or injury when correctly complied to.

To reduce the risk of injury :

Keep batteries out of reach of children.
Do not heat, open, or dispose of battery pack in fire.
Do not allow metal objects to touch the battery on the device.
Do not expose battery pack to excessive heat.
Do not use a high current charger, or the charging line will burn out.

RF warning for portable device:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Hottips®



CLIP-ON OPEN EARBUDS USER MANUAL

Paring

1: Auto Pairing

Taking the earphones out of the charging case, and then the earphones will automatically turn on, sync together and enter pairing mode.

2: Syncing your earphones

When earphones do not sync together or enter disconnected state during use.

1): Turn off both earphones and turn back on.

2): If that does not work, placing both earphones back into case, closing the charging case and then open the charging case again.

3): While earphones is out of the charging case. Press and hold both earphones for 5 seconds. This will force the earphones to turn off and on again and sync with each other.

3: Open up Bluetooth setting on your smart device and scan for 'HT CLIP'.

Operation

1: Power on/off .

1) Take the earphones out of the charging case, automatically turn on;
2) Put the earphones back to the charging case, automatically turn off;
3) Long press 5 seconds to turn on/turn off

2: Play/Pause music.

When listening to music.

Tap left/right earphones once to play or pause the music.

3: Previous /Next Song

When listening to music.

Quickly triple tap left earphones to go to previous song.

Quickly triple tap right earphones to go to next song.

4: Volume +/-

Quick double tap left earphone to lower the volume,
Quick double tap right earphone to increase volume.

5: Answer/Hang up

When there is an incoming call.

Tap left or right earphones once to answer the call.

Tap left or right earphones again to end the call.

6: Reject

When there is an incoming call.

Long press left or right earphones for 3 seconds to reject the call.

7: Voice assistant

Long press left or right earphones for 2 seconds to activate voice assistant.

FCC Statement

FCC ID: 2AS7V-OWS66-HTCLIP

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This device generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

--Reorient or relocate the receiving antenna.

--Increase the separation between the device and receiver.

--Connect the device into an outlet on a circuit different from that to which the receiver is connected.

--Consult the dealer or an experienced radio/TV technician for help
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

反面