

5. ADJUSTMENTS




Zero-gravity is based on the NASA space capsule relaxation theory. Using the back, seat, and the leg rest, the chair puts the heart and knee at the same level, reducing the blood circulation pressure. Not only that, but all the gravitational forces can be dispersed to the massage chair, reducing heart and spine pressure.


Zero Gravity Angle Adjustment

KEYS	DESCRIPTION	GUIDELINES
Leg up Leg down	Angle Adjustment Key for Legrest	Leg Up Long-press this button, the legrest will move up to the top position, release this button, legrest stops moving. Leg Down Long-press this button, the legrest will move down to the lowest position, release this button, legrest stops moving.
Back up Back down	Angle Adjustment Button for Backrest	Back Up Long-press this button, the backrest will move up to the original position, release this button, backrest stops moving. Back down Long-press this button, the backrest will move down to the lowest position, release this button, backrest stops moving.
Off 1 2 3	Zero Gravity Function Control	Touch this button to activate the zero gravity position, and choose from Zero Gravity mode1, Zero Gravity mode 2 and Zero Gravity mode 3.

Other Adjustments


KEYS	DESCRIPTION	GUIDELINES
	Roller Intensity	SLOW / MEDIUM / FAST Only effective under manual massage mode.   
	Kneading Speed	5 levels kneading speed adjustments.
	Tapping Speed	5 levels tapping speed adjustments.
	Air Intensity	5 levels tapping air intensity adjustments.

6. AIR MASSAGE



KEYS	DESCRIPTION	GUIDELINES
	Full body	Full body air massage.
	Shoulder	Shoulder air massage.
	Arm	Arm air massage.
	Waist	Waist air massage.
	Leg	Leg air massage.
	Foot	Foot air massage.

7. SETTINGS



BLUETOOTH INSTRUCTIONS

Play Mobile Music/Bluetooth speaker:
Turn on Bluetooth of mobile, then select Bluetooth device of massage chair (JL10053GB-BN). Once paired, it can act as speaker when mobile phone is playing music. (Remarks: No Password)

AI VOICE ORDERS

Items	Function	Order	Response
1	ON/OFF	Hello, Massage	I am here
2		Power on	Massage starts
3		Shut down	Massage ends
4	Pause	Pause massage	Massage paused
5		Resume massage	Massage resumed
6		Continue massage	
7	Heat	Heating on	Heating on
8		Heating off	Heating off
9	Timer	5 Minutes	Massage will stop in 5 minutes
10		10 Minutes	Massage will stop in 10 minutes
11		15 Minutes	Massage will stop in 15 minutes
12		20 Minutes	Massage will stop in 20 minutes
13		25 Minutes	Massage will stop in 25 minutes
14		30 Minutes	Massage will stop in 30 minutes

Items	Function	Order	Response
15	Zero Gravity	Zero gravity 1	Zero gravity 1
16		Zero gravity 2	Zero gravity 2
17		Zero gravity 3	Zero gravity 3
18		Zero gravity	Zero Gravity mode 2
19		Back up	Back up
20		Back down	Back down
21		Back stop	Back stop
22		Leg up	Leg up
23		Leg down	Leg down
24		Leg stop	Leg stop
25	Foot Roller	Foot rolling	Foot rolling is on
26		Calf rolling	
27		Stop rolling	Foot rolling stop
28	Work Relief	Work relief mode	Work relief mode is on
29	Deep tissue	Deep tissue mode	Deep tissue mode is on
30	Thai	Thai mode	Thai stretch mode is on
31		Stretch mode	

Items	Function	Order	Response
32	Athletic	Athletic mode	Athletic mode is on
33	Vertebral	Vertebral mode	Vertebral mode is on
34	Neck and Shoulder	Neck and Shoulder mode	Neck and Shoulder mode is on
35	Recovery	Recovery mode	Recovery mode is on
36	Rest and sleep	Rest and sleep mode	Rest and sleep mode is on
37	Gental	Gental mode	Gental mode is on
38	For Her	For Her mode	For her mode is on
39		Beauty mode	
40	For Him	For Him mode	For him mode is on
41	Waist and Hip	Waist and Hip mode	Waist and hip mode is on
42	Manual	Manual mode	Manual mode is on
43		More roller strength	Strength increased
44		Less roller strength	Strength decreased
45		More air intensity	Air intensity increased
46		Less air intensity	Air intensity decreased

SAFETY INSTRUCTIONS

- 1.Should any abnormality occur,shut off and detach power plug from socket.
- 2.When power cord are damaged, it must be changed from special power cord or available from other manufacturer or service department.



!Warning: Do not dismantle,modify or change components by unqualified person to avoid electric shock or fire.

DAILY CARE AND MAINTENANCE

Storage guide

- Do not dismantle any part the chair or make modifications.Serious injury make occur.
- Do not attempt to repair the machine by unqualified person to avoid electric shock or fire.
- Make sure to shut off and detach the power plug when cleaning to avoid electric shock or hazard.
- Keep the massage chair clean and free dust.Do not place the massage chair in a humid area.
- If not in use for a long period ,please cover it with a cloth to protect from dust.
- Do not place the massage chair under sunlight or heating source like a heater or directly by a window that has direct sunlight.

Maintenance

- Use a neutral detergent only that is free of acid and alcohol.
- Use a neutral detergent to clean the back cushion, head cushion and leg cushion. Let it dry.
- With a damp cloth wipe down the plastic parts, pipe and synthetic leather material of the chair.

- Make sure not to use any gasoline, banana oil, benzene based cleaners to avoid leather color fading or discoloring.
- Do not spray pesticide or aerosols near or on the chair to avoid electric shock or fire.
- Please clean with dry cloth to avoid mechanical failure.

Controller maintenance

- Do not place the massage chair near heater or fire.
- Keep away from humidity to avoid electric shock and damage to the chair.
- Please clean dust with soft cloth or small banister brush.
- Make sure not to use detergents containing benzene, gasoline,banana oil.

TROUBLE SHOOTING

Checking is necessary in frequent usage.

Make sure the machine work normally before usage, after not in used for long time.

Abnormality situation	Solution guide
Failure to start and indication light is off	Check the plug is well connected./Check the switch on the chair is turned on in the "I" position.
Sound in operation	The following sounds are normal • The mechanism will produce a sound for kneading or knocking • Sound changes after speed adjustment • Sound from when the rollers go up or down. • When the chair does a tapping massage it will make the chair vibrate making a sound. • When the air inflates and deflates it will make a swooshing sound • Sound for airbag inflating and venting. Airbags may crackle. • Sound for leg adjustment. • Sound for motor when the massage chair is loaded.

SPECIFICATION

Product name	Massage Chair
Model	JL10053
Power supply	110V~60HZ
Rated power	150W
Rated working time	15min



Warning: Supervision and guidance are necessary when people with disabilities and mental illness. Please advise with your doctor before using the chair if you have any medical conditions. Children under 18 should not use the chair and consult with a doctor for approval if attempted. Do not operate the chair and consult with a doctor for approval if attempted. Do not operate the chair if there are any children or pets near by. Serious injuries may occur if these instructions are not followed.