















TWS-12N User Manual ANC TWS Wireless Earbuds	CONTENTS  Earbuds charging case * 1PCS  User manual  Earbuds * 1 Pair  Ear tips * 3 Pair (S / M / L) * Earbuds wear L size by default  Type-C charging cable * 1PCS	PRODUCT INTRODUCTION  In-ear detection FB ANC mic Led indicator Touch panel Microphone Charging pins  Charging indicator Charging port Earbuds re-set button <table><tr><td colspan="2">Specification</td></tr><tr><td>Pairing name</td><td>TWS-12N</td></tr><tr><td>Bluetooth version</td><td>V5.2</td></tr><tr><td>Battery</td><td>50mAh (each earbud) 500mAh (charging base)</td></tr><tr><td>Play time</td><td>7H (ANC off) 6H (ANC on)</td></tr><tr><td>Call time</td><td>7H (ANC off) 6H (ANC on)</td></tr><tr><td>Earbuds charging time</td><td>1.5H</td></tr><tr><td>Case charging time</td><td>2H</td></tr><tr><td>Standby time</td><td>180days</td></tr><tr><td>Charging port</td><td>Type c</td></tr></table>	Specification		Pairing name	TWS-12N	Bluetooth version	V5.2	Battery	50mAh (each earbud) 500mAh (charging base)	Play time	7H (ANC off) 6H (ANC on)	Call time	7H (ANC off) 6H (ANC on)	Earbuds charging time	1.5H	Case charging time	2H	Standby time	180days	Charging port	Type c	OPERATING  Left Earphone  Right Earphone 1x 2x 2x Answer Hang up Play/Pause Reject the Call Power On / Off While the earbuds into the charging case, open the case cover the TWS-12N will Power On automatically. Put earbuds back into the case, earbuds LED indicator RED light solid and Power Off automatically. Answer / Hang Up / Reject the Call Click L or R earbud to answer the phone call while the incoming call. Double-click L or R earbud to reject the call while the incoming call. Double-click L or R earbud to hang up the call while calling. Play / Pause Music Double-click L or R earbud to Play/Pause while playing music.	OPERATING  Left Earphone  Right Earphone 2s 3x 3x 2s Voice assistant Last song Next song ANC Mode Transparency Mode Pre / Next Song Triple-click L earbud to return to previous song while playing music. Triple-click R earbud to next song while playing music. Voice Assistant Press and hold 2 seconds the L earbud to wake up the voice assistant. ANC On → Transparency → ANC Off Mode Press and hold 2 seconds the R earbud to change the ANC or Transparence or ANC Off normal mode.	GET STARTED   Take "TWS-12N" out from the charging case, both earbuds will power on and pairing each other automatically, at the same time, the master earbud will blink the RED and GREEN light alternately. Open the device wireless and chose the name of "TWS-12N" on list, then you will hear CONNECTED from earbud.
Specification																									
Pairing name	TWS-12N																								
Bluetooth version	V5.2																								
Battery	50mAh (each earbud) 500mAh (charging base)																								
Play time	7H (ANC off) 6H (ANC on)																								
Call time	7H (ANC off) 6H (ANC on)																								
Earbuds charging time	1.5H																								
Case charging time	2H																								
Standby time	180days																								
Charging port	Type c																								
RESET  Clear pairing records Put back both earbuds into the charging case, open the cover and hold the multi-function button of charging case 5S until charging case four LED indicator blink 10 times at same time, it means clear pairing records successfully.	CHARGING  LED 25% 50% 75% 100% Please use the provided charging cable to recharge the earbuds by the charging case. Charging case LED indicators in white when charging. After full recharged, 4 LED indicators on charging case stays on.	ACCESSORIES  Wear the right size ear caps for your ears. Adjusting earbuds correctly achieves the best noise reduction performance and sound quality.	NOTES 1. Avoid prolonged exposure to excessive volume that may cause noise-induced hearing impairment. Turn the volume down before putting on your earphones, then adjust it to the right volume. 2. Don't use earphones while driving or riding your bike 3. Stay away from sharp edges, uneven surfaces, metal parts, and anything that could damage the earphones. 4. Do not modify, repair or remove earphones without professional guidance. 5. Do not use corrosive or volatile liquid to clean the earphones. 6. Do not use earphones in dangerous environments. 7. This earphones contains small parts, which may cause choking hazard. Please keep away from children and pets to prevent accidents. 8. Battery warning: *Improper use of the battery may cause fire or chemical burns.The battery may explode in case of damage. *The battery can only be charged using an adapter specially provided for this product. *Please dispose of batteries according to local regulations.Recycle if possible.Do not dispose of batteries as household waste or throw them into a fire, lest they explode. *Please refer to the user manual for instructions on the charging status indicator.	FCC STATEMENT FCC Statement Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: —Reorient or relocate the receiving antenna. —Increase the separation between the equipment and receiver. —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. —Consult the dealer or an experienced radio/TV technician for help This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.																					