


Bluetooth Speaker

How to use the Speaker

The General Features




1.On/Off
Long press this button to power on/off the device.

2.NEXT/Volume Up Button
Short press the button to play the next track.
Hold in the button to turn up the volume.

3. PREV/Volume Down Button
Short press the button to play the previous track.
Hold in the button to turn down the volume.


4. Play/Pause Button/Hand-free
Short press this button to play/pause the playingmusic.
Short press this button to answer the **incoming phone call**.

5. Light control: Gently touch the net to control the light brightness: Maximum, Medium, Minimum, or turn on/off the light.



6. Bluetooth/Charging Indicator light
When the device is turned on, the light turn to blue and flashes.
When the Bluetooth is connected, the light stop flashing and remain blue.
When charging the device, the red light turn on.
When the device is fully charged, the red light turn to green.

7. MIC
Receive your voice when making phone calls.



8. Charging Interface
Inset the USB cable to charging the speaker.

9. Line-in/Reset Interface
Inset the audio cable to listen to music.
Stab the reset interface with some kind of tiny stick to sweep all status and restart the speaker.

Pairing Instructions

- Active Bluetooth mode on mobile device and turn speaker on. Speaker will automatically enter pairing mode.
- Search for the Bluetooth Speaker from your mobile device
- Mobile device will display the Bluetooth Speaker as" ISB210 " in list of available devices.Select pair.
- Follow instruction on mobile device to complete pairing. If pass-code is needed, enter" 0000 " .
- After the Mobile Device and Bluetooth Speaker connect,sound can be controlled from the Buttons "+" "-" and "🔊".
- If the mobile device has paired with a Bluetooth speaker previously,the match will finish automatically.

TWS Connection

If you have two " ISB210 " wireless speakers, you can paired them to form a left and right channel stereo system.

- Power ON both speaker one by one.
- Make sure both speaker are not connected to any bluetooth enabled device.
- Short press Power button of any one speaker and wait for few seconds you will get beep sound post successful connection.
- To disconnect speaker from TWS mode short press Power button of any one speaker.
- To reconnect quickly press Power button two times on sub speaker.
- LED Indicator light will be flashing in Master speaker
- LED indicator light will be solid in Sub speaker.

Technology Specifications

Parameters	Index
Speaker:	φ50mm 4Ω 5W
Bluetooth Ver.:	4.2
Frequency response:	150Hz-20Hz
Sensitivity:	80±2dB
Signal to noise ratio:	≥72dB
Battery capacity:	2000mAh
Battery voltage:	3.7v
Distortion:	1%
Charging time:	3-4 hours
Play time:	8-10 hours(70% volume level)
Size	78 x 78 x 111 mm

FCC WARNING

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference,
(2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement:
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment .
This transmitter must not be co - located or operating in conjunction with any other antenna or transmitter.

Safety Information:

- Avoid contact with liquids and damp areas
- If speaker is damaged seek professional consultation,do not repair
- Do not take speaker apart to avoid electrocution
- Keep speaker away from flame
- Keep it away from children