

BL-06 INSTRUCTION MANUAL

DO NOT PRINT THIS LAYER


PRINT BACK TO BACK

Folded Size: 3.33" (w) x 3.15" (h)

DIELINE:

FOLDING LINE:

FOLDING INSTRUCTIONS



SPECIFICATIONS

Bluetooth version: 5.1
Battery: 400 mah
Speaker: 4Ω3W

PACKAGE CONTENT

Bluetooth speaker x1
Charging cable x1

NOTICE

1. Keep the product dry. Do not store or use in damp places. If wet, let dry completely before attempting to use.
2. Keep out of direct sunlight or high temperatures. As this my result in damage or dysfunction.
3. Keep out of cold temperatures. As this may result in internal damage.
4. Do not disassemble the product. Avoid dropping the speaker.
5. Do not charge the speaker for over 10 hours.

© 2022 Zeikos, Inc. iHip is a trademark of Zeikos, Inc., Registered in the U.S. and other countries. The illustrated product and specifications may differ slightly from that supplied. All other trademarks and trade names are those of their respective owners. United States and international patent pending. All Rights Reserved. For ages 12+up. This is not a toy. Designed by iHip, Manufactured in China.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by "iHip" is under license. Other trademarks and trade names are those of their respective owners.

Limited One Time Warranty.

To activate your product warranty go to our website.
www.iHip.com & register this product.

Bluetooth®

TABLETOP CORNHOLE

True wireless speaker



USER MANUAL

Please read all instructions carefully & retain for future use

BLUETOOTH PAIRING

1. Place the cornhole game within 30 ft of your bluetooth enabled device.
2. Hold the **power button** to turn on the speaker. The LED light will flash blue to indicate it is ready to pair.
3. Use your wireless enabled device to search for and select "**iHip Cornhole Speaker**".
4. The LED will turn **solid blue** and the device will "**beep**" when pairing is complete.

Note: If a pin is required, enter "0000"

SYNC 2 BOARDS TOGETHER

1. Press and hold the **power button on both speakers**.
2. **Double tap the power button on one speaker**. This will be the primary unit streaming from your device. They will automatically connect and "**beep**" to indicate they are paired together.
3. From your devices bluetooth list select "**iHip Cornhole Speaker**". **One speaker will "beep"** again to indicate successful pairing.

-Note -
If audio does not come from both speakers hold down the power button to turn off and repeat steps 1-3.

OFFICIAL CORNHOLE RULES

Every match is broken down into *innings of play*

- 1 Grab some players**
Cornhole can be played with 2 or 4 players. **Player 1 vs. Player 2** or **team 1 vs. Team 2**
- 2 Flip a coin**
Determine which player or team throws first by flipping a coin.
- 3 Toss bags**
Throw your bag (underhand) at the opposite board. Alternate throws with the player next to you.
- 4 Score points**
1 point for each bag that lands on top of the board.
3 points for each bag that is tossed through or knocked into the hole.
- 5 Tally the score**
Tally points after all (8) bags have been thrown per inning by using the cancellation method.
Total = your points - opponent's points
- 6 Win the Game**
The game is over when a Player or Team reaches (or exceeds) 21 Points.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.