

Thank you for purchasing the GOMOMI Wireless Charging Stand, item VM30090N. With this charging stand, you can charge Qi compatible devices horizontally and vertically. Please read this manual carefully before using the wireless charging stand.

FEATURES



Quick Charge



LED Indicator



Charges Horizontally
and Vertically



Qi Compatible

CHARGER SETUP

Using the included USB cable, connect the cable's standard USB end into a power source (computer or wall adapter [not included]). Then insert the cable's Micro USB end into the port on the charger.



WIRELESS CHARGING

1. The LED indicator will illuminate red when the charging stand is powered ON.
2. Place your phone in the center of the Qi charging pad, vertically or horizontally, and the LED Indicator will illuminate blue indicating that your device is charging.
3. Take your phone off the Qi charging pad when charging is complete.

MAINTENANCE AND CARE

- Before using your charging stand, inspect the ports and plugs to make sure that they are clear of dust and debris.
- Use a soft cloth to clean your charging stand. Never use any harsh chemicals or detergents. Make sure your mount is dry before using.
- When your charging stand is not in use, it should be stored in a cool, dry place.
- Never tug or yank on a USB cable that is connected to your device. Connect and disconnect all cables carefully.
- Please recycle or dispose of your charging stand properly based on the laws and rules of your municipality. Contact local recycling facilities and/or the manufacturer of your vent mount for further information.

SPECIFICATIONS

Input: 5V 2A / 9V 1.67A
Wireless Output: 10W
Transmission Distance: 5-8mm (include 2mm plastic shell)

CONTENTS

- VM230090N Wireless Charging Stand
- User's Manual with Warranty Information

IMPORTANT SAFETY PRECAUTIONS

When using your wireless charging stand, basic safety precautions should always be followed including:

1. READ ALL INSTRUCTIONS BEFORE USING YOUR WIRELESS CHARGING STAND..
2. Your charging stand is not to be used by children or the infirm without suitable adult supervision.
3. Never expose the charging stand to high temperatures, extreme cold, high humidity or any moisture or water.
4. Do not use the charging stand at temperatures under 32°F (0°C) or over 104°F (40°C).
5. If you detect any abnormalities when using your vent mount contact the manufacturer for support.
6. In order to avoid the risk of electric shock, never attempt to open your vent mount or repair it without the assistance of certified professionals.
7. Do not drop the charging stand, throw it, or subject it to strong impacts or physical trauma.
8. Your charger may cause interference to radio equipment and should not be installed near maritime safety communications equipment or other critical navigation, communication or medical equipment.
9. Do not place any metallic items other than compatible smartphones on the charging surface.
10. Only place phones with wireless charging capability on the surface of your charger. The use of incompatible phones can cause your charger to overheat.
11. Please recycle or dispose of your vent mount properly based on the laws and rules of your municipality. Contact local recycling facilities and/or the manufacturer of your vent mount for further information.
12. Keep implanted medical devices (cardiac pacemakers, implantable cochleas, etc.) at least 20 cm away from the wireless charger to avoid potential interference with medical equipment.

! IMPORTANT WARNING

Do not use to charge any phones that have a metal body, or phone cases that contain any metal parts, metal pieces or magnets. Doing so can increase the risk of fire, serious malfunction or damage to your phone.



VIVITAR ONE YEAR WARRANTY

This warranty covers the original consumer purchaser only and is not transferable. This warranty covers products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship. Your product will be repaired or replaced at no charge for parts or labor for a period of one year.

What Is Not Covered by Warranty

Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including but limited to: repair by unauthorized parties, tampering, modification or accident.

To Obtain Warranty Service and Troubleshooting Information:

Call 1-800-592-9541 or visit our website at www.vivitar.com.

To receive warranty service along with the name and address of an authorized product service center, the original consumer purchaser must contact us for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the product is within the applicable warranty period(s), MUST be presented in order to obtain the requested service. It is your responsibility to properly package and send any defective products along with a dated copy of proof of purchase, a written explanation of the problem, and a valid return address to the authorized service center at your expense. Do not include any other items or accessories with the defective product. Any products received by the authorized service center that are not covered by warranty will be returned unrepaid.

NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY. DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTEE GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR. REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTOR'S SOLE DISCRETION - ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER. IN NO EVENT WILL DISTRIBUTOR, ITS MANUFACTURERS, OR SAKAR INT. BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS) CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT, EXCEPT AS STATED HEREIN. NO OTHER WARRANTIES SHALL APPLY. NOTWITHSTANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.

Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies.

FCC STATEMENT

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Radiation Exposure Statement

This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. During the operation of device a distance of 15 cm surrounding the device and 20 cm above the top surface of the device must be respected.