

材质：80G书纸
尺寸：98*86mm



红色：熔岩红
PANTONE
Bright Red C
RGB 255,40,25
黑色：钛黑
PANTONE
My Soul Black 6C
RGB 255,40,25

封面

1

2

EH601



1MORE ComfoBuds Z 真无线耳机 用户指南
1MORE ComfoBuds Z User Guide

封底



www.1more.com

制造商：万魔声学科技有限公司
地址：深圳市福田区梅林街道田厦工业 A 区田厦大厦 1403
服务热线：400-992-0909
Manufacturer: Tinlab Acoustic Technology Limited
Add: Tinlab Building 1403, Zone A Tianxia Industrial Park,
Touyuan Str., Nanshan Dist., Shenzhen, P.R. China
Made in China

FCC ID: 2ASDIEH601

CMIT ID: 2020DP12120



3


4

1MORE MUSIC APP



中国内地用户可扫描二维码，下载 1MORE MUSIC APP
进行产品升级，体验更完整的功能。

1MORE MUSIC APP



For users outside mainland China, please download the
1MORE MUSIC APP for product upgrades and additional features.
中國內地以外的用戶可下載 1MORE MUSIC APP
進行產品升級，體驗更完整的功能。

5

包装内容



耳机 × 1 副 + 充电盒 × 1



Type-C 充电线 × 1



硅胶耳塞套 × 3 副
(XS/S/L)



使用说明书 × 1




保修卡 × 1



1MORE MUSIC APP
音乐卡 × 1

6


产品概览



选取耳塞

硅胶耳塞套


XS / S / M / L




更换耳塞



耳机佩戴




开/关机




* 上述功能适用于单、双模式使用时的任一耳机。

左、右耳机配对





耳机与蓝牙设备配对




* 上述功能适用于单、双模式使用时的任一耳机。

充电



电量提示



操控

本机不具备通话功能，其播放功能请在所连接的手机等设备端进行相应操作。
聆听舒缓歌单请在 1MORE MUSIC APP 中进行相应操作。


APP 切换音质风格

耳机与 1MORE MUSIC APP 连接后，进入 1MORE ComfoBuds Z 真无线耳机界面，
可自选切换“音乐”和“舒缓”音质风格。



舒缓旋律

页面中点击“舒缓旋律”，可进入对应舒缓歌单页面。



点击“+”添加想要聆听的音乐，即可同步下载至耳机中进行聆听。



其它功能

1. 如何确定耳机已充满电？
将耳机放入充电盒内，耳机指示灯亮起即表示耳机满电。
2. 耳机无法开机，该如何解决？
先确保耳机是否有电。如无电，请充电 30 分钟以上再开机。
3. 耳机与手机蓝牙无法连接，该如何解决？
可将左、右耳机放入充电盒内，长按配对按钮 3 秒，待手机蓝牙搜索到耳机设备后，点击配对连接。
4. 耳机无法通话，该如何解决？
耳机不具备免提通话功能，不支持直接通话功能。
5. 蓝牙耳机播放时，出现断音情况，该如何解决？
1) 请尽量远离设备与耳机之间的距离，避免障碍物遮挡。
2) 请确保手机未被遮挡。
3) 请确保手机未被遮挡。
6. 在 1MORE MUSIC APP 播放舒缓旋律时，不能用手机音量键调节音量大小，该如何解决？
耳机内置的舒缓旋律是内置在耳机内存中的，只能通过 APP 歌曲界面中的音量按钮来调节音量。
7. 耳机与手机连接 超距后蓝牙断开，再次返回耳机可接收蓝牙信号的范围后，耳机无法回连，该如何解决？
在手机端蓝牙连接界面，手动点击耳机设备名称回连。
8. 耳机佩戴后感觉耳朵有异物感，影响，该如何解决？
出现异物感或胀痛，是由于耳塞的大小和个人耳道大小不匹配造成，建议更换较小的耳塞使用。

* 1MORE MUSIC APP 的所有功能，在不同手机及操作系统上使用或有不同，
请联系客服了解更多详情。

售后产品保修说明

1MORE ComfoBuds Z 真无线耳机产品售后服务严格依据《中华人民共和国消费者权益保护法》、
《中华人民共和国产品质量法》实行产品售后服务，服务内容如下：
在产品自购买之日起一年的免费保修期内，您可以依照本规定享受退货、换货、维修的权利。修理、
换货、退货应当凭相关订单号或发票办理。
1、7 日无理由退货（电商渠道），由用户承担物流费用；
2、免费维修或以换代修的产品保修期仍然按原始产品的购买日期计算一年免费保修期。
3、本产品出现《产品性能故障表》所列性能故障的情况，经检测确认后，可以免费享受如下服务：

服务类型	服务政策
退货	自签收之日起 7 天内产品质量问题退货
换货	自签收之日起 15 天内产品质量问题换货
维修	自签收之日起 1 年内产品质量原因维修

产品性能故障表

名称	性能故障
1MORE ComfoBuds Z 真无线耳机	蓝牙耳机听不到声音 无法为蓝牙耳机充电

非保修条例

1. 未经授权的维修、误用、错用、滥用、改装、不正确的使用非本产品配件，
或改装、修改数据、仿造标识；
2. 已超过三包有效期；
3. 因不可抗力造成的损坏；
4. 不符合《产品性能故障表》所列性能故障的情况；
5. 因人为原因导致本产品及其配件产生《产品性能故障表》所列性能故障。
更多服务可登录 1MORE 官方网站 www.1more.com 点击“服务”或
或咨询服务热线：400-992-0909

环保支持

产品中有有害物质的名称及含量

部件名称	有害物质					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
电路板及组件	×	○	○	○	○	○
耳机外壳件	○	○	○	○	○	○
电池	×	○	○	○	○	○
耳塞	×	○	○	○	○	○
配件	○	○	○	○	○	○
充电线	×	○	○	○	○	○

本表格依据 SJ/T 11364 的规定编制。
○ 表示该有害物质在该部件所有均质材料中的含量 GB/T 26572 规定的限量要求以下。
× 表示该有害物质至少在该部件的某一均质材料中的含量超出 GB/T 26572 规定的限量要求。

提示

1. 使用产品前请仔细阅读本使用说明书并妥善保管；
2. 首次使用，请先将本产品充满电；
3. 如产品长期（超过 3 个月）不使用，请对其充电；
4. 必须选择正规厂家生产的经过第三方权威机构认证的充电线和电源适配器；
5. 在干燥环境佩戴，静电可能会触到耳朵产生瞬间发展的电流，这与产品质量性能无关。

警告

1. 请勿以任何理由拆卸或维修改装耳机，否则可能会导致火灾、电子击穿甚至彻底损坏本产品；
2. 请勿将设备置于温度过低或过高（0℃ 以下或 45℃ 以上）的环境中；
3. 请勿在雷暴天气下使用该设备，雷暴可能导致设备工作不正常，并增加触电的危险；
4. 请勿用油及其它挥发性液体擦拭本产品；
5. 请勿连续长时间佩戴耳机（超过 6 小时），尤其不要长时间开最大音量听耳机；
6. 请勿在骑车或开车的状态下佩戴耳机，因为这种行为在某些国家属于违法行为；
7. 6 岁及以下儿童请在成人监护下使用耳机；
8. 如佩戴耳机后感到耳朵不适，建议咨询耳科医生是否适合佩戴入耳式耳机；
9. 本产品内含锂电池，禁止拆解、撞击、挤压或投入火中。若出现膨胀，请勿使用，请置于
高温环境中。

FAQ

1. 如何确定耳机已充满电？
将耳机放入充电盒内，耳机指示灯亮起即表示耳机满电。
2. 耳机无法开机，该如何解决？
先确保耳机是否有电。如无电，请充电 30 分钟以上再开机。
3. 耳机与手机蓝牙无法连接，该如何解决？
可将左、右耳机放入充电盒内，长按配对按钮 3 秒，待手机蓝牙搜索到耳机设备后，点击配对连接。
4. 耳机无法通话，该如何解决？
耳机不具备免提通话功能，不支持直接通话功能。
5. 蓝牙耳机播放时，出现断音情况，该如何解决？
1) 请尽量远离设备与耳机之间的距离，避免障碍物遮挡。
2) 请确保手机未被遮挡。
3) 请确保手机未被遮挡。
6. 在 1MORE MUSIC APP 播放舒缓旋律时，不能用手机音量键调节音量大小，该如何解决？
耳机内置的舒缓旋律是内置在耳机内存中的，只能通过 APP 歌曲界面中的音量按钮来调节音量。
7. 耳机与手机连接 超距后蓝牙断开，再次返回耳机可接收蓝牙信号的范围后，耳机无法回连，该如何解决？
在手机端蓝牙连接界面，手动点击耳机设备名称回连。
8. 耳机佩戴后感觉耳朵有异物感，影响，该如何解决？
出现异物感或胀痛，是由于耳塞的大小和个人耳道大小不匹配造成，建议更换较小的耳塞使用。

* 更多更详细的产品实际使用问题解析，请登录 1MORE 官方网站“技术支持”页进行咨询。

扫描、关注 1MORE 官方微信公众号

欢迎访问 1MORE 社区：bbs.1more.com
登录 www.1more.com，注册成为 1MORE 会员，
更多精彩内容等您。



型号：EH601

单耳机重量：2.7 g

充电盒重量：34 g

整机重量：39.4 g

耳机尺寸：24 × 9.2 × 14.2 mm

充电盒尺寸：60 × 30 × 38.5 mm

整机电池容量：30 mAh

充电盒电池容量：410 mAh

耳机充电时间：85 分钟

充电盒充电时间：80 分钟

使用时长

* 停止充电状态

BLE 本地播放：约 3.5 小时*

蓝牙播放：约 2.5 小时*

BLE 本地播放：约 14 小时*

蓝牙播放：约 10 小时*

整机阻抗：22 Ω

通讯距离：10 米（在空旷环境下）




















蓝牙规范：Bluetooth® 5.0

蓝牙协议：A2DP / AVRCP / BLE

输入：5V=1A

频率波段：2.400 GHz ~ 2.4835 GHz

规格参数为实验室测试数据。
* 播放时称为 AAC 格式，50% 音量条件下的实验室测试数据，依设备设置、环境、使用情况及诸
多其他因素可能有所差异。
制造商：万魔声学科技有限公司
地址：深圳市福田区桃源街道田厦工业 A 区田厦大厦 1403
执行标准：GB8898

EN	EN In The Box  Headphones x 1 set Charging Case  Type-C Charging Cable x 1  Silicone Ear Tip x 3 sets (XS/S/M/L)  User Guide x 1  Warranty Card x 1
EN Product Overview  Silicone Ear Tip  Charging Pin  Headphone  LED Indicator for Headphone Status Charging Case  Pairing Button  Charging Case LED Indicator	EN Fit Silicone Ear Tip XS / S / M / L  XS S M L Replace 
EN Placement  Power On: Take the headphones out of the charging case (with charge), the headphones will turn on automatically.  Power Off: Put the headphones back into the correct slot and close the lid, they will automatically turn off and start charging.  * Above functions are available for either headphone in individual or Stereo mode. 	EN Headphones Pairing 1. The Left and Right headphones will automatically pair to each other after the lid is open when they are in the case (with charge). 2. Headphones taken out of the case that fail to pair to each other will enter sleep mode. Put the headphones back into the charging case (with charge), and they will pair to each other automatically.  Bluetooth Pairing To The Device To connect to your device during first use, turn the headphones on to enter pairing mode, the LEDs for headphone status will flash in white. Headphones will enter sleep mode if not paired to a device within 2 minutes. * After first successful pairing, headphones will automatically connect to your device. To skip previously paired device and pair with a new one, put headphones back into the case, press and hold the pairing button for 3 seconds when powered on (no playback) to re-enter pairing mode.  * Above functions are available for either headphone in individual or Stereo mode.
EN Charging 1) To charge the case with Type-C cable.  Full charge will take around 80 minutes.  The LED light of the charging case will indicate different battery status: red light indicates low battery, orange light indicates medium battery and green light indicates full battery. 2) To charge the headphones with the case.  Put the headphones into the correct slot until it locks in via magnetic click. LEDs will indicate headphone status. LEDs breathing in white indicate headphones are charging.  Full charge will take around 85 minutes. Headphone status LEDs glow in white indicating charging is complete.	EN Battery Notification  LED indicator for case battery status: when case battery is too low on charge, LED indicator will glow solid red for 10 seconds.  When headphones are placed in charging case and the LED on charging case flashes 10 times, the case has low battery, please charge the case first.
EN Controls Phone call function is not available on these headphones, and the playback controls must be implemented on the connected device. Please download 1MORE MUSIC APP for the sleep listening. Switch Listening Modes via APP Enter the 1MORE ComfoBuds Z home page in 1MORE MUSIC APP after pairing to your cellphone, then you can switch listening modes between "Music" and "Soothing". 	EN Soothing Sounds Click the "Soothing Sounds" to enter the playlist.  1MORE ComfoBuds Z Listening Modes Music Soothing Soothing Sounds  Soothing Sounds 1. Soothing Sounds 2. Soothing Sounds 3. Soothing Sounds 4. Soothing Sounds 5. Soothing Sounds Click "+" to select the sound to be downloaded to your headphones for listening. 
EN Click the timer icon in the song page to set up the playtime.  * Volume adjustment for the soothing sounds can only be implemented via APP. Extra Functions 1. If headphones cannot pair normally when they power on, Put both headphones into the case, press and hold the pairing button in the case for 3 seconds and the headphone status LEDs flash in white, and then headphones will start searching for Left & Right pairing. 2. For single mode: put Left and Right earbuds in the case, double-click the pairing button and enter the separate pairing for single earbud. Then the Left and Right earbuds can be connected to different cellphones. 3. To unpair the device: Press and hold the pairing button in the case for 3 seconds to disconnect the earbuds and the device. * Functions of 1MORE MUSIC APP may vary with different cellphones or operating systems. For more details, please contact our customer service.	EN 1MORE (1) Year Limited Warranty 1MORE Inc., ("1MORE") warrants to the original retail purchaser that this product is to be free from defective materials and workmanship for a period of one year from the date of purchase if it is properly used and maintained. If this product proves defective in either material or workmanship, 1MORE, at its option, will (a) repair the product with new or refurbished parts, or (b) replace the product with an equivalent new or refurbished product, at no charge for parts or labor. If the product model is no longer available and cannot be repaired effectively or replaced with an identical model, 1MORE at its sole option may replace the unit with a current model of equal or greater value. In some cases, modification to the mounting surface may be required where a new model is substituted. 1MORE assumes no responsibility or liability for such modification. TO OBTAIN A REPAIR OR REPLACEMENT UNDER THE TERMS OF THIS WARRANTY, PLEASE RETURN TO THE ORIGINAL DEALER FIRST AND THE ORIGINAL DEALER SHALL REPAIR THE PRODUCT WITH NEW OR REFURBISHED PARTS OR REPLACE THE PRODUCT WITH AN EQUIVALENT NEW OR REFURBISHED PRODUCT. You will be required to submit a proof of purchasing details, including but not limited to a receipt or sales invoice. Return shipping for exchanges/repairs is the sole responsibility of the original retail purchaser. Limitations: - This limited warranty does not cover the failure of the product resulting from improper installation, misuse, abuse, accident, neglect, mishandling, or wear from ordinary use or environmental deterioration. - This limited warranty does not cover cosmetic damage, including paint damage, or consequential damage to other components or premises which may result for any reason from the failure of the product. - This limited warranty is null and void for products not used in accordance with 1MORE's instructions. - This limited warranty is null and void for products with altered or missing serial numbers and for products not purchased from an AUTHORIZED dealer. - This limited warranty terminates if you sell or otherwise transfer this product to another party.
EN We Appreciate Your Business We know you will enjoy new 1MORE headphones as much as we do. At 1MORE, we value your satisfaction. If you would like more details on this product or any of our other products, please visit us online by scanning the QR codes. Go to www.1more.com and sign up for VIP, and 1MORE will treat you like one. Tips 1. Please read this instruction manual carefully and retain for future reference. 2. Please fully charge the battery before first use. 3. If the headphones have been unused for more than 3 months, we recommend that you charge them. This will improve battery capacity. 4. Only use charging cables and adapters that are FCC (Federal Communications Commission) approved. 5. In dry environments, static electricity may numb your ear. This is not related to the quality of the product. Safety Information 1. Never disassemble the headphones. There are no user-serviceable parts inside. 2. Do not expose the headphones to temperatures below 32 °F (0 °C) or to temperatures above 113 °F (45 °C). 3. Do not use the headphones in a thunderstorm storm. This could prevent the headphones from working properly, and also increase your chance of being electrically shocked. 4. Do not use oil or any volatile liquid to clean this product. 5. Do not listen at high volumes for extended periods of time. 6. Do not use the headphones in traffic. Do not use the headphones any time it would be dangerous to be unaware of noises around you. 7. Adult supervision is required for children of age 6 and under. 8. If you don't feel comfortable after wearing the headphones, please refer to an aurist for advice on whether in-ear headphones are suitable for you.	EN FAQ 1. How to make sure the headphones have been fully charged? Put the headphones into the charging case, if the headphone status LEDs are glowing this means they have been fully charged. 2. Why won't headphones turn on? Check if your headphones have enough battery life. If not, please charge them for at least 30 minutes. 3. Why won't the headphones connect to my cellphone, or take a long time to connect? Put both buds back into the charging case, then press and hold the pairing button for 3 seconds, click the device name in your settings, they should now pair correctly to the phone. 4. Why won't the headphones make phone calls? The headphones are without microphones or phone call functions. 5. Why is the Bluetooth connection not stable and/or experiences some interruptions? 1) Try shortening the distance between your headphones and the device. Avoid solid barriers in between you and the device. 2) Please keep away from strong interference sources, such as Wi-Fi and GPRS. 3) Please make sure the Bluetooth antenna of your device is not blocked. 6. Why can't the volume be adjusted by the cellphone buttons when playing soothing sounds in 1MORE MUSIC APP? The soothing sounds are stored in the flash of the headphone which can be adjusted only via the APP. 7. The headphones will be disconnected from the cellphone when out of wireless range. They cannot restore the connection after returning back into the wireless range, how to solve it? Click the device name in the cellphone pairing list to connect again. 8. I feel uncomfortable when wearing the headphones, how to solve it? This is mainly because the sizes of ear tips and your canals are not snug, we suggest trying smaller ear tips. * For more detailed product FAQs, please visit the product support section under www.1more.com
EN WEEE Electrical and electronic equipment, parts and batteries marked with this symbol must not be disposed of with normal household wastage, it must be collected and disposed of separately to protect the environment. Your 1MORE retailer will advise you of the correct way of disposal in your country. Safety Caution Do not expose batteries or battery packs to excessive heat such as sunshine, fire or the like. CE Declaration of Conformity Hereby, Tianlab Acoustic Technology Limited declares that the radio equipment type 1MORE ComfoBuds Z of EH601 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: www.1more.com RF exposure information: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction. Radiation Exposure Statement Power is so low that no RF exposure calculation is needed. Declaration for EU Compliance Operation Frequency/Max. EIRP: 2400-2483.5MHz, Max. EIRP is 9.10dBm.	EN Warning Replacement of a battery with an incorrect type that can defeat a safeguard (such as catching fire, explosion, leakage of corrosive electrolyte etc); Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion; Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas; and A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.  The symbol indicates DC voltage.  RECYCLING This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE). This means that this product must be handled pursuant to European directive 2012/19/EU in order to be recycled or dismantled to minimize its impact on the environment. User has the choice to give his product to a competent recycling organization or to the retailer when he buys a new electrical or electronic equipment.  To prevent possible hearing damage, do not listen at high volume levels for long periods.
EN FCC The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types EH601 (FCC ID: ZASDIEH601) has also been tested against this SAR limit. This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or changes to this equipment. Such modifications or changes could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -Reorient or relocate the receiving antenna. -Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help. Supplier's Declaration of Conformity 47 CFR § 2.1077 Compliance Information Unique Identifier: Trade Name: 1MORE Model No.: EH601 Responsible Party – U.S. Contact Information 1MORE USA, Inc. Address: 10225 Barnes Canyon Road, Suite A202, San Diego, California, 92121 Tel: 1-855-551-6673 E-Mail: support@1moreusa.com	EN Model: EH601 Headphone Weight: 2.7 g Case Weight: 34 g Product Weight: 39.4 g Headphone Size: 24 × 9.2 × 14.2 mm Case Size: 60 × 30 × 38.5 mm Headphone Battery Capacity: 30 mAh Case Battery Capacity: 410 mAh Headphone Charging Time: 85 mins Case Charging Time: 80 mins Battery Life * Headphone Fully Charged BLE Local Playtime: approx. 3.5 h Bluetooth Playtime: approx. 2.5 h* * Headphones + Case Fully Charged BLE Local Playtime: approx. 14 h* Bluetooth Playtime: approx. 10 h* Impedance: 22 Ω Wireless Range: 10 m Bluetooth: Bluetooth® 5.0 Bluetooth Protocol: A2DP / AVRCP / BLE Input: 5V=1A Frequency Band: 2.400 GHz ~ 2.4835 GHz The specifications are acquired from laboratory tested data. * The playtime, tested under the laboratory condition of AAC format and 50% volume, may vary with different device setting, environments, usage and other factors. Manufacturer: Tianlab Acoustic Technology Limited Address: Tianlab Building 1403, Zone A Tianlab Industrial Park, Taoyuan Str., Nanshan Dist., Shenzhen, P.R. China Product information can be found at www.1more.com