

材质：80G书纸+胶装
尺寸：86*98mm

封底



www.1more.com

制造商：万魔声学股份有限公司
地址：深圳市南山区留仙大道 3333 号德朗城 A 座 35 楼
服务热线：400-992-0909
Manufacturer: Tinlab Corporation
Addr: No. 3333, Luxian Avenue, Tower A, 35th Floor,
Tangliang City, Nanshan District, Shenzhen, China



FCC ID: 2ASDIES602L
FCC ID: 2ASDIES602R



CMIT ID: 2021DP6872
HVIN: ES602L
HVIN: ES602R



IC: 24662-ES602L
IC: 24662-ES602R





封面

ES602




1MORE ColorBuds 2 时尚豆 用户指南
1MORE ColorBuds 2 User Guide

1MORE MUSIC APP



中国内地用户可扫描二维码，下载 1MORE MUSIC APP
进行产品升级，体验更完整的功能。


1MORE MUSIC APP




For users outside mainland China, please download
the 1MORE MUSIC APP for product upgrades and additional features.
中國內地以外的用戶可下載 1MORE MUSIC APP
進行產品升級，體驗更完整的功能。

筒中

包装内容




产品概览



左、右耳机配对

在充电盒有电的状态下，如左、右耳机置于盒内，打开盒盖，左、右耳机即自动配对。




耳机与蓝牙设备配对

首次使用，开机后其中右耳机白灯闪烁进入搜索模式，3 分钟后未连接到设备，耳机进入待机状态。

* 已连接过设备的耳机，将自动与该设备进行蓝牙配对。

如需连接新设备，将左、右耳机放入盒内，长按配对按钮 2 秒，点击新设备配对列表中的“1MORE ColorBuds 2”进行连接。




* 上述功能适用于单、双模式使用时的任一耳机。

耳机佩戴




开 / 关机




* 上述功能适用于单、双模式使用时的任一耳机。

充电 ① 使用 Type-C 充电线给充电盒充电




② 使用充电盒给耳机充电



触控操作

聆听模式切换
耳机出厂设置为“主动降噪”，长触耳机表面（约 1.5 秒）可在“主动降噪”与“通透”模式间切换。
通话和播放功能可通过触控耳机表面来实现。



* 上述功能适用于单、双模式使用时的任一耳机。
* 拒接电话、速曲及音量调节，请在 1MORE MUSIC APP 及手机等设备键进行操作。
* 以上功能定义因设备不同可能略有差异。

其它功能

- 如左、右耳机无法配对，仅有单个耳机可与蓝牙设备连接，可将左、右耳机放入盒中，三击配对按钮，再点击蓝牙设备配对列表中的“1MORE ColorBuds 2”进行连接。
- 耳机恢复出厂设置：
将左、右耳机放入充电盒中，长按充电盒配对按钮 8 秒，左、右耳机重新自动配对，且蓝牙设备的连接记录被强制清除。
- OTA 固件升级：左、右耳机蓝牙连接时，可直接在 1MORE MUSIC APP 上同步升级。

* 1MORE MUSIC APP 的所有功能，在不同手机及操作系统上使用或有不同，请联系客服了解更多详情。

非保修条例

- 未经授权的安装、误用、碰撞、疏忽、进水、事故、改动、不正确的使用非本产品配件，或翻新、涂改标签、防伪标记；
- 已超过一年保修期；
- 因不可抗力造成的损坏；
- 不符合《产品性能故障表》所列性能故障的情况；
- 因人为原因导致本产品及其配件产生《产品性能故障表》所列性能故障；
- 产品附带的任何配件或赠品。

更多服务可登录 1MORE 官方网站 www.1more.com 点击“服务”项或咨询服务热线：400-992-0909

环保支持

产品中有害物质的名称及含量

部件名称	有害物质					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (CrVI)	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
耳机外壳	×	○	○	○	○	○
电路板及组件	×	×	×	×	○	○
电池	×	○	○	○	○	○
耳套	○	○	○	○	○	○
配件	○	○	○	○	○	○
充电线	×	○	○	○	○	○

FAQ

- 耳机无法开机，该如何解决？
请确认耳机有电，若耳机没有电，请充电 30 分钟以上再开机。
- 耳机与手机蓝牙无法连接，连接时间长，该如何解决？
1) 如左、右耳机无法配对，仅一个耳机可与手机连接时，可将左、右耳机放入盒中，快速 3 击配对按钮，选择设备名，耳机即可与手机连接。
2) 如需与新手机连接，开机且非通话状态下，将左、右耳机放回盒内，长按配对按钮 2 秒，在新手机蓝牙列表里面选择耳机蓝牙名，耳机将与新手机进行蓝牙配对。
- 安卓系统手机连接耳机成功后，无法听到音乐，该如何解决？
在耳机与手机连接成功后，点击所连接设备名称右边的图标，进入后确保“媒体音频”选项已被开启。
- 在安卓系统手机连接耳机成功后，无法通话，该如何解决？
在耳机与手机连接成功后，点击所连接设备名称右边的图标，进入后确保“手机音频”选项已被开启。
- 蓝牙连接不稳定，出现断连情况，该如何解决？
1) 请尽量缩短设备与耳机之间的距离，避开实体障碍物；
2) 请远离强干扰源环境（Wi-Fi / GPRS）等；
3) 请确保手机天线不被遮挡。
- 使用第三方音乐播放软件时，为什么部分按键功能与说明书定义不一致？
1) 手机软件与第三方软件因定义不同而导致耳机按键功能有差异；
2) 建议使用品牌手机系统自带音乐播放器。

扫描、关注 1MORE 官方微信公众号

























































欢迎访问 1MORE 社区：bbs.1more.com
登录 www.1more.com，注册成为 1MORE 会员，更多精彩在等你。



型号：ES602	满电播放时长（标准开）* 单耳满电，6 小时
耳机重量（单个）：4.9 克	搭配充电盒满电，18 小时
充电盒重量：34.5 克	满电播放时长（标准开）* 单耳满电，8 小时
耳机重量：44.3 克	搭配充电盒满电，24 小时
耳机尺寸：27 × 21 × 20 mm	蓝牙规范：Bluetooth® 5.2
充电盒尺寸：60 × 30 × 38 mm	蓝牙协议：HFP / A2DP / AVRCP
喇叭阻抗：32 Ω	输入：5V=1A
通讯距离：10 米（在空*环境下）	工作温度：0℃~45℃
耳机电池容量（单个）：55mAh	频率波段：2,400 GHz ~ 2,4835 GHz
充电盒电池容量：410 mAh	
耳机充电时间：70 分钟	
充电盒充电时间（有线）：85 分钟	

规格参数为实验室测试数据。
* 播放时长为 AAC 格式、50% 音量条件下的实验室测试数据，依设备设置、环境、使用情况等诸多其他因素可能有所差异。

制造商：万魔声学股份有限公司
地址：深圳市南山区留仙大道 3333 号德朗城 A 座 35 楼
执行标准：GB8898

	<div>EN</div> <div><h3>In The Box</h3><div><div><p>Headphones x 1 Pair</p></div><div><p>Charging Case x 1</p></div><div><p>Type-C Charging Cable x 1</p></div><div><p>Silicone Ear Tip (XS/S/L)</p></div><div><p>User Guide x 1</p></div><div><p>Warranty Card x 1</p></div><div><p>1MORE Bear Sticker x 1</p></div></div></div> <tr><td><div>EN</div><div><h3>Product Overview</h3><div><div></div><div></div></div></div></td><td><div>EN</div><div><h3>Placement</h3><div></div><h3>Power</h3><div><div><p>Power On: Take the headphones out of the charging case (with charge), the headphones will turn on automatically.</p></div><div><p>Power Off: Put the headphones back into the correct slot of the charging case and close the lid, they will automatically turn off and start charging.</p></div></div><p>* Above functions are available for either earbud in individual or stereo mode.</p></div></td></tr> <tr><td><div>EN</div><div><h3>Headphones Pairing</h3><p>The Left and Right headphones will automatically pair to each other after the lid is open when they are in the case (with charge).</p><div></div><h3>Bluetooth Pairing To The Device</h3><p>To connect to your device for the first time, turn the headphones on to enter the pairing mode, the Right headphone will flash in white alternatively. Headphones will enter a standby mode if not paired to a device within 3 minutes.</p><p>* After the first successful pairing, headphones will automatically connect to your device.</p><p>To pair the headphones to a new device, simply place them into the charging case and press the pairing button for 2 seconds. Then click "1MORE ColorBuds 2" in the new device pairing list to connect.</p><p>* After the first successful pairing, headphones will automatically connect to your device.</p></div></td><td><div>EN</div><div><h3>Charging</h3><p>① To charge the case with Type-C cable.</p><div><div><p>A full charge will take around 85 minutes.</p></div><div><p>The LED light of the charging case will indicate different battery statuses.</p></div></div><p>* The headphones are certified by Qi wireless charging, please use a Qi certified charging pad to ensure charging safety and efficiency.</p><p>② To charge the headphones with the case.</p><div><div><p>Put headphones in correct slot until it locks in via the magnet. The white light of headphones will indicate headphones are charging.</p></div><div><p>A full charge will take around 70 minutes. The red light on the headphones turning off indicates the charging is complete.</p></div></div></div></td></tr> <tr><td><div>EN</div><div><h3>Battery Status Display in 1MORE MUSIC APP</h3><p>Battery status of headphones and charging case will be displayed in 1MORE MUSIC APP.</p><div></div><h3>Battery Notification</h3><div><div><p>LED indicator for low battery: when there is 25-30 minutes of use left, you will hear the notification sound and the LED indicator will flash white twice.</p></div><div><p>When the charge is too low on the case battery, the LED indicator will flash red.</p></div></div></div></td><td><div>EN</div><div><h3>Touch Controls</h3><p>Switch the Listening Modes</p><p>The default setting of the headphones is "ANC On", touch and hold on the outside of the headphone to switch "ANC On" to "Pass-through".</p><p>Phonecalls and music can be controlled by tapping the outside of the earbuds.</p><div><div><p>Phone Call</p></div><div><p>Touch Control Area</p></div><div><p>Answer/End call:																
Double-tap</p></div><div><p>Voice control on cellphone: Tap 3 times when Bluetooth on and no phone calls</p></div><div><p>Playback</p></div><div><p>Play/Pause: Double-tap</p></div></div><p>* Above functions are available for either earbud in individual or Stereo mode. * To decline a call, change a song or control volume, please operate on 1MORE MUSIC APP, paired mobile phone or device. * Above functions may vary with different devices.</p></div></td></tr> <tr><td><div>EN</div><div><h3>Smart Playback</h3><p>An IR Sensor automatically detects when you take out your headphones to stop playback intuitively and resumes playback when you put them back in.</p><p>To turn off Auto-Play, connect the headphones to the 1MORE MUSIC App and change in the settings.</p><div></div></div></td><td><div>EN</div><div><h3>Extra Functions</h3><div></div><p>1. If only 1 headphone can be paired to the device, Open the case, click the pairing button in the case 3 times quickly to initiate a Left & Right pairing, and then click "1MORE ColorBuds 2" in the device pairing list to connect to your device.</p><p>2. Resetting the headphones: Put both Left and Right headphones into the case, then press and hold the pairing button in the case for 8 seconds. The headphones will initiate pairing to each other again and the pairing records on the mobile phone/device will be cleared.</p><p>3. OTA Firmware Update: can be done synchronously via the 1MORE MUSIC APP while the Left and Right earbuds are paired to each other.</p><p>* Functions of 1MORE MUSIC APP may vary with different cellphones or operating systems. For more details, please contact our customer service.</p></div></td></tr> <tr><td><div>EN</div><div><h3>1MORE (1) Year Limited Warranty</h3><p>1MORE warrants to the original retail purchaser that this product is to be free from defective materials and workmanship for a period of one year from the date of purchase if it is properly used and maintained. If this product proves defective in either material or workmanship, 1MORE, at its option, will (a) repair the product with new or refurbished parts, or (b) replace the product with an equivalent new or refurbished product, at no charge for parts or labor. If the product model is no longer available and cannot be repaired effectively or replaced with an identical model, 1MORE at its sole option may replace the unit with a current model of equal or greater value. In some cases, modification to the mounting surface may be required where a new model is substituted. 1MORE assumes no responsibility or liability for such modification. TO OBTAIN A REPAIR OR REPLACEMENT UNDER THE TERMS OF THIS WARRANTY, PLEASE RETURN TO THE ORIGINAL DEALER FIRST AND THE ORIGINAL DEALER SHALL REPAIR THE PRODUCT WITH NEW OR REFURBISHED PARTS OR REPLACE THE PRODUCT WITH AN EQUIVALENT NEW OR REFURBISHED PRODUCT. You will be required to submit a proof of purchasing details, including but not limited to a receipt or sales invoice. Return shipping for exchanges/repairs is the sole responsibility of the original retail purchaser.</p><p>Limitations:</p> • This limited warranty does not cover the failure of the product resulting from improper installation, misuse, abuse, accident, neglect, mishandling, or wear from ordinary use or environmental deterioration. • This limited warranty does not cover cosmetic damage, including paint damage, or consequential damage to other components or premises which may result for any reason from the failure of the product. • This limited warranty is null and void for products not used in accordance with 1MORE's instructions. • This limited warranty is null and void for products with altered or missing serial numbers and for products not purchased from an AUTHORIZED dealer. • This limited warranty terminates if you sell or otherwise transfer this product to another party. </div></td><td><div>EN</div><div><h3>We Appreciate Your Business</h3><p>We know you will enjoy new 1MORE headphones as much as we do. At 1MORE, we value your satisfaction, if you would like more details on this product or any of our other products, please visit us online by scanning the QR code. Go to www.1more.com and sign up for VIP, and 1MORE will treat you like one.</p><h3>Tips</h3> 1. Please read this instruction manual carefully and retain for future reference. 2. Please fully charge the battery before first use. 3. If the headphones have been unused for more than 3 months, we recommend that you charge them. This will improve battery capacity. 4. Only use charging cables and adapters that are FCC (Federal Communications Commission) approved. 5. In dry environments, static electricity may numb your ear. This is not related to the quality of the product. <h3>Safety Information</h3> 1. Never disassemble the headphones. There are no user-serviceable parts inside. 2. Do not expose the headphones to temperatures below 32 °F (0 °C) or to temperatures above 113 °F (45 °C). 3. Do not use the headphones in a thunderstorm storm. This could prevent the headphones from working properly, and also increase your chance of being electrically shocked. 4. Do not use oil or any volatile liquid to clean this product. 5. Do not listen at high volumes for extended periods of time. 6. Do not use the headphones in traffic. Do not use the headphones any time it would be dangerous to be unaware of noises around you. 7. Adult supervision is required for children of age 6 and under. 8. If you don't feel comfortable after wearing the headphones, please refer to an aurist for advice on whether in-ear headphones are suitable for you. </div></td></tr> <tr><td><div>EN</div><div><h3>FAQ</h3> 1. Why the headphones cannot be turned on? Check if your headphones have enough battery life. If not, please charge them for at least 30 minutes. 2. Why the headphones cannot connect to my cellphone, or take a long time to connect? 1) If the earbuds cannot pair to one another, and only one earbud will pair with your cellphone, then put both buds back into the charging case and quickly press the pairing button 3 times, click the device name, they should now pair correctly to the phone. 2) To pair the earbuds to a new cellphone, simply place them into the charging case and depress the pairing button for 2 seconds. Then click the new device name and pair with the new cellphone. 3. Why the headphones cannot play music after successfully connecting to my Android device? After pairing successfully, on the Bluetooth menu of your device, tap the icon on the right of your device name and make sure the "Media Audio" option is on. 4. Why there is no sound from the headphones while making phone calls after successfully connecting to my Android device? After pairing successfully, on the Bluetooth menu of your device, tap the icon on the right of your device name and make sure the "Phone Audio" option is on. 5. Why the Bluetooth connection is not stable and causes some interruptions? 1) Try shortening the distance between your headphones and device. Avoid solid barriers in between. 2) Please keep away from strong interference sources, such as Wi-Fi and GPRS. 3) Please make sure the Bluetooth antenna of your device is not blocked. 6. Why some control functions do not match those in the manual while using third party music/video player Apps? Your operating system and the third party music/video player apps may have different settings for the in-line remote control functions. We recommend that you use the music/video player apps that your device has originally provided. <p>* For more detailed product FAQs, please visit the product support section under www.1more.com</p></div></td><td><div>EN</div><div><h3>WEEE</h3><p>Electrical and electronic equipment, parts and batteries marked with this symbol must not be disposed of with normal household waste; it must be collected and disposed of separately to protect the environment.</p><p>Your 1MORE retailer will advise you of the correct way of disposal in your country.</p><h3>Safety Caution</h3><p>Do not expose batteries or battery packs to excessive heat such as sunshine, fire or the like.</p><h3>CE</h3><p>Declaration of Conformity Hereby, TiniLab Corporation declares that the radio equipment type "1MORE ColorBuds 2" is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: www.1more.com</p><p>RF exposure information: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction. Radiation Exposure Statement Power is so low that no RF exposure calculation is needed.</p><p>Declaration for EU Compliance Operation Frequency/Max. EIRP: 2400-2483.5MHz, Left ear Max. EIRP is 12dBm, Right ear Max. EIRP is 12dBm.</p></div></td></tr> <tr><td><div>EN</div><div><h3>Warning</h3><p>Replacement of a battery with an incorrect type that can defeat a safeguard (such as catching fire, explosion, leakage of corrosive electrolyte etc);</p><p>Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion;</p><p>Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas; and A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.</p><p>⚡ The symbol indicates DC voltage.</p><p> RECYCLING</p><p>This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE). This means that this product must be handled pursuant to European directive 2014/53/EU in order to be recycled or dismantled to minimize its impact on the environment.</p><p>User has the choice to give his product to a competent recycling organization or to the retailer when he buys a new electrical or electronic equipment.</p><p> To prevent possible hearing damage, do not listen at high volume levels for long periods.</p></div></td><td><div>EN</div><div><h3>FCC</h3><p>The SAR limit of USA (FCC) is 1.6 W/kg for head averaged over one gram of tissue. Device types ES602 (FCC ID: 2ASDIES602L (Left ear) , 2ASDIES602R (Right ear)) has also been tested with 0mm against this SAR limit.</p><p>NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or changesto this equipment. Such modifications or changes could void the user's authority to operate the equipment.</p><p>NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> - Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver. - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. - Consult the dealer or an experienced radio/TV technician for help. <p>This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:</p> (1) This device may not cause harmful interference. (2) This device must accept any interference received, including interference that may cause undesired operation. </div></td></tr> <tr><td><div>EN</div><div><p>Supplier's Declaration of Conformity 47 CFR § 2.1077 Compliance Information Unique Identifier: Trade Name: 1MORE Model No.: ES602 Responsible Party – U.S. Contact Information 1MORE USA, Inc. Address: 10225 Barnes Canyon Road, Suite A202, San Diego, California, 92121 Tel: 1-855-551-6673 E-Mail: support@1moreusa.com</p><p>IC regulatory conformance This device complies with CAN ICES-003 (B)/NMB-003(B) and CAN RSS-216 / CNR-216 . This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference. (2) This device must accept any interference, including interference that may cause undesired operation of the device. Cet appareil est conforme à la norme ICES-003 (B)/NMB-003 (B) et au CAN RSS-216 / CNR-216 . Cet appareil contient des émetteurs / récepteurs exempt (s) de la licence qui sont conformes aux RSS exemptes de l'Innovation, Sciences et Développement économique Canada. Son fonctionnement est soumis aux deux conditions suivantes: (1) Cet appareil ne doit pas provoquer d'interférences. (2) Cet appareil doit accepter toute interférence, y compris les interférences susceptibles de provoquer un fonctionnement indésirable de l'appareil.</p><p>The SAR limit of Canada (ICES) is 1.6 W/kg for head averaged over one gram of tissue. Device types ES602 (IC: 24662-ES602L (Left ear) , 24662-ES602R (Right ear)) has also been tested with 0mm against this SAR limit.</p><p>* Do not put the battery in trash that is disposed of in landfills. When disposing of the battery, comply with local laws or regulations.</p></div></td><td><div>EN</div><div><div><div>Model: ES602</div><div>Headphone Weight (Single): 4.9 g</div><div>Case Weight: 34.5 g</div><div>Product Weight: 44.3 g</div><div>Headphone Size: 27 × 21 × 20 mm</div><div>Case Size: 60 × 30 × 38 mm</div><div>Headphone Battery Capacity (Single): 55 mAh</div><div>Case Battery Capacity: 410 mAh</div><div>Headphone Charging Time: 70 mins</div><div>Case Charging Time (with cable): 85 mins</div><div>Fully Charged Playtime (ANC On)</div><div>Headphone: 6 hours</div></div><div><div>Headphones + Case: 18 hours</div><div>Fully Charged Playtime (ANC Off)</div><div>Headphone: 8 hours</div><div>Headphones + Case: 24 hours</div><div>Impedance: 32 Ω</div><div>Wireless Range: 10 m</div><div>Bluetooth: Bluetooth® 5.2</div><div>Bluetooth Protocol: HFP / A2DP / AVRCP</div><div>Input: 5V = 1A</div><div>Working Temperature: 0 °C ~ 45 °C</div><div>Frequency Band: 2.400 GHz ~ 2.4835 GHz</div></div></div><div>The specifications are acquired from laboratory tested data. * The playback time, tested under the laboratory condition of AAC format and 50% volume, may vary with different device setting, environments, usage and other factors.</div><div>Manufacturer: TiniLab Corporation Add: No. 3333, Liuxian Avenue, Tower A, 35th Floor, Tanglang City, Nanshan District, Shenzhen, China Product information can be found at www.1more.com</div></td></tr>	EN Product Overview  	EN Placement  Power  Power On: Take the headphones out of the charging case (with charge), the headphones will turn on automatically.  Power Off: Put the headphones back into the correct slot of the charging case and close the lid, they will automatically turn off and start charging. * Above functions are available for either earbud in individual or stereo mode.	<div>EN</div> <div><h3>Headphones Pairing</h3><p>The Left and Right headphones will automatically pair to each other after the lid is open when they are in the case (with charge).</p><div></div><h3>Bluetooth Pairing To The Device</h3><p>To connect to your device for the first time, turn the headphones on to enter the pairing mode, the Right headphone will flash in white alternatively. Headphones will enter a standby mode if not paired to a device within 3 minutes.</p><p>* After the first successful pairing, headphones will automatically connect to your device.</p><p>To pair the headphones to a new device, simply place them into the charging case and press the pairing button for 2 seconds. Then click "1MORE ColorBuds 2" in the new device pairing list to connect.</p><p>* After the first														
successful pairing, headphones will automatically connect to your device.</p></div>	EN Charging ① To charge the case with Type-C cable.  A full charge will take around 85 minutes.  The LED light of the charging case will indicate different battery statuses. * The headphones are certified by Qi wireless charging, please use a Qi certified charging pad to ensure charging safety and efficiency. ② To charge the headphones with the case.  Put headphones in correct slot until it locks in via the magnet. The white light of headphones will indicate headphones are charging.  A full charge will take around 70 minutes. The red light on the headphones turning off indicates the charging is complete.	EN Battery Status Display in 1MORE MUSIC APP Battery status of headphones and charging case will be displayed in 1MORE MUSIC APP.  Battery Notification  LED indicator for low battery: when there is 25-30 minutes of use left, you will hear the notification sound and the LED indicator will flash white twice.  When the charge is too low on the case battery, the LED indicator will flash red.	EN Touch Controls Switch the Listening Modes The default setting of the headphones is "ANC On", touch and hold on the outside of the headphone to switch "ANC On" to "Pass-through". Phonecalls and music can be controlled by tapping the outside of the earbuds.  Phone Call  Touch Control Area  Answer/End call: Double-tap  Voice control on cellphone: Tap 3 times when Bluetooth on and no phone calls  Playback  Play/Pause: Double-tap * Above functions are available for either earbud in individual or Stereo mode. * To decline a call, change a song or control volume, please operate on 1MORE MUSIC APP, paired mobile phone or device. * Above functions may vary with different devices.	EN Smart Playback An IR Sensor automatically detects when you take out your headphones to stop playback intuitively and resumes playback when you put them back in. To turn off Auto-Play, connect the headphones to the 1MORE MUSIC App and change in the settings. 	EN Extra Functions  1. If only 1 headphone can be paired to the device, Open the case, click the pairing button in the case 3 times quickly to initiate a Left & Right pairing, and then click "1MORE ColorBuds 2" in the device pairing list to connect to your device. 2. Resetting the headphones: Put both Left and Right headphones into the case, then press and hold the pairing button in the case for 8 seconds. The headphones will initiate pairing to each other again and the pairing records on the mobile phone/device will be cleared. 3. OTA Firmware Update: can be done synchronously via the 1MORE MUSIC APP while the Left and Right earbuds are paired to each other. * Functions of 1MORE MUSIC APP may vary with different cellphones or operating systems. For more details, please contact our customer service.	EN 1MORE (1) Year Limited Warranty 1MORE warrants to the original retail purchaser that this product is to be free from defective materials and workmanship for a period of one year from the date of purchase if it is properly used and maintained. If this product proves defective in either material or workmanship, 1MORE, at its option, will (a) repair the product with new or refurbished parts, or (b) replace the product with an equivalent new or refurbished product, at no charge for parts or labor. If the product model is no longer available and cannot be repaired effectively or replaced with an identical model, 1MORE at its sole option may replace the unit with a current model of equal or greater value. In some cases, modification to the mounting surface may be required where a new model is substituted. 1MORE assumes no responsibility or liability for such modification. TO OBTAIN A REPAIR OR REPLACEMENT UNDER THE TERMS OF THIS WARRANTY, PLEASE RETURN TO THE ORIGINAL DEALER FIRST AND THE ORIGINAL DEALER SHALL REPAIR THE PRODUCT WITH NEW OR REFURBISHED PARTS OR REPLACE THE PRODUCT WITH AN EQUIVALENT NEW OR REFURBISHED PRODUCT. You will be required to submit a proof of purchasing details, including but not limited to a receipt or sales invoice. Return shipping for exchanges/repairs is the sole responsibility of the original retail purchaser. Limitations: • This limited warranty does not cover the failure of the product resulting from improper installation, misuse, abuse, accident, neglect, mishandling, or wear from ordinary use or environmental deterioration. • This limited warranty does not cover cosmetic damage, including paint damage, or consequential damage to other components or premises which may result for any reason from the failure of the product. • This limited warranty is null and void for products not used in accordance with 1MORE's instructions. • This limited warranty is null and void for products with altered or missing serial numbers and for products not purchased from an AUTHORIZED dealer. • This limited warranty terminates if you sell or otherwise transfer this product to another party.	<div>EN</div> <div><h3>We Appreciate Your Business</h3><p>We know you will enjoy new 1MORE headphones as much as we do. At 1MORE, we value your satisfaction, if you would like more details on this product or any of our other products, please visit us online by scanning the QR code. Go to www.1more.com and sign up for VIP, and 1MORE will treat you like one.</p><h3>Tips</h3> 1. Please read this instruction manual carefully and retain for future reference. 2. Please fully charge the battery before first use. 3. If the headphones have been unused for more than 3 months, we recommend that you charge them. This will improve battery capacity. 4. Only use charging cables and adapters that are FCC (Federal Communications Commission) approved. 5. In dry environments, static electricity may numb your ear. This is not related to the quality of the product. <h3>Safety Information</h3> 1. Never disassemble the headphones. There are no user-serviceable parts inside. 2. Do not expose the headphones to temperatures below 32 °F (0 °C) or to temperatures above 113 °F (45 °C). 3. Do not use the headphones in a thunderstorm storm. This could prevent the headphones from working properly, and also increase your chance of being electrically shocked. 4. Do not use oil or any volatile liquid to clean this product. 5. Do not listen at high volumes for extended periods of time. 6. Do not use the headphones in traffic. Do not use the headphones any time it would be dangerous										
to be unaware of noises around you. 7. Adult supervision is required for children of age 6 and under. 8. If you don't feel comfortable after wearing the headphones, please refer to an aurist for advice on whether in-ear headphones are suitable for you. </div>	EN FAQ 1. Why the headphones cannot be turned on? Check if your headphones have enough battery life. If not, please charge them for at least 30 minutes. 2. Why the headphones cannot connect to my cellphone, or take a long time to connect? 1) If the earbuds cannot pair to one another, and only one earbud will pair with your cellphone, then put both buds back into the charging case and quickly press the pairing button 3 times, click the device name, they should now pair correctly to the phone. 2) To pair the earbuds to a new cellphone, simply place them into the charging case and depress the pairing button for 2 seconds. Then click the new device name and pair with the new cellphone. 3. Why the headphones cannot play music after successfully connecting to my Android device? After pairing successfully, on the Bluetooth menu of your device, tap the icon on the right of your device name and make sure the "Media Audio" option is on. 4. Why there is no sound from the headphones while making phone calls after successfully connecting to my Android device? After pairing successfully, on the Bluetooth menu of your device, tap the icon on the right of your device name and make sure the "Phone Audio" option is on. 5. Why the Bluetooth connection is not stable and causes some interruptions? 1) Try shortening the distance between your headphones and device. Avoid solid barriers in between. 2) Please keep away from strong interference sources, such as Wi-Fi and GPRS. 3) Please make sure the Bluetooth antenna of your device is not blocked. 6. Why some control functions do not match those in the manual while using third party music/video player Apps? Your operating system and the third party music/video player apps may have different settings for the in-line remote control functions. We recommend that you use the music/video player apps that your device has originally provided. * For more detailed product FAQs, please visit the product support section under www.1more.com	EN WEEE Electrical and electronic equipment, parts and batteries marked with this symbol must not be disposed of with normal household waste; it must be collected and disposed of separately to protect the environment. Your 1MORE retailer will advise you of the correct way of disposal in your country. Safety Caution Do not expose batteries or battery packs to excessive heat such as sunshine, fire or the like. CE Declaration of Conformity Hereby, TiniLab Corporation declares that the radio equipment type "1MORE ColorBuds 2" is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: www.1more.com RF exposure information: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction. Radiation Exposure Statement Power is so low that no RF exposure calculation is needed. Declaration for EU Compliance Operation Frequency/Max. EIRP: 2400-2483.5MHz, Left ear Max. EIRP is 12dBm, Right ear Max. EIRP is 12dBm.	EN Warning Replacement of a battery with an incorrect type that can defeat a safeguard (such as catching fire, explosion, leakage of corrosive electrolyte etc); Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion; Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas; and A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas. ⚡ The symbol indicates DC voltage.  RECYCLING This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE). This means that this product must be handled pursuant to European directive 2014/53/EU in order to be recycled or dismantled to minimize its impact on the environment. User has the choice to give his product to a competent recycling organization or to the retailer when he buys a new electrical or electronic equipment.  To prevent possible hearing damage, do not listen at high volume levels for long periods.	EN FCC The SAR limit of USA (FCC) is 1.6 W/kg for head averaged over one gram of tissue. Device types ES602 (FCC ID: 2ASDIES602L (Left ear) , 2ASDIES602R (Right ear)) has also been tested with 0mm against this SAR limit. NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or changesto this equipment. Such modifications or changes could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: - Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver. - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. - Consult the dealer or an experienced radio/TV technician for help. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference. (2) This device must accept any interference received, including interference that may cause undesired operation.	EN Supplier's Declaration of Conformity 47 CFR § 2.1077 Compliance Information Unique Identifier: Trade Name: 1MORE Model No.: ES602 Responsible Party – U.S. Contact Information 1MORE USA, Inc. Address: 10225 Barnes Canyon Road, Suite A202, San Diego, California, 92121 Tel: 1-855-551-6673 E-Mail: support@1moreusa.com IC regulatory conformance This device complies with CAN ICES-003 (B)/NMB-003(B) and CAN RSS-216 / CNR-216 . This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference. (2) This device must accept any interference, including interference that may cause undesired operation of the device. Cet appareil est conforme à la norme ICES-003 (B)/NMB-003 (B) et au CAN RSS-216 / CNR-216 . Cet appareil contient des émetteurs / récepteurs exempt (s) de la licence qui sont conformes aux RSS exemptes de l'Innovation, Sciences et Développement économique Canada. Son fonctionnement est soumis aux deux conditions suivantes: (1) Cet appareil ne doit pas provoquer d'interférences. (2) Cet appareil doit accepter toute interférence, y compris les interférences susceptibles de provoquer un fonctionnement indésirable de l'appareil. The SAR limit of Canada (ICES) is 1.6 W/kg for head averaged over one gram of tissue. Device types ES602 (IC: 24662-ES602L (Left ear) , 24662-ES602R (Right ear)) has also been tested with 0mm against this SAR limit. * Do not put the battery in trash that is disposed of in landfills. When disposing of the battery, comply with local laws or regulations.	<div>EN</div> <div><div><div>Model: ES602</div><div>Headphone Weight (Single): 4.9 g</div><div>Case Weight: 34.5 g</div><div>Product Weight: 44.3 g</div><div>Headphone Size: 27 × 21 × 20 mm</div><div>Case Size: 60 × 30 × 38 mm</div><div>Headphone Battery Capacity (Single): 55 mAh</div><div>Case Battery Capacity: 410 mAh</div><div>Headphone Charging Time: 70 mins</div><div>Case Charging Time (with cable): 85 mins</div><div>Fully Charged Playtime (ANC On)</div><div>Headphone: 6 hours</div></div><div><div>Headphones + Case: 18 hours</div><div>Fully Charged Playtime (ANC Off)</div><div>Headphone: 8 hours</div><div>Headphones + Case: 24 hours</div><div>Impedance: 32 Ω</div><div>Wireless Range: 10 m</div><div>Bluetooth: Bluetooth® 5.2</div><div>Bluetooth Protocol: HFP / A2DP / AVRCP</div><div>Input: 5V = 1A</div><div>Working Temperature:											
0 °C ~ 45 °C</div><div>Frequency Band: 2.400 GHz ~ 2.4835 GHz</div></div></div> <div>The specifications are acquired from laboratory tested data. * The playback time, tested under the laboratory condition of AAC format and 50% volume, may vary with different device setting, environments, usage and other factors.</div> <div>Manufacturer: TiniLab Corporation Add: No. 3333, Liuxian Avenue, Tower A, 35th Floor, Tanglang City, Nanshan District, Shenzhen, China Product information can be found at www.1more.com</div>																	
EN Product Overview  	EN Placement  Power  Power On: Take the headphones out of the charging case (with charge), the headphones will turn on automatically.  Power Off: Put the headphones back into the correct slot of the charging case and close the lid, they will automatically turn off and start charging. * Above functions are available for either earbud in individual or stereo mode.																
EN Headphones Pairing The Left and Right headphones will automatically pair to each other after the lid is open when they are in the case (with charge).  Bluetooth Pairing To The Device To connect to your device for the first time, turn the headphones on to enter the pairing mode, the Right headphone will flash in white alternatively. Headphones will enter a standby mode if not paired to a device within 3 minutes. * After the first successful pairing, headphones will automatically connect to your device. To pair the headphones to a new device, simply place them into the charging case and press the pairing button for 2 seconds. Then click "1MORE ColorBuds 2" in the new device pairing list to connect. * After the first successful pairing, headphones will automatically connect to your device.	EN Charging ① To charge the case with Type-C cable.  A full charge will take around 85 minutes.  The LED light of the charging case will indicate different battery statuses. * The headphones are certified by Qi wireless charging, please use a Qi certified charging pad to ensure charging safety and efficiency. ② To charge the headphones with the case.  Put headphones in correct slot until it locks in via the magnet. The white light of headphones will indicate headphones are charging.  A full charge will take around 70 minutes. The red light on the headphones turning off indicates the charging is complete.																
EN Battery Status Display in 1MORE MUSIC APP Battery status of headphones and charging case will be displayed in 1MORE MUSIC APP.  Battery Notification  LED indicator for low battery: when there is 25-30 minutes of use left, you will hear the notification sound and the LED indicator will flash white twice.  When the charge is too low on the case battery, the LED indicator will flash red.	EN Touch Controls Switch the Listening Modes The default setting of the headphones is "ANC On", touch and hold on the outside of the headphone to switch "ANC On" to "Pass-through". Phonecalls and music can be controlled by tapping the outside of the earbuds.  Phone Call  Touch Control Area  Answer/End call: Double-tap  Voice control on cellphone: Tap 3 times when Bluetooth on and no phone calls  Playback  Play/Pause: Double-tap * Above functions are available for either earbud in individual or Stereo mode. * To decline a call, change a song or control volume, please operate on 1MORE MUSIC APP, paired mobile phone or device. * Above functions may vary with different devices.																
EN Smart Playback An IR Sensor automatically detects when you take out your headphones to stop playback intuitively and resumes playback when you put them back in. To turn off Auto-Play, connect the headphones to the 1MORE MUSIC App and change in the settings. 	EN Extra Functions  1. If only 1 headphone can be paired to the device, Open the case, click the pairing button in the case 3 times quickly to initiate a Left & Right pairing, and then click "1MORE ColorBuds 2" in the device pairing list to connect to your device. 2. Resetting the headphones: Put both Left and Right headphones into the case, then press and hold the pairing button in the case for 8 seconds. The headphones will initiate pairing to each other again and the pairing records on the mobile phone/device will be cleared. 3. OTA Firmware Update: can be done synchronously via the 1MORE MUSIC APP while the Left and Right earbuds are paired to each other. * Functions of 1MORE MUSIC APP may vary with different cellphones or operating systems. For more details, please contact our customer service.																
EN 1MORE (1) Year Limited Warranty 1MORE warrants to the original retail purchaser that this product is to be free from defective materials and workmanship for a period of one year from the date of purchase if it is properly used and maintained. If this product proves defective in either material or workmanship, 1MORE, at its option, will (a) repair the product with new or refurbished parts, or (b) replace the product with an equivalent new or refurbished product, at no charge for parts or labor. If the product model is no longer available and cannot be repaired effectively or replaced with an identical model, 1MORE at its sole option may replace the unit with a current model of equal or greater value. In some cases, modification to the mounting surface may be required where a new model is substituted. 1MORE assumes no responsibility or liability for such modification. TO OBTAIN A REPAIR OR REPLACEMENT UNDER THE TERMS OF THIS WARRANTY, PLEASE RETURN TO THE ORIGINAL DEALER FIRST AND THE ORIGINAL DEALER SHALL REPAIR THE PRODUCT WITH NEW OR REFURBISHED PARTS OR REPLACE THE PRODUCT WITH AN EQUIVALENT NEW OR REFURBISHED PRODUCT. You will be required to submit a proof of purchasing details, including but not limited to a receipt or sales invoice. Return shipping for exchanges/repairs is the sole responsibility of the original retail purchaser. Limitations: • This limited warranty does not cover the failure of the product resulting from improper installation, misuse, abuse, accident, neglect, mishandling, or wear from ordinary use or environmental deterioration. • This limited warranty does not cover cosmetic damage, including paint damage, or consequential damage to other components or premises which may result for any reason from the failure of the product. • This limited warranty is null and void for products not used in accordance with 1MORE's instructions. • This limited warranty is null and void for products with altered or missing serial numbers and for products not purchased from an AUTHORIZED dealer. • This limited warranty terminates if you sell or otherwise transfer this product to another party.	EN We Appreciate Your Business We know you will enjoy new 1MORE headphones as much as we do. At 1MORE, we value your satisfaction, if you would like more details on this product or any of our other products, please visit us online by scanning the QR code. Go to www.1more.com and sign up for VIP, and 1MORE will treat you like one. Tips 1. Please read this instruction manual carefully and retain for future reference. 2. Please fully charge the battery before first use. 3. If the headphones have been unused for more than 3 months, we recommend that you charge them. This will improve battery capacity. 4. Only use charging cables and adapters that are FCC (Federal Communications Commission) approved. 5. In dry environments, static electricity may numb your ear. This is not related to the quality of the product. Safety Information 1. Never disassemble the headphones. There are no user-serviceable parts inside. 2. Do not expose the headphones to temperatures below 32 °F (0 °C) or to temperatures above 113 °F (45 °C). 3. Do not use the headphones in a thunderstorm storm. This could prevent the headphones from working properly, and also increase your chance of being electrically shocked. 4. Do not use oil or any volatile liquid to clean this product. 5. Do not listen at high volumes for extended periods of time. 6. Do not use the headphones in traffic. Do not use the headphones any time it would be dangerous to be unaware of noises around you. 7. Adult supervision is required for children of age 6 and under. 8. If you don't feel comfortable after wearing the headphones, please refer to an aurist for advice on whether in-ear headphones are suitable for you.																
EN FAQ 1. Why the headphones cannot be turned on? Check if your headphones have enough battery life. If not, please charge them for at least 30 minutes. 2. Why the headphones cannot connect to my cellphone, or take a long time to connect? 1) If the earbuds cannot pair to one another, and only one earbud will pair with your cellphone, then put both buds back into the charging case and quickly press the pairing button 3 times, click the device name, they should now pair correctly to the phone. 2) To pair the earbuds to a new cellphone, simply place them into the charging case and depress the pairing button for 2 seconds. Then click the new device name and pair with the new cellphone. 3. Why the headphones cannot play music after successfully connecting to my Android device? After pairing successfully, on the Bluetooth menu of your device, tap the icon on the right of your device name and make sure the "Media Audio" option is on. 4. Why there is no sound from the headphones while making phone calls after successfully connecting to my Android device? After pairing successfully, on the Bluetooth menu of your device, tap the icon on the right of your device name and make sure the "Phone Audio" option is on. 5. Why the Bluetooth connection is not stable and causes some interruptions? 1) Try shortening the distance between your headphones and device. Avoid solid barriers in between. 2) Please keep away from strong interference sources, such as Wi-Fi and GPRS. 3) Please make sure the Bluetooth antenna of your device is not blocked. 6. Why some control functions do not match those in the manual while using third party music/video player Apps? Your operating system and the third party music/video player apps may have different settings for the in-line remote control functions. We recommend that you use the music/video player apps that your device has originally provided. * For more detailed product FAQs, please visit the product support section under www.1more.com	EN WEEE Electrical and electronic equipment, parts and batteries marked with this symbol must not be disposed of with normal household waste; it must be collected and disposed of separately to protect the environment. Your 1MORE retailer will advise you of the correct way of disposal in your country. Safety Caution Do not expose batteries or battery packs to excessive heat such as sunshine, fire or the like. CE Declaration of Conformity Hereby, TiniLab Corporation declares that the radio equipment type "1MORE ColorBuds 2" is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: www.1more.com RF exposure information: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction. Radiation Exposure Statement Power is so low that no RF exposure calculation is needed. Declaration for EU Compliance Operation Frequency/Max. EIRP: 2400-2483.5MHz, Left ear Max. EIRP is 12dBm, Right ear Max. EIRP is 12dBm.																
EN Warning Replacement of a battery with an incorrect type that can defeat a safeguard (such as catching fire, explosion, leakage of corrosive electrolyte etc); Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion; Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas; and A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas. ⚡ The symbol indicates DC voltage.  RECYCLING This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE). This means that this product must be handled pursuant to European directive 2014/53/EU in order to be recycled or dismantled to minimize its impact on the environment. User has the choice to give his product to a competent recycling organization or to the retailer when he buys a new electrical or electronic equipment.  To prevent possible hearing damage, do not listen at high volume levels for long periods.	EN FCC The SAR limit of USA (FCC) is 1.6 W/kg for head averaged over one gram of tissue. Device types ES602 (FCC ID: 2ASDIES602L (Left ear) , 2ASDIES602R (Right ear)) has also been tested with 0mm against this SAR limit. NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or changesto this equipment. Such modifications or changes could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: - Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver. - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. - Consult the dealer or an experienced radio/TV technician for help. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference. (2) This device must accept any interference received, including interference that may cause undesired operation.																
EN Supplier's Declaration of Conformity 47 CFR § 2.1077 Compliance Information Unique Identifier: Trade Name: 1MORE Model No.: ES602 Responsible Party – U.S. Contact Information 1MORE USA, Inc. Address: 10225 Barnes Canyon Road, Suite A202, San Diego, California, 92121 Tel: 1-855-551-6673 E-Mail: support@1moreusa.com IC regulatory conformance This device complies with CAN ICES-003 (B)/NMB-003(B) and CAN RSS-216 / CNR-216 . This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference. (2) This device must accept any interference, including interference that may cause undesired operation of the device. Cet appareil est conforme à la norme ICES-003 (B)/NMB-003 (B) et au CAN RSS-216 / CNR-216 . Cet appareil contient des émetteurs / récepteurs exempt (s) de la licence qui sont conformes aux RSS exemptes de l'Innovation, Sciences et Développement économique Canada. Son fonctionnement est soumis aux deux conditions suivantes: (1) Cet appareil ne doit pas provoquer d'interférences. (2) Cet appareil doit accepter toute interférence, y compris les interférences susceptibles de provoquer un fonctionnement indésirable de l'appareil. The SAR limit of Canada (ICES) is 1.6 W/kg for head averaged over one gram of tissue. Device types ES602 (IC: 24662-ES602L (Left ear) , 24662-ES602R (Right ear)) has also been tested with 0mm against this SAR limit. * Do not put the battery in trash that is disposed of in landfills. When disposing of the battery, comply with local laws or regulations.	EN Model: ES602 Headphone Weight (Single): 4.9 g Case Weight: 34.5 g Product Weight: 44.3 g Headphone Size: 27 × 21 × 20 mm Case Size: 60 × 30 × 38 mm Headphone Battery Capacity (Single): 55 mAh Case Battery Capacity: 410 mAh Headphone Charging Time: 70 mins Case Charging Time (with cable): 85 mins Fully Charged Playtime (ANC On) Headphone: 6 hours Headphones + Case: 18 hours Fully Charged Playtime (ANC Off) Headphone: 8 hours Headphones + Case: 24 hours Impedance: 32 Ω Wireless Range: 10 m Bluetooth: Bluetooth® 5.2 Bluetooth Protocol: HFP / A2DP / AVRCP Input: 5V = 1A Working Temperature: 0 °C ~ 45 °C Frequency Band: 2.400 GHz ~ 2.4835 GHz The specifications are acquired from laboratory tested data. * The playback time, tested under the laboratory condition of AAC format and 50% volume, may vary with different device setting, environments, usage and other factors. Manufacturer: TiniLab Corporation Add: No. 3333, Liuxian Avenue, Tower A, 35th Floor, Tanglang City, Nanshan District, Shenzhen, China Product information can be found at www.1more.com																

