



EarFun Wave
Wireless Headphones
User Manual



FCC ID: 2ASK7-HP100

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

CAUTION

Danger of explosion if battery is incorrectly replaced.

Replace only with the same or equivalent type.

the battery shall not be exposed to excessive heat such as sunshine, fire or the like



The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Shenzhen Earfun Technology Co., Ltd. is under license.

Other trademarks and trade names are those of their respective owners.

EarFun Wave


Wireless Headphones
User Manual

1 What's in the Box

EarFun Wave



Travel Case



x1

Charging Cable



x1

Audio Cable



x1

User Manual





x1

EarFun Wave





Wireless Headphones
User Manual

2 Buttons and LEDs



MIC

3 Connections




You can check the headphone battery level on the phone that is paired with.

EarFun Wave

Wireless Headphones
User Manual


4 Bluetooth® Connection

Step 1: Press and hold the MFB button for 2s to power on the headphone. It will automatically enter pairing mode (flash blue and red).



Step 2: Activate Bluetooth on your Bluetooth-enabled device and search for other Bluetooth devices.

Step 3: Select "EarFun Wave" from the list of Bluetooth devices shown (if a password is needed, type '0000').



Notes:


- In power-off mode, you can press and hold the MFB button for 5s to enter pairing mode to connect a new Bluetooth device.
- The headphones will automatically connect with the device they were last paired with when powered on.

EarFun Wave


Wireless Headphones
User Manual

5 Functions


Power On/Off




Playing Music



Hands-Free Call



Voice Assistant




EarFun Wave

Wireless Headphones
User Manual

6 Reset and Reconnect

If the headphones become disconnected or have another problem, you can reset to resolve. Ensure headphones are powered on. Press and hold the "MFB" and "Volume -" button for 5s at least to reset. After that, power on the headphone to reconnect. You need to delete the old connection from the Bluetooth device and reconnect "EarFun Wave".



Specifications

Bluetooth Version: V5.0

Support: A2DP, AVRCP, HFP, HSP

Driver size: 40mm

Battery type: 680mAh/3.7V

Music play time: Up to 40 hours (varies by volume level and audio content)

Charging Time: About 2 hours

Input: DC5V / 1A

Weight: 265g

Customer Service

18-month limited warranty

For FAQs and more information, please email to: support@myearfun.com

www.myearfun.com



Facebook