

105克双铜/骑马钉
73*54mm
按英-日-德顺序排版

EN FAD B10 User Manual Manual thoroughly before operating your device. In order to avoid unnecessary injuries, please do not disassemble this product by yourself. Please use a standard charger.	EN1 – 15 JP16–31 DE32–47	Product Overview Power Button / Indicator Light MIC Charging Case Indicator Light Charging Contact Pin Ear Cap 1	1 Charge the earbuds with the case. 2 Make sure that the earbuds are fully inserted into the charging case and the contacts are in contact. 3 When the earbuds are fully inserted, the charging case will light up. 4 When the earbuds are fully inserted, the charging case will light up. 2	First time using 1 Take out the earbuds from the charging case. 2 Put the earbuds back into the charging case before taking it out for use. 3
---	---	--	--	---

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.