

10" OVERHEAD MEDIA PLAYER

©2019 FCA US LLC. All Rights Reserved.

Mopar® is a registered trademark of FCA US LLC.

Bluetooth® is a registered trademark of Bluetooth
SIG, Inc.

FCC COMPLIANCE STATEMENT:

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications to this unit not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement

This equipment complied with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.




Mopar® OVERHEAD DVD PLAYER

IMPORTANT CUSTOMER INFORMATION

– **DO NOT DISCARD**

DVD-2500 RU



QUICK START GUIDE

10" Overhead Media Player

IMPORTANT NOTES

Listen to audio through the vehicle's speakers by switching to the auxiliary mode on your radio.



For headphones use, turn set on and use with the overhead DVD player.



All functionality of the Overhead DVD Player must be done through the overhead unit itself or remote control.



Overhead DVD player operates while vehicle is in ACCY or RUN mode.



Your Mopar® Overhead DVD Player is designed to give your family years of enjoyment.

- Play your favorite CDs or DVDs.
- Plug and play a variety of devices through the multiple input ports.
- Listen to audio through the vehicle's speakers and/or with the wireless headphones.

Please review the accompanying Owner's Manual to become familiar with all features and operation.

STANDARD OPERATION

Press the POWER button on the overhead DVD player or on the remote.

To play a DVD/CD

- Gently insert disc with label side facing up into the overhead DVD player.

To display content through the Overhead DVD Player HDMI port

- Connect an HDMI cable to a compatible video/audio device.
- Some devices will also need an MHL (Media High-Definition Link) cable or genuine Apple® adapter.

To display content through the USB port or RCA jack

- Plug in your device.
- Refer to the overhead DVD player owner's manual for supported file formats.

To eject a DVD/CD

- Press the eject button on the overhead DVD player to open the disc loader.

For any questions or issues with your Mopar® Overhead DVD Player, please contact your local dealer for assistance

WIRELESS REMOTE

SR-BT20T



FCC COMPLIANCE STATEMENT:

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications to this unit not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement


The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction.

Before using the remote it must be paired to the DVD player.


REMOTE PAIRING PROCEDURE

When using for the first time, the remote requires two AAA batteries for operation.


- ① Press the "SETUP" and "REPEAT" buttons together.



- ② The LED indicator will flash blue and red.



- ③ Press the "DIMMER" and "EXIT" buttons together on DVD player.



- ④ Once the pairing is finished successfully, the LED indicator will light blue for about 3 seconds.

WIRELESS NOISE CANCELING STEREO HEADSET

SM-H50BT



FCC COMPLIANCE STATEMENT:

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications to this unit not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement


The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.

CHARGE THE HEADPHONES

When using for the first time, fully charge the battery.
For full charging, it takes about 4 hours.
The Bluetooth[®] wireless is disconnected during charging.

- ① Plug the USB cable into the micro-USB connector on the right.
- ② Plug the other end into a USB wall charger or computer that is powered on.



While charging, the LED indicator lights up red for every 5 seconds

When the battery charged fully, the LED indicator lights up blue.

The included USB charging cable is only designed to charge and data cannot be transferred to and from a computer.


POWER ON AND OFF

To power on

- ① Press and hold the POWER button for about 2 seconds while this unit is turned off.
- ② Make sure that the indicator flashes blue after the device powered on.


To power off

- ① Press and hold the POWER button for about 2 seconds while this unit is turned off.
- ② Make sure that the indicator is turned off after the device powered off.




BLUETOOTH PAIRING PROCEDURE


- ① Press and hold the POWER button on the left for about 7 seconds.
- ② The LED indicator beside the POWER button will flash blue and red alternately.



- ③ Press the MENU button on the remote control



- ④ On the "Audio" menu, select the "Bluetooth" menu.
- ⑤ In the "Bluetooth" menu, select "Available Devices".
- ⑥ It will show your headphones on the device list.
- ⑦ Select your headphones from the device list.



- ⑧ The LED indicator will flash blue once the pairing success.

TROUBLESHOOTING

If you encounter a problem, please turn the power off, then on again. If the unit is still not functioning normally, please review the items in the following checklist.

DVD Player

Symptom	Solution
DVD don't power on	• Check the ACC is on
DVD disc doesn't play	• Check the disc and load it with the labeled side upward • Re-insert the disc • Clean up the disc • Change the disc if the disc has damaged
No sound	• Increase the volume of the head unit • Check the DVD player whether it is playing or not

Remote Control

Symptom	Solution
Remote doesn't work	• Change new battery
Unable to pair or connect	• Use the remote within 3m from the DVD player • Check the DVD player whether it is power on • Try to pair again with the DVD player

TROUBLESHOOTING

Bluetooth Headphones

Symptom	Solution
Headphones don't power on	• Charge the battery
Unable to pair or connect	• Use the headphones within 3m from the DVD player • Disconnect the USB charging cable • Check the DVD player whether it is power on • Connect another Bluetooth device (Smartphone) • Clear the pairing list and try to pair again
No sound	• Turn on the headphones and charge the battery • Increase the volume of the headphones • Check the DVD player whether it is playing or not • Connect another Bluetooth device (Smartphone)
Sound is interrupted or noise sound	• Try to connect another music device • Move the headphones closer to the DVD player • Increase or decrease the volume of the headphones
Battery won't charge	• Securely connect the USB charging cable • Change another charging source