

420mm

色值:

	C (%)	M (%)	Y (%)	K (%)
	0	0	0	95
	20	100	100	0
	0	10	85	0

材质:

80克书写纸

$$\ddot{N}$$

双面印刷/折叠

单页尺寸:

420×297mm(A3纸)

折叠要求:封面在上

封面(84mm)



标题: M200 英日德中性说明书-A3纸折叠

图例编号:

制图者		比例	1:1
时间		材料	
审批		大小	

专利及保密协议:

这份图版的所有信息,包括版权、设计及其他知识产权均属威海越印科技有限公司所有。此文件条款不赋予你使用及复制产品,或拥有产品所有权利。上述权利均属威海越印科技有限公司所有。未经威海越印科技有限公司书面同意,严禁在任何情况下复制、披露、转载产品信息。

[illegible][illegible]

20	100	1
0	10	8

材质：
80克书写纸

工艺：
双面印刷/折叠

单页尺寸：
420×297mm(A3纸)


折叠要求：封面在上

封面 (84mm)

M200 Instruction

	
2) 图样	
① 图样应清晰、完整、准确地表达设计意图，并符合 GB/T 14689 的要求。 ② 图样应采用国家标准的制图方法，并符合 GB/T 14689 的要求。 ③ 图样应采用国家标准的制图方法，并符合 GB/T 14689 的要求。	
标题: M200 英日德中性说明	
图纸编号:	
制图者	比例
时间	材料
审批	大小
专利及保密协议:	
这份图纸的所有信息, 包括版权、设计及其他知识产权, 均归本公司所有, 未经本公司书面许可, 不得复制或传播。	

M200 Instruction




- Please read this instruction carefully before using this product and keep it properly.
- 本製品を使用する前に説明書もしっかりお読みください。
- Bitte lesen Sie dieses Handbuch sorgfältig durch, bevor Sie dieses Produkt verwenden.
- Veuillez lire attentivement ce manuel avant d'utiliser ce produit et le conserver correctement.
- Si prega di leggere attentamente questo manuale prima di utilizzare questo prodotto e conservarlo correttamente.
- Por favor, lea cuidadosamente este manual antes de usar este producto y guárdelo adecuadamente.



- Multilingual detailed instruction manual
- 多言語詳細説明マニュアル
- ボタンをフリックして言語を選択し、●ボタンをフリックして言語を切り替えます。
- Klicken Sie auf die Taste ●, um eine Sprache auszuwählen, klicken Sie auf die Taste ●, um die Sprache zu wechseln.
- Cliquez sur le bouton ● pour sélectionner la langue, puis sur le bouton ● pour changer la langue.
- Pire clic sul pulsante ●, selezionare la lingua, fare clic sul pulsante ●, cambiare la lingua.
- Haga clic en el botón ● para seleccionar el idioma, haga clic en el botón ● para cambiar el idioma.

Language switching | 言語の切り替え | Sprachwechsel | Chngement de langue | Cambio di lingua | Cambio de idioma

- Click the ● button to select the language and click the ● button to switch the language.
- ボタンをフリックして言語を選択し、●ボタンをフリックして言語を切り替えます。
- Klicken Sie auf die Taste ●, um eine Sprache auszuwählen, klicken Sie auf die Taste ●, um die Sprache zu wechseln.
- Cliquez sur le bouton ● pour sélectionner la langue, puis sur le bouton ● pour changer la langue.
- Pire clic sul pulsante ●, selezionare la lingua, fare clic sul pulsante ●, cambiare la lingua.
- Haga clic en el botón ● para seleccionar el idioma, haga clic en el botón ● para cambiar el idioma.



Contains three languages: English, Japanese, German

English

01. Item Checklist


- Printer x1
- Instruction Manual x1
- USB Cable x1
- Paper Width Guide Disk (in the printer) x1

The number of paper rolls in the list is subject to the actual shipment.

02. Product Specifications

Name	Multifunctional Portable label Maker
Model	M200
Technology	Thermal Printing
Width of label	20-75mm
Supported Consumables	Black mark thermal Label, Pre-cut Label, Continuous Label
Consumable specifications	80mm x ϕ50mm (Max width + Max diameter)
Printing speed	30-50mm/s
Darkness	1-15 levels
Resolution	203dpi
Pinthead Lifespan	500K
Communication Port	Bluetooth / Data wire
Product Dimensions	120*117*60mm (4.92*4.58*2.3in)
Power Input	5V = 2A
Power Supply	Data wire / Lithium battery
OS Supported	Android / iOS
Command set	ESC / PDS
Barcode	1D barcode and QR code are supported
Working environment	5℃~50℃
Storage environment	-20℃~60℃
Working humidity	20%~85%
Storage humidity	20%~95% (Not frozen)

03. Product Introduction - Parts and Features



Button functions

Diagram	Button	Instruction	Function
	Power Button	Long press 3s Press once	Switch on/off Switch between the main menu pages, Eject one label and reposition the label paper to the head of the next label.
	Eject Button	Long press (for Continuous paper) Hold for 3 seconds	Hold to eject paper. Release to stop. Return to the main menu.
		Continuous click	1. After switching to the desired main menu page using the Power Button, press Eject Button to go through the sub-menu. 2. Press once to eject one sheet of paper when the printer is in standby mode.

04. Parts Description

Main Menu - Settings

Options	Parameters (Contents)
Language	Chinese, English
Ink Intensity	1(weakest), 2, 3, 4(weak), 5, 6 (Normal), 7, 8, 9, 10 (Dark), 11, 12, 13, 14, 15 (Darkest)
Print speed	1 (Slowest), 2 (Slow), 3 (Normal), 4 (Fast), 5 (Fastest)
Paper Type	Non-continuous paper, Continuous paper, Black mark thermal paper
Automatic Shutdown	15 minutes, 15 minutes, 30 minutes, 1 hour, 2 hours, 4 hours, 8 hours, 24 hours, Stay on (Default)
Factory Reset	Restore to default factory configuration
Firmware version	Show firmware version
Device address	Show device address

05. Paper Roll Installation

- Slide down the Open-Cover Button to open the paper compartment cover.
- Take out the paper holder inside the compartment.
- Remove the left disk and insert the label roll (with the printing side facing down). Insert the left disk and push it to the right.
- After the label holder is complete, insert the holder into the paper compartment.
- Pull out around 15 mm of paper and close the paper compartment cover.
- Press the Eject Button once to detect and reposition the label paper.
- Hold the Power Button for 3 seconds.
- The label paper is repositioned once it comes out.

On your first use or after you have replaced the label paper, the printer automatically ejects paper to reposition the label paper. This helps avoid printing errors (incomplete print, non-centered content, etc.).

06. App Download Method

- NOTE
- You need to connect the printer through the Print Master app.
- Android phones must enable GPS (Location Services) before using Bluetooth.

Method I:

Use your phone to scan the QR code to install the App.



- Google Play
- App Store
- Print Master

07. Connecting the Printer

- Turn on GPS (Location Services) (Android phones only)
- Open Print Master
- Tap the **Connect Now** button to search for your device.
- Press "Start using"

NOTE

- This product needs to be connected to the printer in the App after the Bluetooth is turned on.
- According to the official requirements of Google, Android mobile phones need to open the GPS permission before they can use the Bluetooth function.
- When connecting the App, please make sure that the printer is turned on and the Bluetooth of the mobile phone is turned on.

08. Identifying the Label Size

The App is required to set the label size or template before printing. Please follow the instructions to download it.


Method I:

Check your label package.



Method II:

Measure with a ruler.



09. FCC Caution

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
- Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not used and properly shielded, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the distance between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
- *RF warning for Portable device:
- The device has been evaluated to meet general RF exposure requirement.
- The device can be used in portable exposure condition without restriction.

10. IC Caution

- Radio Standards Specification RSS-Gen, Issue 5- English:
- This device contains a license-exempt radio transmitter (y receiver) that comply with Industry Canada's RSS-247, Class 2, license-exempt RSS (2) requirements.
- (9) Operation is subject to the following two conditions:
- This device may not cause interference.
- This device must accept any interference, including interference that may cause undesired operation of the device.

RF exposure statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

-French-

Cet appareil contient des émetteurs / récepteurs exempts de licence conformes aux RSS (RSS) d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes:

Cet appareil ne doit pas causer d'interférences.

Il est interdit d'utiliser cet appareil dans des endroits où il est susceptible de provoquer un fonctionnement indésirable de l'appareil.

L'appareil a été évalué pour répondre aux exigences générales d'exposition aux RF. L'appareil peut être utilisé dans des conditions d'exposition portable sans restriction.


日本語

01. パッケージ内容

- プリンター x 1台
- 説明書 x 1冊
- USBケーブル x 1本
- 段巻用紙 (パール仕様) x 1巻

※ 商品箱に食まれるローラー紙の数は実物と異なる場合があります。

02. 製品外観紹介



ボタン紹介

アイコン	ボタン名称	操作方法	機能
	電源ボタン	3秒長押し 1回押す	電源オン/オフ メインメニューに切り替え
	用紙送りボタン	1回押す データケーブルは接続して次のステップに進む	ケーブルを接続して用紙を送り出し、用紙送りボタンを押すとメインメニューに切り替える
	印刷ボタン	長押し (連続印刷の場合)、離すと停止	ボタンを長押しして用紙送りをを行い、離すと停止
		3秒長押し	メインメニューに戻る
		1回押す	1. 電源ボタンでメインメニューに切り替えした後、用紙送りボタンを押すとサブメニューに切り替える 2. スリープ中に1回押すと用紙を1枚送る

03. 部品について

ディスプレイ設定メインメニュー

オプション	パラメーター (内容)
言語	中国語、英語
印刷濃度	1(最も薄い) 2, 3, 4(薄い) 5, 6(標準) 7, 8, 9, 10(濃い) 11, 12, 13, 14, 15(最も濃い)
印刷速度	1(最も遅い) 2(遅い) 3(標準) 4(速い) 5(最速)
用紙の種類	データケーブル、連続紙、アイマーク付き用紙
自動電源オフ	5分、15分、30分、1時間、2時間、4時間、8時間、24時間、工場出荷時の状態に設定
初期化する	工場出荷時の状態に戻す
ファームウェアバージョン	ファームウェアのバージョンを表示する
IPアドレス	IPアドレスを表示する

