




# D30 Instruction Manual

Contains three languages: English, Japanese, German



Please read the instructional manual carefully before using the product.

## English



Please scan the QR code to obtain the multilingual comprehensive version of the instruction manual and more. [Tutorial.](#)

### 01. Item Checklist

|  |                      |
|--|----------------------|
|  | Label Maker*1        |
|  | Instruction Manual*1 |
|  | USB Cable*1          |

\* The number of label rolls on the checklist is determined by the contents of the shipped package.

### 02. Specifications


|                       |                                                           |
|-----------------------|-----------------------------------------------------------|
| Name                  | Smart Mini Label Maker                                    |
| Model                 | D30                                                       |
| Technology            | Thermal printing                                          |
| Consumable width      | 12.5mm                                                    |
| Supported Consumables | Black mark thermal Label, Pre-cut Label, Continuous Label |
| Darkness              | Light, Medium, High                                       |
| Resolution            | 203 dpi                                                   |
| Printhead Lifespan    | 50 KM                                                     |
| Communication Port    | Bluetooth                                                 |
| Product Dimensions    | 131.5*75.5*29 mm (5.2*2.9*1.2 inch)                       |
| Power Input           | 5V=2A                                                     |
| Power Supply          | Lithium Battery                                           |
|                       | Micro USB                                                 |
| OS supported          | Android                                                   |
|                       | iOS                                                       |

### 03. Product Introduction Parts and Features

|                                           |             |              |           |                   |              |                 |               |              |
|-------------------------------------------|-------------|--------------|-----------|-------------------|--------------|-----------------|---------------|--------------|
| 01 Label Maker display                    | Upper Cover | Paper Output | Printhead | Label Compartment | Power Button | Indicator Light | Charging Port | Lanyard Hole |
|                                           |             |              |           |                   |              |                 |               |              |
| Various labels are available for purchase |             |              |           |                   |              |                 |               |              |
| Non-continuous label                      |             |              |           |                   |              |                 |               |              |
| Continuous label                          |             |              |           |                   |              |                 |               |              |

### 03. Features of Continuous Labels


Tear away the base of the label easily with the easy-to-tear line



Gently bond the label along the easy-to-tear line to tear the base from the adhesive easily

### 03. Product Introduction Power and Indicator Light

| Button       | Operation          | Functions             |
|--------------|--------------------|-----------------------|
| Power button | Hold for 3 seconds | Power on/off          |
| Power button | Press once         | Output the label      |
| Power button | Press twice        | Print diagnostic page |



#### Indicator Light


| Indicator Light | Normal                                    |
|-----------------|-------------------------------------------|
|                 | Powered on & charging                     |
|                 | Powered off & charging                    |
|                 | Error (No Paper, Cover is open, Overheat) |
|                 | 10% Power left                            |
|                 | 5% Power left                             |
|                 |                                           |

### 04. How to Use

01 Open the label compartment.




02 Take out the label roll, tear the anti-loosening sticker.



03 Place the label roll into the label compartment with the printing side facing left.



04 Close the cover.



### 05. Downloading the App

After installing the label roll for the first time or replacing the label roll, remember to reposition the label (Step No. 07). If you do not reposition the label (Step No. 07), the first label you print may be cut off or misaligned (missing contents, not aligning to the center, etc.).

Continuous labels do not need repositioning. You only need to pull the label to the opening of the Label Maker.



You need to connect the Label Maker through the Print Master app. In compliance with Google's requirement, Android phones must enable GPS (Location Services) before using Bluetooth.


Method 1: Use your phone to scan the QR code to install the App.




Method 2: Search for "Print Master" in the app store on your phone to download the App.

### 06. Connecting the Label Maker


01 Turn on GPS (Location Services) (Android phones only).




02 Tap the "Connect now" button to search for your device.



03 Open Print Master.




04 Press "Start using".




In compliance with Google's requirement, Android phones must enable GPS (Location Services) before using Bluetooth. Before connecting to your phone's device in Print Master, please make sure your printer is turned on and your phone's Bluetooth is on.

### 07. Identifying the Label Size

Method 1: Check your label package.



Method 2: Measure with a ruler.



Method 3: Check the tag on your label roll. (Label rolls are being updated, so the actual product you receive may vary.)



### 08. FCC Caution

This device (Main device model: D30; Series model: CP-D30, OY-D30, D30A, D30 Pro, D31, D30C, D30E, D30F) complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
  - Increase the separation between the equipment and receiver.
  - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
  - Consult the dealer or an experienced radio/TV technician for help.
  - \*RF warning for Portable device:
- The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

### 09.ISED NOTICE (Canada)

CAN ICES-003(B)/NMB-003(B)

This device contains license-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS (s).  
Cet appareil contient un émetteur (s) /récepteur (s) qui sont conformes à la licence d'innovation, Science et Développement économique Canada.

Operation is subject to the following two conditions:  
1. This device must accept any interference, including interference that may cause undesired operation of the device.  
2. This device must not cause interference.  
This equipment complies with ISED radiation exposure limits set forth for an uncontrolled environment and meets RSS-102 of the ISED radio frequency (RF) IC RF exposure statement:  
The device has been evaluated to meet general IC RF exposure requirement. The device can be used in portable exposure condition without restriction.

Cet appareil contient un émetteur (s) /récepteur (s) qui sont conformes à la licence d'innovation, Science et Développement économique Canada.  
Le fonctionnement n'est soumis qu'à deux conditions suivantes:  
1. Cet appareil ne peut pas causer d'interférences.  
2. Cet appareil doit accepter toute interférence, y compris les interférences qui pourraient causer un fonctionnement indésirable de l'appareil.

Cet équipement est conforme aux limites d'exposition aux rayonnements électromagnétiques prévues pour un environnement non contrôlé et répond à l'exigence RSS-102 des règles d'exposition aux RF.

L'appareil a été évalué pour répondre aux exigences générales d'exposition aux RF d'IC. L'appareil peut être utilisé dans des conditions d'exposition portable sans restriction.

## 日本語

本製品使用前には必ず本説明書をお読みください




QRコードをスキャンすれば、更に詳しい操作方法が書かれた多言語詳細版説明書をご覧いただけます。

### 01. パッケージ内容

|                                |            |
|--------------------------------|------------|
|                                | プリンター*1台   |
|                                | USBケーブル*1本 |
|                                | 増巻用*1冊     |
| ・同梱品に含まれるロール紙の数は実物と異なる場合があります。 |            |

### 02. 機器について 外部パーツ


#### 01 プリンター本体の見た



#### 02 ラベル紙の見た



#### 03 連続紙の見た



ミシン目に沿ってラベル紙を切り曲げることによってラベルがハク/剥がれやすくなる。

### 02. 機器について 電源と状態表示ランプ

電源がタカについて


| ボタン | 操作    | 機能          |
|-----|-------|-------------|
|     | 3秒長押し | 電源オン/オフ     |
|     | 短く押す  | 排紙する        |
|     | 2回押す  | テストページをプリント |

状態表示ランプについて

| 緑点灯 | 正常                           |
|-----|------------------------------|
|     | 電源オンで充電                      |
|     | 電源オフで充電                      |
|     | エラー (用紙切れ、カバーが開いている、温度が高すぎる) |
|     | 赤点灯                          |
|     | 充電残量10%                      |
|     | 充電残量5%                       |

### 03. 使用方法について


01 排紙トレイを開けてください



02 プリントが正常に行われるようにラベル紙を5mm程度引出してください




03 カバーを開いてください




方法1 ラベル紙のバネージを確認  
(図3)ラベル紙は二重目のラベル紙です  
異なる場合があるため、確認する必要があります




04 アプリのダウンロード




05 カバーを閉めてください



Method 1: 確認してください  
Method 2: 確認してください




06 ラベル紙の位置を確認



07 ラベル紙の位置を確認




08 ラベル紙の位置を確認




09 ラベル紙の位置を確認



01 ラベル紙の位置を確認



02 ラベル紙の位置を確認




03 ラベル紙の位置を確認




04 ラベル紙の位置を確認



05 ラベル紙の位置を確認




06 ラベル紙の位置を確認



07 ラベル紙の位置を確認



08 ラベル紙の位置を確認




09 ラベル紙の位置を確認



10 ラベル紙の位置を確認



11 ラベル紙の位置を確認



12 ラベル紙の位置を確認



13 ラベル紙の位置を確認



14 ラベル紙の位置を確認



15 ラベル紙の位置を確認



16 ラベル紙の位置を確認




17 ラベル紙の位置を確認



18 ラベル紙の位置を確認



19 ラベル紙の位置を確認



20 ラベル紙の位置を確認




21 ラベル紙の位置を確認




22 ラベル紙の位置を確認



23 ラベル紙の位置を確認



24 ラベル紙の位置を確認



25 ラベル紙の位置を確認



26 ラベル紙の位置を確認




27 ラベル紙の位置を確認




28 ラベル紙の位置を確認




01 ラベル紙の位置を確認




02 ラベル紙の位置を確認



03 ラベル紙の位置を確認




04 ラベル紙の位置を確認



05 ラベル紙の位置を確認




06 ラベル紙の位置を確認




07 ラベル紙の位置を確認



08 ラベル紙の位置を確認



09 ラベル紙の位置を確認



10 ラベル紙の位置を確認




11 ラベル紙の位置を確認



12 ラベル紙の位置を確認




13 ラベル紙の位置を確認



14 ラベル紙の位置を確認



15 ラベル紙の位置を確認




16 ラベル紙の位置を確認



17 ラベル紙の位置を確認




18 ラベル紙の位置を確認



19 ラベル紙の位置を確認



20 ラベル紙の位置を確認



21 ラベル紙の位置を確認



22 ラベル紙の位置を確認



23 ラベル紙の位置を確認




24 ラベル紙の位置を確認



25 ラベル紙の位置を確認




26 ラベル紙の位置を確認



27 ラベル紙の位置を確認




28 ラベル紙の位置を確認




29 ラベル紙の位置を確認



30 ラベル紙の位置を確認



31 ラベル紙の位置を確認



32 ラベル紙の位置を確認



33 ラベル紙の位置を確認



34 ラベル紙の位置を確認



35 ラベル紙の位置を確認

