

# SAFETY GUIDE

Label Printer

## D422S



## 01 Pro Tips

- **Each time you change the label**, please run the automatic label identification.
- Press the feed button on the printer to **skip a blank label**.
- Double click the feed button.
- **Avoid poor quality labels** as they can damage the printer.
- Regularly **clean the print head**.
- **If the paper is jammed and the blue light is flashing slowly**, run the automatic label identification.
- Insert Label Printer into the **same USB port** on your computer every time. This will avoid creating duplicate copies of the printer in your operating system.

## 02 FAQ

**Please visit our official website to check FAQ file.**

## **06** Safety Notices

- The print head may be very hot after printing labels. Do not touch the print head.
- Do not bend the power cord excessively or place objects on the cord.
- Do not use the printer if you find any irregularities as these could result in fire or electric shock.
- Keep the printer out of reach of children.
- Use only approved accessories and do not try to disassemble, repair the unit by yourself.
- Keep the printer away from water and other objects that could penetrate the components.
- Please unplug the printer when it is not in use for a long time.

**English** **ISED Warning statement:**

This device contains licence-exempt transmitter(s)/ receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- 1.This device may not cause interference.
- 2.This device must accept any interference, including interference that may cause undesired operation of the device.

**French** **Déclaration d'avertissement ISED:**

L' émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d' Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence.

L' exploitation est autorisée aux deux conditions suivantes:

- 1.L' appareil ne doit pas produire de brouillage;
- 2.L' appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d' en compromettre le fonctionnement.

**English****ISED RF exposure statement:**

This equipment complies with ISED Radiation exposure limit set forth for uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the product and your body.

**French****ISED RF Déclaration de exposition:**

L'équipement est conforme à la limite d'exposition aux radiations de la ISED établie pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec une distance minimale de 20 cm entre le radiateur et votre corps.

## **07** **FCC Warning**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

**FCC RF exposure statement:**

The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum 20cm distance between the radiator and your body.

## **01** Hinweise für Vorbereitung

- Jedes Mal, wenn Sie das Etikett wechseln, lassen Sie bitte die automatische Etikettenerkennung laufen.
- Drücken Sie die Einzugstaste am Drucker, um ein leeres Etikett zu überspringen.
- klicken Sie zweimal auf die Vorschubtaste.
- Bitte vermeiden Sie, unqualifizierte Etiketten zu verwenden, die den Drucker beschädigen können.
- Reinigen Sie den Druckkopf regelmäßig.
- Wenn das Papier gestaut ist und das blaue Licht langsam blinkt, führen Sie die automatische Etikettenerkennung durch.
- Schließen Sie den Drucker immer an demselben USB-Anschluss Ihres Computers an, um zu vermeiden, dass der Drucker doppelte Kopien erstellt.

## **02** FAQ

**Besuchen Sie bitte unsere offizielle Website, um die FAQ-Datei zu lesen.**

## 05 Spezifikationen

|                          |                                                                                |
|--------------------------|--------------------------------------------------------------------------------|
| Methode                  | Direct Thermal                                                                 |
| Auflösung                | 203 dpi                                                                        |
| Max Druckgeschwindigkeit | 150 mm/s                                                                       |
| Papierbreite             | 20-115mm                                                                       |
| Papierdicke              | 0.06-0.19mm                                                                    |
| Spannungsadapter         | 24V $\rightleftharpoons$ 2.5A                                                  |
| Lebensdauer              | TPH 50KM                                                                       |
| Betriebsumgebung         | Temperatur: 5 bis 40 °C<br>Luftfeuchtigkeit: 25-85%<br>(nicht kondensierend)   |
| Speicherumgebung         | Temperatur: -40 bis 60 °C<br>Luftfeuchtigkeit: 10-90%<br>(nicht kondensierend) |

## **06**   **Sicherheitshinweise**

- Berühren Sie den Druckkopf nicht. Nach dem Drucken kann der Druckkopf erhitzt werden.
- Bitte vermeiden Sie, das Netzkabel zu biegen oder Gegenstände auf dem Kabel zu legen.
- Verwenden Sie den Drucker nicht, wenn Sie Unregelmäßigkeiten bemerken, die zu Bränden oder Stromschlägen führen können.
- Halten Sie den Drucker außerhalb der Reichweite von Kindern.
- Verwenden Sie nur zugelassenes Zubehör. Versuchen Sie nicht, der Drucker selbst zu zerlegen oder zu reparieren.
- Halten Sie den Drucker von Wasser und anderen.
- Ziehen Sie den Netzstecker aus der Steckdose, wenn der Drucker längere Zeit nicht benutzt wird.

## 07 Garantiekarte

☐ Zurückgeben

☐ Umtauschen

☐ Reparieren

|                                              |                             |                      |          |
|----------------------------------------------|-----------------------------|----------------------|----------|
| Benutzerinfo                                 | Name:                       | Geschlecht:          | Telefon: |
|                                              | Adresse:                    |                      |          |
| Info zum Produkt                             | Kaufdatum:                  |                      |          |
|                                              | Bestellnummer des Produkts: |                      |          |
|                                              | Seriennummer des Produkts:  |                      |          |
| Anforderungen an Rückgabe /Ersatz /Reparatur | Beschreibung des Grundes:   |                      |          |
| Aufzeichnungen zur Wartung                   | Störungsbedingung:          | Wartungsperson:      |          |
|                                              | Handhabungssituation:       | Lieferdatum:         |          |
|                                              | Wartungsscheinnummer:       | Datum der Lieferung: |          |