


Quick Start Guide

M08D
Portable printer



HVIN: M08D
English

1. Product Introduction

1.1 Packing List

Printer X1, Quick Start Guide X1, Type-C Cable X1, Velvet Pouch X1, USB to Type-C Adapter X1, Single-sided Thermal Paper- 10 sheets X1

1.2 Printer Parts Instruction

Reset Hole, Type-C Charger Port, Power Button, Indicator Light, Cover Open Buttons X2, Top Cover, Paper Output Slot, Display, Paper Entry Slot

2. Getting Started

2.1 Downloading the App

Method 1: Search for the "Phomemo" app on App Store or Google Play for download and installation. Method 2: Scan the QR code to download the app.

2.2 Paper Installation Guide

01 Long press the Power Button for 3 seconds until the Indicator Light is green to power up the printer. 02 Simultaneously press the Cover Open Buttons with both hands. 03 Open the Top Cover. 04 Remove the protective paper. 05 Put the Top Cover back down, and press down on both of its ends at the same time until you hear a click, indicating the cover is securely closed. 06 Insert the paper with the text side up into the Paper Entry Slot until the printer automatically pulls it in and the Indicator Light is lit green, signaling paper insertion is complete.

07 Edit your first image before clicking [Print]. 08 Confirm the preview of the image, and tap [Print]. 09 Printing is completed. The software interface is for reference only. Please refer to the actual operating page for accurate information.

2.3 User Guide: Printing via Mobile App

01 Open the "Phomemo" app. 02 Grant permissions. 03 Wait for the printer to be searched. 04 Tap [Connect Now]. 05 Connection successful. Please click [Print Image]. 06 Select the image to be printed.

3. Cleaning and Maintenance

01 Disconnect the printer from the power supply before starting any cleaning or maintenance. If you encounter issues such as blank lines, blurry print, or missing words, it may be caused by dirt on the Print Head. Please follow these steps: 01 If you have just finished printing, wait for at least 30 minutes for the Print Head to cool down completely. 02 Use a cotton swab dipped in alcohol or a dry alcohol-soaked cotton ball to gently wipe the Rubber Roller and the Print Head left and right 5 times each, removing dust and stains from the surfaces. 03 Wait 5-10 minutes for the alcohol to evaporate completely before closing the Top Cover and completing the cleaning process. You may now continue using the printer.

4. Charging Instructions

1. Please prepare your own power adapter (DC 5V/2A) with a Type-A port. 2. Insert the Type-C end (flat end) of the USB cable into M08D's Type-C Charger Port and plug the Type-A end (wide end) into the Type-A port of the power adapter. 3. After completing the connection and plugging into the socket, please check the status of the printer indicator lights. In the charging state, the indicator light will flash green. 4. To ensure quick usage, please charge the printer for at least 20 minutes. For a complete charge, wait for 4 hours or until the Indicator Light is solid green. 5. As the printer may heat up during charging, avoid placing it on materials such as cotton or linen. 6. Once the battery is fully charged, please unplug the charger promptly.

01 Avoid using the printer while charging.Using the printer while charging may lead to reduced charging speed, compromised print quality, and shortened battery life. 02 The printed content will not appear on the side that reads "non-printing side."

5. Additional Instructions

5.1 Button Instructions

Table with 3 columns: Button Type, Operation, Function. Rows include Power Button (Long press for 3s: Power on/off; Double press when printer is on: Print a self-test page).

5.2 Indicator Light Instructions

Table with 3 columns: Status, Meaning, Advised Action. Rows include Solid Green Light (Functioning/Fully charged), Flashing Green Light (Charging), Slow flashing red light (Low battery), Fast flashing red light (When the battery reaches critically low level, the printer will shut down soon), No light after long pressing Power Button for 3s (Battery depleted).

6. Accessing Detailed Online Guide

Visit m08d.phomemo.com to access the Detailed Online Guide, video tutorials, and answers to FAQs.

7. Information to User

Caution: Operating this equipment in a residential area may cause radio interference.

8.1 FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense. The device has been evaluated to meet general RF exposure statement. The device can be used in portable exposure condition without restriction.

7.2 ISED NOTICE (Canada)

English: This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: 1) This device may not cause interference. 2) This device must accept any interference, including interference that may cause undesired operation of the device. RF exposure statement: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction. French: L' émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d' Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L' exploitation est autorisée aux deux conditions suivantes : 1) L' appareil ne doit pas produire de brouillage; 2) L' appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d' en compromettre le fonctionnement Déclaration d'exposition RF: L'appareil a été évalué pour répondre aux exigences générales d'exposition aux RF. L'appareil peut être utilisé dans des conditions d'exposition portable sans restriction.