





使用说明书

迷你自拍杆

产品介绍


•各部分说明



打开四脚架

•自动打开四脚架

按下解锁按钮，四脚架自动打开。



连接遥控器

•初次连接

长按开启遥控器，指示灯蓝灯闪烁进入配对状态



手机搜索“Selfie”匹配，配对成功后,指示灯熄灭。

•自动关机

在开机状态下，无操作10分钟，自动关机；


•自动连接

开机可自动连接已配对手机；

•遥控器兼容

Android 4.4以上 iOS 5.1以上

按键使用说明



• 开关键

长按：开机/关机
单击：拍照/录制
双击：切换前置/后置摄像头


• 调焦键

单击：放大画面
长按：持续放大画面
单击：缩小画面
长按：持续缩小画面


* 调节无法超过设备最大/最小值
* 部分手机需要在系统设置中 打开“缩放”功能才可使用
* 如果前置摄像头不具备变焦功能，则遥控器无法调节变焦

遥控器

•可取出遥控器



•可安装在手柄上



手机夹使用


• 安装手机




•可滑动手机夹



关闭四脚架



调节自拍杆



规格

主要材料	ABS+铝合金
折叠长度	115.5mm
拉伸长度	410mm
产品尺寸	115.5x55.5x44.2mm
产品重量	124g
电池	CR1632(可更换)

⚠ 电池不得暴露在诸如日照、火烤或类似过热环境中

提醒


Android设备设置
如果你在相机选项下改变了你的“音量键功能”，请把它改为“默认”或者“拍照”让遥控器正常工作；

1. 使用本产品之前请仔细阅读说明书，并妥善保管说明书以便日后参考。
2. 此说明书上产品图仅供参考，请以实物为准。

ⓧ CE FC RoHS ♻

Introduce


•Part description



Open Quadrapod

•Automatic opening of quadrapod


Push the unlock button, and the quadrapod will open automatically.



Connect Your Phone

•First time connection

Long press to turn on the remote control, and the blue light of the indicator light flashes to enter the pairing state.



Search “Selfie” with your phone to match, after successful pairing, the indicator light will turn off.

•Automatic shutdown

The remote control will automatically power off after 10 minutes of inactivity.


•Automatic connection

Turning on the remote control automatically connects the paired phone.

•Remote control compatibility

Android 4.4 or above iOS 5.1 or above

Button Operations



• Power Button

Long press: Power on/off
Click: Take a photo/video
Double Click: Switch front/rear cameras

• Zoom Button

Click: Zoom in
Long press: Zoom in continuously
Click: Zoom out
Long press: Zoom out continuously


* The zoom adjustment cannot exceed the device's maximum or minimum limits.

* On some phones, the “Zoom” feature must be enabled in the system settings to use this function.


* If the front camera lacks zoom functionality, the zoom adjustment cannot be controlled via the remote.

Remote Control

•Take out the remote control




•Can be installed on the handle




Cell Phone Mount


• Mount the phone




• Sliding phone clip



Close Quadrapod



Adjust Selfie Stick



Specification

Main Material	ABS+Aluminum Alloy
Folded Length	115.5mm
Extended Length	410mm
Product Size	115.5x55.5x44.2mm
Product Weight	124g
Battery	CR1632(Replaceable)

⚠ The battery must not be exposed to sunlight, fire or similar overheating environments.

Remind **Android devices settings**
If you change your “volume key function” on the camera, be sure to change it to the “default value” or “Shooting”. Getting the remote control to work.

1. Please read the instructions carefully before using this product, and keep the instructions properly for future reference.
2. The product picture on this manual is for reference only, please refer to the actual product.

ⓧ CE FC RoHS ♻

材质：70g书纸 黑白印刷

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement in portable exposure condition without restriction.