

LC-B41

User Guide

1. Brief introduction


This product is a simple stylish business in-ear wireless earphone, with built-in CSR chipset, it brings you HD calls and music.

It is attention-needed that the Bluetooth connection may be interrupted by wall partition or other electronic interference or distance excess. Please read these instructions thoroughly before start using it, to make sure to use it in right and safe way and keep it in good condition.

2.Instructions

(1) Key Function :

1. Headset body
2. Volume key
3. Power switch
4. Call answer/end key
5. Rubber ear buds
6. Ear hook
7. Mic



1) Power ON/OFF——-Intelligent voice prompts reminds.

2) Volume key

Press and hold the volume + key to skip to next track; Press and hold the volume - key to skip to last track.

3) Call answer/end key

A. Press to answer or end calls; Double click to redial the last number you called.

B. Music play or pause. Press to pause music; Press again to play.

C. Press and hold 3S to enter into two phones pairing mode.

(2) Charge:

1) With a lithium-ion polymer battery built in, the headset needs about 3 hours to complete charging at the first time.

2) Red indicator displays that charging is going; Blue indicator displays that charge is completed.

3) Please stop using it when charging.

(3) Pairing:

1) First, turn on the Bluetooth facility in your device and let it enter pairing mode.

2) Connect the "LC-B41" in the searching list.

3) Two-device connection:

After connect successfully with device A, cut the connection between A and the headset for a while by closing the A' s Bluetooth. Then connect device B with the headset. After successful connection with device B, open the A' s Bluetooth again and the headset will connect with A automatically.

4) If there is no device found to be paired, the headset will power off automatically after 10 minutes.

(4) Instructions for use:

- 1) Power on / off: Direct dial on (off) or dial down (on) switch button.
- 2) Answer/end a call: Press the call answer/end key
- 3) Make a call:
Enter and dial the number on the mobile phone as you normally do. Once the call has been set up, the sound will be transmitted to your headset automatically.
- 4) Reject a call:
When there comes a call, press and hold the call answer/end key on the headset for 1-2 seconds.
- 5) Volume control: press the volume key, click to volume up or down.
- 6) If Bluetooth headset prompt voice "battery low", please charge.

3.Specifications

- 1) Bluetooth version: 4.1

- 3) Talking Time: About 24 hours
- 4) Standby Time: About 60 days
- 5) Charging Time: 3 hours
- 6) Music Play Time: 22 hours
- 7) wireless Range: 10m
- 8) Previous song,next song: Yes
- 9) Battery Status Display on IOS device: Yes
- 10) Support Multi—point with 2 device: Yes

4.Common problem

- 1) Low power for a long time will cause the disconnection. Please charge the headset when in low power.
- 2) If the headset cannot be switched on, please try charging it first and try switch it on again.

3) If the headset is completely exhausted or is not used for a long time, it is possible when charging that there is no indicator at first for some minutes until the red light turns on.

3) No sound in your headset .

- Make sure the headset and your phone has been paired and connected successfully.
- Make sure the headset is turned on.
- Make sure the headset and the phone does not exceed the effective distance.
- Make sure your phone is within effective wireless range.

5) Bluetooth headset can not be searched.

- Ensure that the headset enters the status ready to be searched.
- There is a possible program error caused by phone and Bluetooth. Please restart the device and repair.

5.Warranty

- Using non-original accessories may cause low performance, body damage ,short circuit and warranty failure.
- Disassembling your headset may damage the headset and causing warranty failure.
- Don' t use your headset in dusty environment.
- Please use a clean,soft and dry cloth to clean your headset.
- Keeping place the headset in the original package when not using it is recommended.
- Don' t let your children playing with the headset. They may hurt themselves or damage the headset.
- Don' t place the headset in hot or cold environments ,otherwise the headset may be temporarily unusable.

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.