

Model No.: VS85004



OPEN EAR BC300

QUICK START GUIDE

Please read this Quick Start Guide carefully and keep it for future use.

 Safety Warnings and Precautions

To ensure your safety and extend the service life of this product, please strictly follow the warnings below:

1. Environmental Warnings

- Do not use this product in extremely high or low temperatures, or in dusty or humid environments.
- Avoid direct sunlight, fire exposure, or any overheating conditions.
- In environments with strong wireless signals or dense crowds (such as airports, stations, exhibitions, etc.), intermittent connection or interference may occur. This is within normal range. Please continue to use the device later or change the usage environment.

2. Operational Safety Warnings


- Do not drop, strike, or subject the product to strong vibrations.
- Do not disassemble or modify the device without authorization to avoid hazards or damage.
- If any abnormal condition occurs, stop using the product immediately and contact your distributor.

3. Battery and Charging Warnings

- When the charging case indicator shows low battery, please recharge in time. If the product is not used for a long period, please recharge it at least once every 30 days.
- Use power adapters that comply with national standards and are CCC-certified.
- The earbuds contain built-in batteries. Do not expose them to high temperatures or flammable environments.
- If the charging port of the earbuds contains foreign objects or has poor contact, gently clean the charging port with a cotton swab dipped in alcohol. Regular cleaning is recommended to ensure proper charging and power-on/off functions.

4. Important Notes

- If there are updates or changes to product functions, please refer to the official website or the sales page for the latest information.
- Please keep this manual for future reference.



1.LED indicator

2.Previous song/Volume down

3. Multi Function Button (MFB)

4.Next song/Volume up

5. Microphone

6. Charging contact

Power/Charging

For better enjoyment, fully charge the headphone before use. A USB charging cable (charge only) is included for standard USB compatible device. Please use a 5V/1A or above power adapter (not included).
Caution:

- Use compatible standard 5 volt power adapter ONLY.
- Other incompatible chargers may cause damages.
- Do not use if the connector or device is wet or damaged.

Power On/Off

To turn on the headphone, press and hold the " MFB " button for 3 seconds, you will hear a power on tone,the white light remains on for 2 second.
To turn off the headphone, press and hold the " MFB " button for 5 seconds, you will hear a power off tone,the red light stays on for 2 second.
Caution: If no Bluetooth device is connected, the headphone will turn off in 3 minutes with power off tone.

Pairing

When power on, the headphone will automatically enter pairing mode for connection, turn on Bluetooth function on your phone and search for "Vanhuz Open Ear BC30 " for pairing. When the headphone is connected, a prompt tone will be heard, red and white lights flash alternately.

Music

Play/Pause: Click" MFB " button
Previous song: Connected mobile phone status, long press " - " button
Next song: Connected mobile phone status, long press " + "button

Call

Answer a call: Short press the" MFB " button
End the call: Short press the" MFB " button
Reject a call: Long press the" MFB " button

Volume Control

Short press the " - " button to turn down the volume
Short press the " + " button to turn up the volume

Mode Switching

TF Card Mode/Bluetooth Mode: Double-click the " MFB " button
Note: TF card mode allows for connection to a computer via a magnetic charging cable, enabling the transfer of songs and their storage to the headphones.

Voice Assistant

To enable/disable voice assistant: Triple-click the " MFB " button

Reset

When the device is powered on, press the "MFB" button continuously for 5 times, The headphones will then restart, clear the pairing information and successfully restore to factory settings.

Dual Device Smart Connection

After connecting the first phone, turn off the headphones and disable Bluetooth on that phone.
Turn on the headphones again and connect them to a second phone. After successful connection, re-enable Bluetooth on the first phone and tap "Vanhuz Open Ear BC30 " to reconnect.

Cautions

- Self replacement of battery is prohibited.
- Do not expose battery (battery pack or battery pack combination) in direct sunlight, fire or high temperatures.

For service, warranty, or product information,
Please contact: support@vanhuz.com with your order ID.

LED Indicator Guide

Status	Description	Voice Prompt
Power On	The white light on 2s and then turn off	Power on tone
Power Off	The red light on 2s and then turn off	Power off tone
Pairing	Red and white indicator lights flash alternately	-
Bluetooth connected	The red and white alternately flashing indicator light went off	Connected tone
Battery low	red indicator light is on for 1 second every 5 seconds.	Battery low tone
Charging	The red indicator light is on, It goes off after being fully charged.	-

FCC STATEMENT

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received. Including interference that may cause undesired operation.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.
FCC ID: 2AT2J-VS85004

75X95MM 105G双胶4C印刷+风琴折