

L28 Users in instruction manual

Declaration

Please read the user's manual so as to keep your mobile phone in the best condition, The manual has been verified and reviewed to guarantee the accuracy. Instructions and descriptions contained herein are accurate at the time of publication. However, mobile phones developed afterwards and the contents of their manual are subject to modification without further notification. Our company reserves the rights in relation to the manual

■ **Overview**

Please read the following concise rules carefully. Nonobservance to the rules may lead to danger or violence of the laws. The user's manual gives details about the safety precautions.

■ **Emergency call**

Make sure the equipment is in the covered area of the network service and the calling function is activated. As per the specific requirements, press the key of finish to clear the screen and return to the standby state. Input the emergency call number (112) and press the call key.

■ **Function Description**

The phone is a perfect combination of humanized design and exquisite workmanship, the streamline and ingenious body is comfortable to hold. With streamline and ingenious frame, it feels comfortable to hold the mobile phone in your hand. It supports SOS, Blue-tooth, dual SIM cards with one standby, network camera, camera, FM and etc, It makes your work more convenient and your free time more fun with the combination of keyboard, florid colored screen, pleasant bells, cartoon head portrait for incoming calls, strong file management function (supporting T-FLASH card), fashionable camera function and long time tape recording function, music player, video player.

1. Introduction

Insert the SIM card and the battery

Ask your SIM card dealer whether he has provided SIM card service and the method of usage who may be service provider or other dealers, SIM card and its contacts are vulnerable to scratch or bending. Attention shall be attached when use, insert or take out the card.

■ Inserting/taking out T-FLASH CARD

Only use approved and compatible T-FLASH card applicable to the mobile phone. Approved memory card trade standard is applied; however, certain bands may not be completely compatible with the mobile phone. Using incompatible memory card may damage not only the card and the mobile, but also the data stored in the card.

■ Charging the battery

Check the model number of the charger before using it to charge the mobile. Only use approved battery, charger and accessories applicable to the specific mobile model. Using other types of battery, charger and accessories may violate the certification or warranty terms of the equipment and may result in danger, Refer to the dealer for supply of relative approved accessories.

■ Startup and shutdown

Press the key of power supply to start up or shut down the mobile phone, If it is prompted to input PIN or UPIN, please input the required password (shown as ***** on the screen).

2. Function of main menu

■ Contacts

You have 2 phonebooks in this mobile phone: SIM card and the mobile. The mobile can store 500 phone numbers and the SIM card's capacity depends on its type.

■ Call log

You can view your recent call situation.

[Missed calls]: Show all missed calls list, select a view after a missed call occurred the date and time, phone number and times.

[Dialed calls]: Show all dialed calls list, select a view after a dialed calls occurred in the date and time, phone number and times.

[Received calls]: Show all answered the phone list, select a view after a phone that has the date and time of occurrence, telephone number, frequency,

[Rejected calls] Show all refused to answer the phone list, select a view after a missed call occurred the date and time, phone number and times.

Press the OK softkey to enter the options menu can be more than the number of call records in the following:

■ Settings

1. Call settings

This is some of the communications settings. There are have Dual-SM, Call divert, Call waiting, Call barring, Hide ID and others.

2. Phone settings

2.1. Date & Time : You can set the phone's time and date and the format.

2.2. Language Settings: You can select the phone's display language .

2.3 Shortcut settings: You can choose to change the function of shortcut keys.

2.4. Auto power on/off: After setting the time, and by that time the phone will auto power on/off.

2.5 Power management: Battery remains.

3. Display

3.1. Animation effect and Wallpaper: You can choose the style you want, and set up Animation effect, Wallpaper settings

3.2 Idle display settings: You can choose to display or not display.

3.2 Contrast & Backlight & Keypad backlight time: The menu is to control of mobile phone screen brightness and Keypad backlight time.

4. Security

You can manage your phone safely with this function.

The phone lock password, SIM card and PIN2 support 4-8 digit numbers, do not support other characters. The password and PIN2 and SIM card are provided by the network

operator. When the PIN/PIN2 is input wrongly in successively.

5. Connections

You can set up the phone network with this function.

SIM1/SIM2 network settings

Network selection: choice the modes of searching the phone network, including Auto and Manual modes.

6. Restore factory settings

Restore factory settings: Enter the correct password of the phone will have to change your phone settings back to factory default state value, the user of the function be used with caution. (Default password: 1234).

■ **Internet**

This includes Internet, Yahoo Facebook Ebuddy Twitter Nimbuzz access.

■ **Message**

Write a message: You may select to send the finished message from SIM card 1 or SIM card

You may select multiple receivers to send the message to more than 1 person.

■ **Camera**

In the options of camera, you may set the DV mode ,Effect ,contrast, Brightness, White balance, and Setting menu: photo size, photo quality, Banding, Shutter sound, Auto save, Storage , and Cont. shot. You may

■ **DV**

phone provides video recording, select video footage that can enter the video recording. In the preview video press OK button to begin, press stop again, can have white balance, exposure compensation, night mode, avoid flashing to set one by one. Settings are stored path cell phone or memory card. Restore all the camera options of setting for the system default values.

■ **Profiles**

There are generally 3 kinds of models (Normal, Silent, Indoor,). You can start, custom, rename, the ring settings, adjust the volume, ringing mode (including Silent, ringtones,) and other ring mode operation (including ring volume adjustment, caller ID, information prompt,

alarm, voice tone, low voltage, the switch machine set).

■ Calendar

calendar this feature allows you to view the calendar. In the calendar interface, press left soft key, you can make a new schedule, check the schedule, all schedule, empty, empty all, go to the date that day, weekly show operation, etc.

■ Audio

The music player is used to play music files in supported formats in the current player's list. You may view details of the music files and set the current music file as the ring signal for incoming call.

■ video

Check the video files in the memory card supported by the cell phone. Play your favorite video files.

■ E-book

Read E-book stored in the T-Flash card your option include:

Add bookmark: Add a bookmark for next read.

View bookmark: Open the bookmark and continue reading the last.

Display settings: You can set up the foot style, font size, scroll by and so on.

Turn off backlight: When reading, open the menu, the screen will always be lit.

Day/Night mode: In the evening, You can switch to night mode.

Jump to percent: Input a number, the e-book will jump there.

Auto view: Set the page time, e-books will automatically page.

■ My Files

memory card

The File Manager lists all the files stored in your phone or memory card. You can new folder, delete folder, view the detail, edit folder (rename, copy, cut), search folder, mark folder, sort the folder, and view the memory status.

■ Bluetooth

You may establish wireless connection with other compatible devices with the Bluetooth technology; you may send images, videos, music files and etc. with the Bluetooth technology.

■ Image

Check the pictures in the memorial card in formats supported by the cell phone.

■ FM radio

Turn on FM broadcast, and you may press the direction keys of left and right to manually tune the channel. Press the direction key of upward to turn on or off the auto-searching mode.

Press OK to record the FM broadcast. Press the direction key of downward to turn on or off FM broadcast. In the options, you may set manually or automatically searching for channels, turning off the background during broadcasting as well as the format of recording thereof.

■ Calculator

You can conduct the basic arithmetic operation with the function.

Input the first number

■ Games

There are two games: sokoban and snake eating.

■ Record

In the options of the video camera, you may set the exposure compensation, avoidance of flickering, white balance, special effect, profile and etc.

■ Alarm

Set the time of alarm clock, ring signal, ring mode, alarm ring mode and interval between repeated alarm rings.

■ Unit conversion

Convert units.

■ STK

This function by the network providers, according to the SIM card provides services will appear different menu options. If a SIM card and network supplier does not support this service, this function will not be used. If you need to get more information please contact with network providers.

3. PC connect

■ USB

Use the T-Flash inserted in the mobile phone as U-Disk. You can transfer music, videos, games and other files from PC to the T-Flash by USB cable. Enjoy it anytime and anywhere.

■ COM PORT

Establish a modem on the local computer and construct a network, and the serial interface is connected after signing in with the account.

4. Maintenance and service

Refer to the local dealer for supply of accessories. Hereafter are some precautions for usage of the accessories, Only use batteries, chargers and accessories approved by the manufacturer. Usage of other types of batteries, chargers and accessories may result in violence of the certification or warranty terms or even lead to danger, Keep the equipment dry, Don't keep the equipment in under cooled places; otherwise, when the temperature rises to normal, moisture may be generated within the equipment, resulting in damage of the circuit board. .Only use matched or approved antenna .

■ FCC Warning

Specific Absorption Rate (SAR) information SAR tests are conducted using standard operating positions accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands, although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value, in general, the closer you are to a wireless base station antenna, the lower the power output. Before a new model phone is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the exposure limit established by the FCC, Tests for each phone are performed in positions and locations (e.g. at the ear and worn on the body) as required by the FCC.

For body worn operation, this mobile phone has been tested and meets the FCC RF exposure guidelines when used with an accessory designated for this product or when used with an accessory that contains no metal and that positions the handset a minimum of 5 mm from the body.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.