685.4

76.2 76.2 76.2 76.2 76.2 76.2 76.2 75.8

126.6

MYLUMA

QUICK START GUIDE

Welcome to the Photoshare Family! Lets get started!

Explorez more products at
www.sshome.com

Scan the QR code to view the full online guide or visit
www.sshome.com/guides

For Customer Service please email
support@photosharetrame.com

PHOTO**share**
MYLUMA

Scan the QR code to view the full online guide or visit

Escanee el código QR para ver la guía completa en línea o visite

Numérisez le code QR pour consulter le guide complet en ligne ou rendez-vous sur

www.sshome.com/guides

Set up your new Photoshare Myluma Frame in 3 simple steps!

Photoshare Ring
Tap the firework(s) once and it will start to shine. Hint: tap the photos you want to add first!

Tilt
Tilt your frame at an angle between 30 degrees and 90 degrees to your wall. Hint: the more you tilt your frame, the more it will shine!

Turn on your frame – Use the included AC power adapter to plug your MyLuma frame into an available outlet.

Create your Photoshare Frame Account – Visit the Apple App Store or Google Play Store on your mobile device and create your account if you have not already done so. Hint: you will need your Wi-Fi network name and password to set up your account.

PC/MAC App
Photoshare Frame PC/MAC app can be downloaded from your account page.

Google Picasa or other Apps
Photoshare Frame can also be linked to your Google Picasa, Flickr or other cloud photo accounts. Hint: you will need your Google Picasa, Flickr or other cloud photo account's username and password to link your frame to your account.

Mobile App
Photoshare Frame Mobile App can be downloaded from your App Store or Google Play Store. Hint: you will need your Wi-Fi network name and password to link your frame to your account.

Connect your frame to WiFi – Select your WiFi network from the list, input your WiFi password, and tap Connect. Follow the on-screen instructions to complete setup.

Screen Saver: Default screen saver options are rotating + a slideshow that cycles through your photos. Just use your finger to flip your photos.

Digital Picture Frame: Use the Photoshare Frame app to display your photos in a fun and easy to enjoy your favorite photos.

Digital Display: Photoshare Frame can also be used as a digital display for your business. Contact your Photoshare Frame representative for more information.

Share Photos Fast: Assign a unique 5 digit code to each family member and MyLuma frame to use as a fast, private, and secure way to share photos.

Family Vacation: Select a family member to MyLuma's Q&A for new photos to share with the family. Hint: you can also use the Photoshare Frame app to share photos with family members who do not have a MyLuma frame.

Share Photos Fast: Assign a unique 5 digit code to each family member and MyLuma frame to use as a fast, private, and secure way to share photos.

Family Vacation: Select a family member to MyLuma's Q&A for new photos to share with the family. Hint: you can also use the Photoshare Frame app to share photos with family members who do not have a MyLuma frame.

Create Your Own Private Social Network!

Do you have friends and family who also own Photoshare Frames? Then click on the button to the top right corner to add and selecting each frame. Then add a friend or family Members Name and enter their Photoshare ID.

Your Photoshare ID can be found on the menu button in the top right corner. Simply enter their email addresses and they'll be invited to join your private social network! Once they accept your invitation, you'll be able to share photos with them instantly!

For Customer Service please email
support@photosharetrame.com

Multiple Ways to Share

Share Photos Fast: Assign a unique 5 digit code to each family member and MyLuma frame to use as a fast, private, and secure way to share photos.

Family Vacation: Select a family member to MyLuma's Q&A for new photos to share with the family. Hint: you can also use the Photoshare Frame app to share photos with family members who do not have a MyLuma frame.