

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOBLE

Bluetooth earphone

MODEL: Falcon Pro




Instruction Manual


ユーザースガイド

Thanks for purchasing NOBLE Falcon Pro Bluetooth 5.2 True Wireless Earbuds.
Please read this instruction manual carefully before using your new Falcon Pro Earbuds.

Packing List



Noble Falcon Pro Earbuds x 1 pairs



Instruction Manual x 1



Ear tips x 3






USB charging cable x 1




Storage bag

Product Overview



Power On



The earbuds will power on automatically when removed from the charging case if the earbuds have been sufficiently charged. A white indicator LED will bling for one second to indicate a "power on" state.

Power Off




If the earbuds are turned on without connecting to a device for 5 minutes, then the earbuds will power off automatically.



The earbuds will power off automatically after being placed in the charging case.

How to Pair



- **Pairing Procedure**
The first time you use your earbuds with your smartphone, you will need to pair them with your smartphone. Once paired, they will connect automatically each time they are booted up.
- Pairing**
1. Remove your two earbuds from the charging case. They will power on automatically, and will enter pairing mode, with orange and white indicator lights flashing alternately.
 2. Enable Bluetooth on your smartphone, and search for "NOBLE Falcon Pro" in available Bluetooth devices. Once found, click "NOBLE Falcon Pro" to initiate the pairing.
 3. After pairing, the connect interface of the second earbud should appear on your smartphone. Click it to confirm and all settings will be completed.


- **Pairing a new device**
Repeat above steps

Button Operation



Model	Function	L	R
MUSIC	Play	Single tap	Single tap
	Pause	Single tap	Single tap
	Next Track	-	Double tap
	Previous Track	-	Triple tap
Phone	Answer Call	Single tap	Single tap
	Hang Up	Single tap	Single tap
	Reject Call	-	-
Siri	Enable	Quadruple tap	Quadruple tap
	Disable	Quadruple tap	Quadruple tap
Volume	Up +	Triple tap	-
	Down -	Double tap	-
Hear-through	Enable	Double tap	-
	Disable	Double tap	-

Reset



Please put both of the earbuds back to the case. Then, long press the reset button for about 5 seconds till the orange LED turns off and white LED turns on for one second, then, the white LED will flash quickly. The earbuds are now successfully reset.

Hear-through function



- Take the earbuds out of the case and double tap the Tap sensor to activate hear-through mode.
- Please make sure that the earbuds are on standby, whether connected or disconnected to the device.
- Note that hear-through mode cannot be activated when music is playing or during a call. Please pause any music or terminate any calls prior to activating the hear-through function.

Single Earbud Usage

1. Please note that both the earbuds can be used in mono mode. Remove the desired earbud from the charging case to switch it on.
2. The selected earbud will automatically enter the connection mode indicated by white LED flashes.
3. Turn on Bluetooth on your device and search for Noble Falcon Pro to connect.

Notes:


To switch to stereo mode, simply take out the other earbud from the case. It will automatically power on and pair with the previously selected earbud, thus enabling stereo usage. You cannot skip tracks or return to the previous tracks in mono mode.

The LED Indicator for Falcon PRO

User Scenario	LED
Power on	White LED on for 1 second
Standby (both connected and disconnected)	White LED flashes twice every 5 seconds
Pairing	Orange and white LED flash alternatively
Reset	White LED flash quickly
Power off	Orange LED on for 1 second
Charging	Orange LED on
Full charged	Orange LED off
Battery low	Orange LED on
Calling and playing music	LED off

Charging

■ Battery Indicator:



● ● ● ● 0% - 25%	● ● ● ● 25% - 50%
● ● ● ● 50% - 75%	● ● ● ● 75% - 100%

Case Charging		Earbuds Charging	
Charging	White LED ON	Charging	Orange LED ON
Fully Charged	All LED On	Fully Charged	Orange LED Off

Declarations and Warning

- Declarations and Warnings Disconnect previous devices before pairing a new device.
- **WARNING!**
 - Long-term exposure to high noise volumes may cause permanent hearing loss.
- Do not use the NOBLE Falcon earbuds in locations prohibiting the use of electronic equipment.
- Consult your physician prior to using your NOBLE Falcon earbuds if you have a pacemaker or other electrical medical device.
- This package contains small parts, which may pose a hazard to small children.
 - Do not disassemble the NOBLE Falcon as it contains lithium batteries, and disassembly could result in electric shock or fire or serious injury.
- Any disassembly of the NOBLE Falcon, or attempt to replace or repair the NOBLE Falcon by an unauthorized person, will void the NOBLE Falcon's warranty.
- This product is not designed for use in water, keep product away from water and liquids. Failure to do so may cause permanent damage to the product.

Qualcomm aptX Adaptive & Qualcomm aptX



Qualcomm aptX and Qualcomm cVc are products of Qualcomm Technologies, Inc. and/or its subsidiaries. Qualcomm is a trademark of Qualcomm Incorporated, registered in the United States and other countries. aptX and cVc are trademarks of Qualcomm Technologies International, Ltd., registered in the United States and other countries.

Qualcomm aptX and Qualcomm TrueWireless are products of Qualcomm Technologies, Inc. and/or its subsidiaries. Qualcomm and Qualcomm TrueWireless are trademarks of Qualcomm Incorporated, registered in the United States and other countries.

この度は、本製品をお買い上げいただき誠に有り難うございます。
本製品をご利用になる前に、本紙に必ず目を通していただきますようお願いいたします。

安全にお使いいただくために

この「コーザースガイド」には、製品を安全に正しくお使いいただき、お客様や他の人々への危害や損害を未然に防止するための注意事項を、危害や損害の大きさと、切迫程度を明示するために、誤った取り扱いにより生じる事が想定される内容を次のように区分して表示しています。

警告 人が死亡または重傷を負う可能性が想定される内容を示しています

注意 人が損害を負う可能性、および物的損害のみの発生が想定される内容を示しています

絵表示

この記号は「**してはいけないこと**」の内容を告げるものです

この記号は「**しなければならないこと**」の内容を告げるものです


警告	
	・車両の運転操作や、エアバッグなどの運転補助装置の妨げにならない場所に設置し絶対に運転中に取り扱わないでください。 ・車両運転中の携帯電話の使用は法律で禁止されています。ハンズフリー自動応答が設定できない場合には、必ず安全な位置に乗り物を停車させてからご使用ください。 ・進行に必要な外部の音が聞こえない場合は、使用しないでください。 交通事故の原因となります。
	・踏切 / 駅のホーム / 道路 / 工事現場など、周囲の音が聞こえないと危険が生じる場所では使用しないでください。交通事故の原因となります。 ・本製品にはリチウムイオン電池が内蔵されています。炎天下の車のダッシュボードや窓辺など、高温になる場所に本製品を設置しないでください。
	・小さな部品があります。いたずらや誤飲などを避けるため、子供や乳幼児の手の届かない場所に保管してください。

注意	
	・音量を上げすぎないでください。耳を刺激するような大きな音量で長時間ご利用になると、聴力に悪影響を与えることがあります。 ・本製品は防水ですが、通常の使用以上に長時間水に濡らす、火に近づける、高温多湿、直射日光の当たる場所やほこりの多い場所に本製品を設置しないでください。故障の原因となります。
	・投げたり、衝撃を与えないでください。事故や故障の原因となります。
	・充電ケースからUSB充電ケーブルを抜くときは、必ずケーブルのコネクタ部分を持って抜いてください。ケーブルを引っ張ると断線し、故障の原因となります。 ・汚れは、乾いた柔らかい布で拭き取ってください。シンナー / ペンジン / アルコールなどは使用しないでください。

梱包品の確認 ※最初に製品がそろっている事をご確認ください



製品本体 x 1



ユーザーズガイド(本紙)x 1



イヤーチップ x 3




USB充電ケーブル x 1



ポーチ x 1


各部の名称




充電ケース本体

RESETボタン

LEDインジケータ




充電用USBポート



LEDインジケータ

マルチファンクション
タップセンサー

マイク



電源を入れる



ケースから本体を取り出すと、本体は自動的に電源がオンになります。
本体の白とオレンジのLEDインジケーターが1秒間点灯し、本体の電源が入った事をお知らせします。

ペアリングする

お手持ちのスマートフォン等の機器と初めて接続する際は、ペアリングを行う必要があります。
ペアリングが完了すると、次回から電源をオンにするだけで自動的に接続されますので、再度ペアリングを行う必要はありません。



■ 本体を初めてご使用になる場合

- ① 本体を充電ケースから取り外します。本体の電源が自動的にオンになった後、自動的にペアリングモードへ移行します。この際、本体に内蔵されたオレンジと白のLEDインジケーターが交互に点滅を開始します。
- ② 接続する機器(スマートフォン等)にあるBluetooth設定画面を開き「NOBLE Falcon Pro」が画面に表示されている事を確認し、選択してください。
- ③ 接続する機器の画面で「接続」と表示されたらペアリングは完了です。


■ ペアリングをやり直す場合

- ① 本体を充電ケースから取り外します。この際、すでにペアリングされた機器がお手元にある場合、その機器と自動的に再接続します。
- ②すでにペアリングされた機器のBluetooth設定画面から、「NOBLE Falcon Pro」を削除すると、本機は自動的に再びペアリングモードへと移行し、本体に内蔵されたオレンジと白のLEDインジケーターが交互に点滅を開始します。
- ③ 接続する機器(スマートフォン等)にあるBluetooth設定画面を開き「NOBLE Falcon Pro」が画面に表示されている事を確認し、選択してください。
- ④ 接続する機器の画面で「接続」と表示されたらペアリングは完了です。

電源を切る



5分間他の機器(スマートフォン等)と接続しなかった場合、自動的に本体の電源がオフになります。



本体を充電ケースに戻すと、本体は充電のために電源が自動的にオフになります。本体の充電中は、本体のLEDインジケーターがオレンジで点灯します。充電が完了すると、LEDインジケーターが消灯します。

※充電ケース内のバッテリーが空になると、本体の電源が自動的にオン/オフなくなります。また本体への充電が出来なくなります。その場合は充電ケースの充電を行ってください。

タップセンサーの使い方



タップセンサーを
タップします



対応する動作	機能	L	R
音楽を聴く	再生する	1回タップ	1回タップ
	一次停止する	1回タップ	1回タップ
	次の曲を再生する	-	2回タップ
	再生中の曲の先頭に戻る ／1つ前の曲に戻る	-	3回タップ
電話を受ける	電話をかける	1回タップ	1回タップ
	通話を終了する	1回タップ	1回タップ
	応答を拒否する	-	-
Siriを使う	有効にする	4回タップ	4回タップ
	無効にする	4回タップ	4回タップ
ボリュームを調整する	音量を上げる	3回タップ	-
	音量を下げる	2回タップ	-
アンビエント(外音取込)のON/OFF		2回タップ	-


LED表示の見方

対応する動作	LED
電源オン	白が1秒点灯
待機中	白が5秒毎に3回点滅
ペアリングモード	白とオレンジが交互に点滅
リセット	白が高速点滅
電源オフ	オレンジが1秒点灯
充電中	オレンジが点灯
充電完了	消灯
バッテリー残量低下	オレンジが点灯
通話時／音楽再生時	消灯

充電する

■ 充電方法

充電ケースのUSBポートに付属の充電用ケーブルのUSB-Cコネクタを接続し、USB(A)コネクタをUSB充電アダプターなどに接続するとケースの充電が開始されます。充電中はバッテリーインジケータが点滅します。LEDが4つ点灯すると、充電完了です。また、電池残量に応じLEDの点灯数が減少します。



充電ケース内バッテリーインジケータは残容量に応じて以下のように表示されます			
● ● ● ●	0% - 25%	● ● ● ●	25% - 50%
● ● ● ●	50% - 75%	● ● ● ●	75% - 100%

外音取り込み（ヒアスルー）機能

外音取り込み機能について

Falcon Proはユーザーの安全を第一に考え、外音取り込み（ヒアスルー）機能を備えています。

外音取り込み機能をオンにすると、本体搭載のマイクで、周りの音を集音し、本体から外の音を再生します。

（例）飛行機の中や、電車と言った公共交通機関をご利用の際に、機内/車内のアナウンスを本体をしたまま聞くことができます。また、徒歩による移動の際にも、自転車や自動車の走行音を聞き取ることが出来るため、安全に配慮することが可能です。

ご使用上の注意 安全のために、周りの音を注意深く聞く必要がある場合は、本体を耳から取り外してください。

ワイヤレス充電機能

ワイヤレス充電機能について

Falcon Proの充電ケースはワイヤレス充電（Qi充電器もご利用頂けます）に対応しています。Falcon Proの充電ケースにはワイヤレス充電機能が組み込まれていますので、充電が手軽で簡単になります。

ワイヤレス充電器はアクセサリとして市販されていて、自動車、カフェ、ホテル、空港に設置されている場合があります。ワイヤレス充電器については、機能や性能が製品によって異なる場合がありますので、ご購入がある場合は、充電器メーカーに直接お問い合わせください。

ワイヤレスで充電する

1. ワイヤレス充電器を電源につなぎます。充電器に付属の電源アダプター、またはメーカー推奨の電源アダプターをご使用ください。
2. ワイヤレス充電器を水平な台の上や、メーカーが推奨する場所に置きます。
3. Falcon Pro の充電器の底面を充電器の上に置きます。充電効率が良くなるように、充電器の中央、またはメーカーが推奨する位置に置いてください。数秒後に充電が始まるはずです。

リセット ※動作が異常と感じられる時はリセットをお試しください



本体を両方とも充電ケースに戻してください。その後、白のLEDが高速で点滅するまで充電ケース中央のリセットボタンを長押ししてください（約5秒）。オレンジのLEDが消灯し、白色のLEDが点灯したら、イヤホンのリセットが成功しています。充電ケースから本体を取り出すと、本体の片方がペアリングモードになるまで白のLEDが高速で点滅し、白のLEDとオレンジのLEDが交互に点滅します。

外音取り込み（ヒアスルー）機能の使い方

- 外音取り込み機能を使用するには、左本体のタップセンサーを2回タップし、機能をオンにします。また、再度センサーを2回タップすることにより機能を解除（オフにすることが）できます。
- 本体を接続しても外しても、本体がスタンバイ状態になっていることを確認してください。
- 音楽再生中や通話中は、外音取り込み（ヒアスルー）機能を起動できません。一度音楽を停止してから、外音取り込み（ヒアスルー）機能を起動してください。

困ったときは

電源が入らない

- ・充電ケースと本体の充電を行ってください
- ・本体を充電ケースに戻し、5秒後に再び取り出してください

再生する機器と接続されない/音が出ない

- ・他の機器とすでに接続している場合は、まずその機器のBluetooth接続をオフにしてください
- ・再生する機器のBluetoothデバイスメニューから“NOBLE Falcon Pro”を選択してください
- ・それでも接続できない場合は、再生する機器から“NOBLE Falcon Pro”のデバイス情報を削除して、再ペアリングしてください

ペアリングモードに入らない

- ・他の機器とすでに接続している場合は、その機器のBluetooth接続機能をオフにするか、ペアリング済みの“Noble Falcon Pro”を削除してください
- ・電源がオンになっていることを確認して、タップセンサーを2回押してください

音が小さすぎる/大きすぎる

- ・タップセンサーで音量の調節をおこなってください
- ・再生機器によっては再生機器側に独立した音量調節があります。その場合は本体と両方の音量を適切に調整してください

片側の音が出ない/出なくなった

- ・本体を充電ケースに戻し、5秒後に再び取り出してください

専用アプリ Noble Sound Suite について

本製品をより便利にご利用いただくために、本体の設定の変更、イコライザー機能、ファームウェアの更新などにご利用いただける専用アプリ Noble Sound Suite をご用意しています。

お使いの機器（スマートフォン等）にあわせて、右のQRコードをスキャンのうえ、ダウンロードいただけます。

Android



iPhone



インターネットによるお問い合わせ

製品に関するお問い合わせは以下のサイトからお問い合わせいただけます。

<https://nobleaudio.jp/support/tws>

スマートフォン等をご利用の方は、右のQRコードを撮影する事で、サポートサイトをご覧頂けます。



電話によるお問い合わせ



0570-057067

受付時間:土日祝日を除く、午前11時から午後5時

※臨時にお休みをいただく場合があります。
また、電話でのお問い合わせは大変混雑している場合がありますので、その場合はインターネットによるお問い合わせをお願いいたします。

※お間違いのないよう、番号をよくご確認のうえおかけください。

※弊社ではお客様からのご相談の内容を正しく把握し、正確にご回答するため、通話内容を録音させていただいております。あらかじめご了承ください。

仕様

製品仕様	
チップセット	Qualcomm QCC3040 (Qualcomm TrueWireless™ Mirroring対応)
ドライバー	Knowles SRDD BA driver&6mm Titanium Coated Dynamic Driver (2BA+1DD)
再生周波数帯域	20 Hz・24,000 Hz
マイク	全指向性 / クアルコムCVC8.0ノイズキャンセリング搭載
Bluetooth仕様	Verson5.2 / Class2 / マルチペアリング対応
Bluetoothプロファイル	A2DP,AVRCP,HSP,HFP
対応コーデック	SBC,AAC,aptX, aptX Adaptive
電源	本体:50mAh / 充電ケース:500mAh 3.7V リチウムポリマー 充電池(内蔵式) (充電ケースは無線充電対応)
連続再生時間(最大)	5.5時間(最大音量時) / 10時間(70%音量時)
連続通話時間(最大)	6時間(最大音量時) / 12時間(70%音量時)
充電時間	イヤホン 約1時間 / 充電ケース 約1.5時間
使用温度範囲	摂氏マイナス20度～60度 (結露なきこと)
耐水性能	IPX5
付属品	充電ケース、ポーチ、イヤピース(ePro製: S/M/L) USBケーブル、ユーザーズガイド(本紙)

製品保証書

この製品保証書は、株式会社エミライが定める製品保証規定に基づき、購入後、1年間にわたり製品本体の無償修理をお約束するものです。
保証期間中、故障が発生した場合、お買い上げの販売店または弊社指定の受付窓口にご依頼ください。保証内容の詳細は本紙下部の
インターネットアドレスからご確認ください。

お買い上げ日： 年 月 日

製品名(型番)： Falcon Pro

販売店(住所/店名/電話番号)：

保証内容の詳細: <http://www.emilai.co.jp/warranty/>
お問い合わせ先ならびに販売元: 株式会社エミライ 0570-057067 (ナビダイヤル)

紛失あんしん保証サービスのご案内

紛失あんしん保証サービスとは？

- ・紛失安心保証サービスとは、本製品をお客様がご利用の際に、片耳のイヤホンを紛失した際に、紛失したイヤホンをお得な価格でご提供するものです。
- ・本サービスは、商品ご購入後に購入できるサービスです。
- ・サービスだけの単品購入はできません。
- ・製造終了品品については、本サービスを適用できない場合があります。あらかじめご了承ください。

ー 紛失安心保証サービスの利用をお考えの方へ ー

サービスの詳細およびご利用方法

以下のインターネットサイトから、本サービスの詳細およびご利用方法をご確認いただけます。

<https://nobleaudio.jp/support/tws-ansin>

