ASTRA BLUETOOTH AUDIO TRANSMITTER - USER MANUAL

PAGE 1

62MM

105MM

JOURNEY

ASTRA Wireless Audio Adapter

journeyofficial.com

PAGE 2

WHAT'S IN THE BOX

1 ASTRA Wireless Audio Adapter

2 USB A to USB-C Cable (30cm)


3 Airplane Adapter

PAGE 3

TRANSMIT MODE (TX)

TX RX

Use your AirPods to wirelessly listen to any in-flight entertainment or headphone jack.



Use the included airplane adapter to connect your ASTRA to any two or three port headphone jacks.

PAGE 4

RECEIVE MODE (RX)

TX RX

Wirelessly stream music from your phone to any speaker with a headphone jack.



PAGE 5

CHARGING ASTRA

Use the included USB-C cable to fully charge before first use.
It takes 2 hours to fully charge. The rechargeable battery last up to 25+ operation hours.

Charging LED indicators	
Solid White	Charging
Off	Fully Charged
Flashing White	Low Battery

NOTES & TIPS


1. **Audio Control**: A single click of the button functions differently depending on the mode:
 - **TX Mode**: Mute or unmute audio.
 - **RX Mode**: Pause or play your music.
2. **Pairing Memory**:
 - **TX Mode**: ASTRA can remember and simultaneously connect to up to two headphones.
 - **RX Mode**: ASTRA can pair with one phone.
3. **Clear Pairings**: To clear all paired devices in TX Mode, click the button three times within 2 seconds.
4. **Pairing Confirmation**: After successful pairing, the LED indicator will remain solid for 10 seconds before turning off.

PAGE 6

PAIRING IN TRANSMIT MODE (TX)

Pairing the first set of wireless headphones/earbuds

1. Slide switch to TX. Hold the power button for 3 seconds to turn on device. The LED will flash orange, indicating it is in pairing mode.



2. Put your headphones/earbuds in pairing mode. *(Refer to model-specific pairing instructions pages, or check your earbuds' user manual)*

3. Once paired, the LED will turn solid orange.




4. Plug ASTRA into your device's (eg. in-flight entertainment, TV, PC, game console) audio port to wireless from your earbuds.

PAGE 7

PAIRING IN TRANSMIT MODE (TX)

Pairing the second set of wireless headphones/ earbuds

1. Make sure ASTRA is already connected to the first set of headphones/earbuds.
2. Enter second device pairing mode:
 - Click the power button twice.
 - The LED will flash blue, indicating it's ready to pair a second device.



3. Put your second set of headphones or earbuds into pairing mode.


4. Once paired, the LED will turn solid blue. Both sets of headphones are now paired and sharing audio.



PAGE 8

USING RECEIVE MODE (RX) WITH AUX-IN

1. Slide switch to RX. Hold Power button for 3 seconds. The LED will flash orange.



2. On your phone or tablet, open Bluetooth settings and connect to "ASTRA Audio Adapter"



3. The LED will turn solid orange when connected.

4. Once connected, plug ASTRA into the AUX-IN port of your device (car stereo, speaker, etc.).



PAGE 9

TROUBLESHOOTING

Symptom	Solution
Cannot enter pairing mode	Ensure ASTRA is charged and turned on. Keep devices next to each other during pairing. Click power button 3 times to reset.
Cannot pair second device	Confirm first device is connected and follow user manual steps.
No sound in RX mode	Check AUX cable is fully inserted and phone is connected.
LED not lighting	Charge ASTRA for at least 30 minutes.
Static noise after paired	Static noise is sometimes heard when no audio is playing. Press the power button once to mute.

SUPPORT

- Contact customer support at sales@journeyofficial.com for more help.
- Keep your firmware updated for best performance.

PAGE 10

MODEL-SPECIFIC PAIRING INSTRUCTIONS


Apple AirPods Pro 3 & AirPods 4

Place both AirPods in the case and keep the case open. Then double tap the front of the case and the LED will flash white.



Apple AirPods 1, 2, 3, Pro 1, Pro 2

Place both AirPods in the case and keep the case open. Press and hold the button on the back of the case until the LED flashes white.



Apple AirPods Max
Press and hold the Noise Control button until the status light flashes white.




PAGE 11

MODEL-SPECIFIC PAIRING INSTRUCTIONS

Samsung Galaxy Buds3 / Buds3 Pro

Place both earbuds in the case, close the case, and then reopen it. Press and hold the connect button on the case for 3 seconds until the LED flashes red, blue, and green.



Samsung Galaxy Buds2 / Buds2 Pro

Place both earbuds in the case, close the case, then reopen it. Touch and hold both earbuds (if there's no button) for 3 seconds until the LED flashes red, blue, and green.




PAGE 12

MODEL-SPECIFIC PAIRING INSTRUCTIONS

Samsung Buds Pro / Buds Live / Buds+ / Buds

Insert both earbuds in the case, open the case and press and hold the Bluetooth button until the LED flashes blue.



Touchpad Method

Place both earbuds in your ears. Touch & hold both earbuds' touchpads at the same time for 3 seconds. You'll hear a chime and the buds will enter pairing mode.



PAGE 12


MODEL-SPECIFIC PAIRING INSTRUCTIONS

Bose Earbuds (eg. QuietComfort Earbuds / QuietComfort Earbuds II)

If not wearing the earbuds, press and hold the Bluetooth button in the charging case until the earbud status lights slowly pulse blue.



Bose Headphones (eg. QC45, 700)
Press and hold the power/Bluetooth button until you hear "Ready to pair" and the LED flashes blue.



PAGE 13

MODEL-SPECIFIC PAIRING INSTRUCTIONS

Beats Headphones (eg. Studio Pro, Studio 4, Studio 3, Solo 4, Solo 3)

Press and hold the power button until the LED light flashes.




Beats Earphones (eg. Beats Fit Pro, Studio Buds+, Studio Buds, Powerbeats Pro)

Press and hold the power button until the LED light flashes.



Beats Neckband Earphones (eg. Beats Flex)

Press and hold the power button until the LED light flashes.



PAGE 14

MODEL-SPECIFIC PAIRING INSTRUCTIONS

Sony Headphones Earbuds (eg. WF-1000XM4, WF-1000XM5, WF-LS910N (LinkBuds S), WF-L910)

Place both Earbuds in the case and keep open. Press and hold the power button until the LED light flashes.



Sony Earbuds -Touchpad Method (eg. WF-C500)

Remove both earbuds from the charging case. Press and hold the buttons on both the left and right earbuds for about 5 seconds until LED flashes blue.



Sony Headphones (eg. WH-1000XM4, WH-1000XM5, WH-XB910N, WH-CH720N)

Press and hold the power buttons for at least 7 seconds unit LED flashes blue.



Sony Neckband Earphones (eg. WI-1000XM2, WI-C100, WI-C400, WI-XB400)

Press and hold the buttons on the in-line remote unit LED flashes blue.




PAGE 15

MODEL-SPECIFIC PAIRING INSTRUCTIONS

JBL Earbuds (eg. Tune 130NC, Live Pro+)

Remove earbuds from the case. Perform a single tap, then a second tap followed by a long press (5 seconds) on one of the earbuds.

You will hear a beep, indicating the earbuds are in pairing mode.



JBL Headphones (eg. Club 950NC, Live 660NC)

Press and hold the power button for 3 seconds until the LED flashes blue.



COMPLIANCE STATEMENTS

FCC Compliance Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
• Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and receiver.
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
• Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restrictions.

Responsible Party - U.S. Contact Information
ALOGIC USA LLC
37524 Marsten DR,
Newark CA 94560, USA

EU Declaration of Conformity

This device in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU.All essential radio test suites have been carried out. This restriction will be applied to all Member States of European Union.
The device complies with RF specifications when the device used at 20cm form your body.
Hereby, ALOGIC Corporation declares that this product is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following Internet address by clicking on the Compliance Documentation link:
https://journeyofficial.com/

ISED Caution:

Radio Standards Specification RSS-Gen, issue 5

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:
This device may not cause interference.
This device must accept any interference, including interference that may cause undesired operation of the device.
RF exposure statement:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Cet appareil contient des émetteurs / récepteurs exemptés de licence conformes aux RSS (RSS) d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes:
Cet appareil ne doit pas causer d'interférences.Cet appareil doit accepter toutes les interférences, y compris celles susceptibles de provoquer un fonctionnement indésirable de l'appareil.

Declaration d'exposition RF:

L'appareil a été évalué pour répondre aux exigences générales d'exposition aux RF. L'appareil peut être utilisé dans des conditions d'exposition portable sans restriction.

WARNINGS

WARNINGS

Avoid exposing it to extreme conditions that may affect its functionality.

Keep ASTRA Wireless Audio Adapter away from all heat and fire sources, including heating equipment, heaters, ovens, open flames, and direct sunlight.

Do not attempt to repair or disassemble the ASTRA Wireless Audio Adapter equipment by yourself, Any unauthorized modification may result in damage or malfunction.

Avoid using or storing ASTRA Bluetooth Audio Transmitter in environments with high humidity or temperatures exceeding 60°C (140°C) to prevent potential failures.

Responsibly dispose of ASTRA Bluetooth Audio Transmitter products following the local government's regulations on waste disposal to minimize environmental impact.

AU COMPLIANCE

AUSTRALIAN WARRANTY

Warranty Period

12 Months

Warranty Terms

ALOGIC Corporation Pty Ltd warrants this product to be free from defects in workmanship and materials for the warranty period stated above from the date of purchase, provided the product is used in accordance with the accompanying recommendations and instructions.

How to Make a Claim

Please retain your receipt as proof of purchase and return the product with the receipt to your place of purchase to make a warranty claim.

This warranty is in addition to your rights under the Australian Consumer Law.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

For New Zealand customers, this warranty is in addition to statutory rights under New Zealand legislation.

ALOGIC Corporation Pty Ltd
Level 34, 140 William St Melbourne VIC Australia 3000
1300 700 989