

CHRISTMAS BEETLE 10 - USER MANUAL

SIDE 1

FRONT PAGE

54MM

85.5MM

JOURNEY

Journey LOC8 VERSA Wallet Universal

journeyofficial.com

INTERNAL PAGE 1

SETUP WITH APPLE FIND MY APP

1. Update your iPhone to the latest version of iOS. Activate Bluetooth.

2. Press your LOC8 VERSA Wallet button once (see arrow pointing to button in drawing below). The beeping that follows indicates your device is ready for pairing.

3. Open the Apple Find My app.

4. Tap "+"; select "Add Other Item" to bring up LOC8 VERSA Wallet on your screen for pairing.

INTERNAL PAGE 2

FIND YOUR LOC8 VERSA

1. In "Find My" app, tap "Items".

Items

PeopleDevicesItemsMe

2. Check your wallet's last known time and place.

3. Click and select the wallet from the list.

4. To find a nearby item, tap "Play Sound" and listen for a chime.

5. For distant items, click "Directions". Open Maps to navigate to the last-known location.

Journey LOC8 VERSA Wallet Universal

Now

Play SoundOff

DirectionsWith You

INTERNAL PAGE 3

SETUP WITH GOOGLE FIND HUB APP

1. Update your Android device to the latest operating system. Activate Bluetooth.

2.Download Find Hub app.

3.Power on the new device and put it into pairing mode.

4.Unlock your phone and turn on the screen.

5.You will receive a notification on your phone prompting you to set up the new device.

6.Tap the notification and follow the on-screen instructions to complete the setup.

INTERNAL PAGE 4

FIND YOUR LOC8 VERSA UNIVERSAL

1. In "Find Hub" app, tap "Items".

LOC8 FINDER FOB 2 UNIVERSAL

2. Check your Fob's last known time and place.

LOC8 VERSA Universal

Near you right now

Battery OK

Find nearby

Play sound, get hints as you approach device

Play sound

Share device

WARNINGS

WARNINGS

Avoid exposing it to extreme conditions that may affect its functionality.

Keep LOC8 Finder Fob 2 Universal away from all heat and fire sources, including heating equipment, heaters, ovens, open flames, and direct sunlight.

Do not attempt to repair or disassemble the LOC8 Finder Fob 2 Universal equipment by yourself. Any unauthorized modification may result in damage or malfunction.

Avoid using or storing LOC8 Finder Fob 2 Universal in environments with high humidity or temperatures exceeding 60°C (140°C) to prevent potential failures.

Responsibly dispose of LOC8 Finder Fob 2 Universal products following the local government's regulations on waste disposal to minimize environmental impact.

To use the Apple Find My app to locate this item, the latest version of iOS, iPadOS, or macOS is recommended. The Find Items app on Apple Watch requires the latest version of watchOS.

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.

Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, macOS and watchOS are trademarks of Apple Inc. iOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

Find Hub network requires location services and Bluetooth to be turned on. Requires cell service or internet connection. Works on Android 9+ on select devices (tablets, phones, and laptops) and in certain countries for age-eligible users.

AU COMPLIANCE

AUSTRALIAN WARRANTY

Warranty Period

12 Months

Warranty Terms

ALOGIC Corporation Pty Ltd warrants this product to be free from defects in materials and workmanship for the warranty period stated above from the date of purchase, provided the product is used in accordance with the accompanying recommendations and instructions.

Exclusions

This warranty no longer applies where any defect results from alteration, accident, misuse, abuse or neglect of the product.

How to Make a Claim

Please retain your receipt as proof of purchase and return the product with the receipt to your place of purchase to make a warranty claim.

This warranty is in addition to your rights under the Australian Consumer Law.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

For New Zealand customers, this warranty is in addition to statutory rights under New Zealand legislation.

ALOGIC Corporation Pty Ltd
Level 14, 140 William St Melbourne VIC Australia 3000

INTERNAL PAGE 5

CHARGING YOUR LOC8 VERSA WALLET UNIVERSAL

To charge your LOC8 VERSA Wallet Universal, connect the charging cable to the LOC8's USB-C port (as shown in the image). The LED status light will glow orange if the tracker is charging and green if the tracker is fully charged.

Rechargeable battery lasts up to 6 months on a full charge.

LED Status	Device Behaviour
Orange	Charging
Green	Fully charged

INTERNAL PAGE 6

CHECKING BATTERY LEVEL

When LOC8 Journey LOC8 VERSA Wallet Universal's battery level is low, you will receive a reminder notification on your phone, via the Google's Find Hub or Apple Find My app. You can also check the battery level of the LOC8 VERSA Wallet Universal in the relevant app.

USE LOST MODE (FOR APPLE)

1. If you can't find your wallet, open the Find My app on your iPhone.

2. Click the 'Items' icon at the bottom of your screen.

3. Tap on your LOC8 VERSA Wallet Universal icon displayed on your screen.

4. Scroll down to "Enable Lost Mode".

5. Tap "Continue".

6. Enter your required contact details to finalise "Lost Mode".

Your Journey LOC8 VERSA Wallet Universal will stay linked to your Apple ID, unless you unpair it. If someone finds your item while it is in Lost Mode, they can use their iPhone or any NFC-capable device to reach you.

INTERNAL PAGE 7

TROUBLESHOOTING (FOR APPLE)

This device can be reset if you have trouble pairing the wallet with your iPhone, or if you want to unpair it and give it to someone else.

To reset:

1. Hold down the tracker button for 10 seconds.

2. Release the button once you hear the ringtone sound five times.

3. You can repeat this step in "SETUP WITH APPLE'S FIND MY APP" to pair the wallet with your iPhone.

INTERNAL PAGE 8

TROUBLESHOOTING (FOR GOOGLE)

Power On: Click the tracker button on the LOC8 device 2 times, the device will "beep" on the second click, indicating it is now powered on.

Identification Mode: When you find an unknown LOC8 device, hold it to your phone and quickly press the device's tracker button once and listen for a "beep". The LOC8 device's identification information will display on your phone.

Reset: While powered on, press the LOC8 device's tracker button and hold for 3 seconds, you will hear a "beep". Continue to hold for 7 more seconds, until you hear another 5 "beeps", after this, quickly release the tracker button and there will be two more "beeps" indicating the reset is complete.

Power Off: Press and hold the LOC8 device's tracker button for 3 seconds and release. The device will play the power off ringtone indicating the device is now off.

Re-Pairing Mode: Please unpair first, power off the LOC8 device, then power it on to re-pair if you want to switch to another device.

LAST PAGE

Journey LOC8 VERSA Wallet Universal

The best of both worlds – your phone and wallet, together.

Hold 5 cards

Built-in Tracker

Compatible with iPhone 12 onwards

Adjustable Stand

Easy Card Access

Money Clip Holder

RFID Protection

USB-C Rechargeable

JR-NY

COMPLIANCE STATEMENTS

FCC Compliance Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
• Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and receiver.
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
• Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Responsible Party - U.S. Contact Information
ALOGIC USA LLC
37524 Marsten DR,
Newark, CA 94560, USA

EU Declaration of Conformity

This device is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. All essential radio test suites have been carried out. This restriction will be applied to all Member States of European Union.

The device complies with RF specifications when the device used at 20cm from your body.

Hereby, ALOGIC Corporation declares that this product is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following Internet address by clicking on the Compliance Documentation link:
<https://journeyofficial.com/>

ISED Caution:

Radio Standards Specification RSS-Gen, issue 5

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: This device may not cause interference.
This device must accept any interference, including interference that may cause undesired operation of the device.
RF exposure statement:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.
Cet appareil contient des émetteurs / récepteurs exempts de licence conformes aux RSS (RSS) d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes:
Cet appareil ne doit pas causer d'interférences.Cet appareil doit accepter toutes les interférences, y compris celles susceptibles de provoquer un fonctionnement indésirable de l'appareil.

Déclaration d'exposition RF:
L'appareil a été évalué pour répondre aux exigences générales d'exposition aux RF. L'appareil peut être utilisé dans des conditions d'exposition portable sans restriction.

SIDE 2