

L710S投影仪说明书

尺寸：110*140mm

128克铜板纸

黑白印刷

miroir

1080P FHD VIDEO PROJECTOR

Quick Start Guide

FCC WARNING STATEMENT

FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.
- (3) The manufacturer is not responsible for any radio or tv interference caused by unauthorized modifications or changes to this equipment. Such modifications or changes could void the user's authority to operate the equipment.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning:


The device has been evaluated to meet general RF exposure requirements.

RF Exposure Information:


This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

Your Miroir Wireless Projector with SYNQ TV




Included in the Box



Projector



Remote Control




Power Cable



User Manual

Learn More

To learn more about your Miroir drivvplay and its operations, to review specs, and find answers to frequently asked questions, please visit: **www.miroirusa.com/L710S**



BATTERIES STATEMENT AND NOTICES

Remove the battery compartment cover on the back of your remote by carefully sliding it open. You can then lift the battery cover away. Fit the correct batteries, referring to the polarity markings. Finally, replace the lid.

NOTE:

- When you receive the product and find that the remote control batteries are swollen or softened, please do not use it before you change it.
- Do not expose the batteries to excessive heat, such as the sun or fire.
- Make sure that batteries are installed with the correct polarity.
- Only the same or equivalent type batteries as recommended are to be used.
- Do not dispose of batteries to fire; batteries may explode or leak. Do not try to recharge a battery.
- Do not mix old and new batteries.
- Do not mix alkaline, standard(carbon-zinc), or rechargeable (ni-cad,ni-mh, etc.) batteries.


QUICK START

1



① Plug the power cord into an outlet

2




② Install batteries in the remote control

3




③ Turn on
Press the Power Button to turn on the projector

4



④ Automatically focus to adjust the picture clearer



⑤ Connect your remote control to the projector via Bluetooth

7



⑦ Back to "home" interface, select the video platform you want to log in

8



⑧ Turn off
Press the Power Button and choose **Yes** to turn off the projector



⑥ Connect to the Network


Operation guidelines:

1. To prolong the projector's lifespan, we highly recommend unplugging the power cable entirely if you're not using the projector for an extended period.
2. After plugging the projector into an AC outlet, it takes 10 seconds for the system to detect power on, so please wait for the system to come on.
3. The bottom of the projector has a cooling vent; please ensure any objects do not block it.

PROJECTION DISTANCE & SIZE

The recommended projection screen size is 80 - 120 inches.

To improve your viewing experience, ensure you have a room where you can control the lighting. These factors work together to provide a visually stunning and immersive viewing experience.



Note: The above data are for reference only, please refer to the actual measurement.


PROJECTION MODE

If you want to hang the projector to the ceiling, a projector mount will be needed.

If you want to project in different way, please select corresponding mode in the setting page.




FRONT TABLE



FRONT CEILING



REAR TABLE



REAR CEILING


INPUT SOURCE

Press  on the remote to enter the interface of the Input Source.


A. HDMI Connection

Connecting Your Projector with a Cable


Connect To Your Laptop HDMI



Connect To Your Device




Connect To Your MacBook USB-C




IMPORTANT! Not all USB - C cables will support video.

Connect To Your Apple Device Lightning




Connect To Your Streaming Stick HDMI



B. USB Connection

Plug a USB stick into the port and play movies, or share pictures.



BLUETOOTH SETTING

A. Bluetooth Setting

1. Go to **Settings** > **Bluetooth Setting**
2. Turn the Bluetooth Connection on and search for nearby Bluetooth devices.
3. Choose correct Bluetooth device to connect.

NOTE:

1. Due to compatibility issues with the Bluetooth protocol, some brands of Bluetooth speakers may not support connection to our projectors. If you have such an issue, feel free to let us know.
2. If you want to connect your headphone/ speaker to an audio port, please disconnect the Bluetooth audio device from the projector first.

B. Bluetooth Remote Control

1. Go to Setup > (Bluetooth Settings) > (Bluetooth (On)) > (Scan for device)
2. Place the remote control close to the projector, press and hold the "LEFT" and "RIGHT" on the remote control until the indicator light flashes quickly and shows up "BT- Remote Control" and choose "BT-Remote Control" and enter "OK" button.
3. After being connected, the operation of the remote control will be more sensitive and the coverage will be broader.




Note:

- (1) You can connect other Bluetooth devices Once the Bluetooth remote control is connected.
- (2) Please keep the projector's Bluetooth ON to ensure the Bluetooth remote can connect and work normally.

C. As A Bluetooth Speaker

Press **(BT)** button on remote control, select **(Bluetooth Speaker)** , and the projector can be used as a Bluetooth speaker.



PROJECTION SETTINGS

Adjust the Projector Image

Focus(under Settings)

By default, the auto focus model of the projector is enabled, allowing it to quickly detect and adjust to the optimal clarity of the screen when it is turn on, or you can manually adjust the picture clarity by Press the remote - button and + adjust the picture clarity

Keystone (under Settings)

The projector will auto keystone to 4-points, or you can manually adjust under settings

Zoom (under Settings)

Depending on your projector's distance from the wall, use the zoom feature to adjust the image size, can be zoom out to 50% of full size, default is 100% (no zoom)

Connecting Your Projector Wirelessly WIFI

- Connect the L710S to your WIFI network. Open Settings, and select WIFI and follow the instructions.
- Update the projector if prompted
- Open the SYNQ TV App
- Connect to the available streaming services (not included); a streaming service subscription is required to stream with SYNQ TV
- Once you've logged into your streaming account, start streaming!

Screen Mirroring

- YouTube, TikTok and other non-DRM-controlled applications will support screen mirroring.
- Connect your iOS, Android, Laptop, or Tablet wirelessly via the device mirroring option.
- Netflix and other DRM-regulated applications will not support screen mirroring.
- Local photos and videos you have taken support Screen Mirroring.

NOTE:

1. Please ensure the projector and your iOS device have been connected to the same Wi-Fi; if there is no Wi-Fi, please open a hotspot on your iOS device and connect the projector.
2. Please remember to open the Wi-Fi function on your Android device. But it is not necessary to connect to any Wi-Fi router.

CEILING INSTALLATION

How to Mount a Projector on the Ceiling?

Mounting a projector on the ceiling is a great way to make your home theater or presentation space look professional and save valuable floor space. Follow these steps to mount your projector securely.

Tools you'll need	1. Mount	5. Screwdriver
	2. kit Ladder or step ladder	6. Tape measure
	3. Drill	7. Pencil (for marking)
	4. Wrench or Allen wrench (depending on the mount)	

Note: None of the above tools are included in the accessories, and you need to purchase a ceiling mounting bracket separately.

Step 1: Determine the position of your projector to the screen
Position your projector and screen so that the throw distance is sufficient for your needs. The lens should be between the upper third and upper half of the screen for optimal picture clarity. Mark the position with a pencil.

Note: Ensure there are no obstructions blocking the projector's beam, and that there is an available power socket nearby.

Step 2: Attach the mount to the projector
Flip the projector upside down and attach the mounting bracket according to the instructions included with the mount.

Step 3: Attach the mount and projector to the ceiling
Ensure the mounting bracket can attach along a ceiling joist, then make marks for screw holes and drill preliminary holes. Use suitable screws to securely fasten the bracket to the ceiling. Check that it is securely fastened to the ceiling by trying to wiggle it around.

Step 4: Aligning the projector
Adjust the zoom, focus, pitch, and yaw of the projector as necessary to ensure a properly aligned image with the screen.

Step 5: Connect Power
Please plug in the power cord to both the projector and a nearby power outlet. Once the connection is confirmed, turn on the projector to test the connection.

Step 6: Final adjustments
Make any final adjustments to the image and lock down the mount to prevent movement.

By following these steps, you can create a stunning and functional projection system.

SPECIFICATION

Display Technology	LCD
Light Source	LED
Resolution	1080P
Input Signal	HDMI / USB
Aspect Ratio	16:9
Focus	AUTO/Manual
Keystone	AUTO + 4P/4D + Manual
Speaker	2*5W
Bluetooth	Version 5.0
Power Input	100-240V
Power Output	95W
Photo Format Supported	JPEG/PNG/BMP/GIF
Audio Format Supported	mp3/ape/flac/ogg/aac/wav/amr/mp2
Video Format Supported	mkv/webm/mp4/mov/ts/trp/tp/mpeg/mpg/vob/dat
Operating Temperature	0°C ~ 38°C / 32°F ~ 100.4°F
Storage Temperature	-20°C ~ 45°C / -4°F ~ 113°F
Temperature Protection	Over 80°C temp auto-shutdown
Ports	HDMI / USB / 3.5mm Audio
Unit Dimension	207.69*149.93*174.42mm

TROUBLE SHOOTING



Remote Control not working

- Make sure the batteries are installed with the correct polarity and don't need to be replaced.
- Make sure the remote is connected to Bluetooth.

A



Blurry image

- Use the manual focus to adjust the image
- The screen or wall material may affect the quality of the image as well.

A



No Sound

- Check to make sure the mute button was not pressed.

A



Projector shut down

- Make sure the bottom vents are not blocked which would cause overheating and shutdown Image is displayed incorrectly
- Make sure the correct "projection mode" is chosen in under the "settings" "image mode".

A



Screen mirroring not working

- Due to DRM control, some videos cannot be mirrored from your device to the projector. e.g. Netflix and other DRM controlled content.

A



Black Spot on screen

A

-Wipe the lens to remove any dust, use a clean cloth.



Missing accessories

A

-Contact Miroir Support at www.miroirusa.com for assistance.

FCC INFORMATION

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

1) This device may not cause harmful interference, and 2) This device must accept any interference received including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Caution: To maintain compliance with the FCC's RF exposure guidelines, place the product at least 8 inches from nearby persons.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This unit generates, uses, and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try and correct the interference by one or more of the following measures: • Reorient or relocate the receiving antenna. • Increase the separation between the equipment and receiver. • Connect the equipment to an outlet on a circuit different from that to which the receiver is connected. • Consult the dealer or an experienced radio/TV technician for help. Shielded cables must be used with this unit to ensure compliance with the Class B FCC limits.

Caution: The radiated output power of the Wi-Fi technology is below the FCC radio frequency exposure limits. Nevertheless, it is advised to use the wireless equipment in such a manner that the potential for human contact during normal operation is minimized.

ONE (1) YEAR LIMITED WARRANTY

USA & Canada Only

Miroir ("Miroir") warrants to you, the original retail purchaser ("Consumer"), that this product ("Product") will under normal use operate substantially in accordance with the accompanying documentation for a period of one (1) year from date of original purchase. Consumer's sole and exclusive remedy, and Miroir's sole and exclusive responsibility under this warranty will be, at Miroir's option, either to repair or replace the defective Product during the one (1) year limited warranty period so that it performs substantially in accordance with the accompanying documentation on the date of your initial purchase. The foregoing warranty is limited and is not applicable to: (i) normal wear and tear; (ii) defects or damage caused by misuse, accident (including without limitation collision, fire and the spillage of food or liquid), neglect, abuse, alteration, unusual stress, modification, improper or unauthorized repair, installation, wiring, or testing, improper storage, use in an unapproved device or if the serial number has been removed; (iii) use not in accordance with the documentation; and (iv) damage caused by the equipment with which the Product is used.

To obtain warranty service for any Product that is subject to the foregoing warranty, Consumer must contact Miroir, provide proof of purchase and a description of the issue. Consumer shall bear the cost of returning the Product for repair or replacement under this limited warranty. Any Product returned without proof of purchase will not be honored under this limited warranty.

The limited warranty extends only to Consumer and is not assignable or transferable to any subsequent purchaser or user. THE LIMITED WARRANTY SET FORTH ABOVE IS PROVIDED IN LIEU OF ALL OTHER WARRANTIES AND MIROIR HEREBY DISCLAIMS ALL OTHER WARRANTIES OF ANY KIND, WHETHER EXPRESS, IMPLIED, STATUTORY OR OTHERWISE, INCLUDING WITHOUT LIMITATION ANY WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR USE OR PURPOSE, NON-INFRINGEMENT, QUALITY AND TITLE. MIROIR DOES NOT WARRANT THAT THE PRODUCT IS ERROR FREE OR THAT IT WILL FUNCTION WITHOUT INTERRUPTION.

To the extent Miroir may not, as a matter of applicable law, disclaim certain implied warranties, the duration of any such implied warranty shall be limited to the shorter of the one (1) year limited warranty period or the minimum time period permitted under such law. Some states do not allow limitations on the duration of implied warranties, so the above limitation may not apply to you. This limited warranty gives you specific legal rights, and you may also have other rights that vary from state to state.

IN NO EVENT WILL MIROIR BE LIABLE FOR ANY SPECIAL, INDIRECT, INCIDENTAL, PUNITIVE OR CONSEQUENTIAL DAMAGES OF ANY NATURE WHATSOEVER INCLUDING BUT NOT LIMITED TO LOSS OF PROFITS OR REVENUES, LOSS OF DATA, LOSS OF USE OF THE PRODUCT OR ANY ASSOCIATED EQUIPMENT, COST OF ANY REPLACEMENT GOODS OR SUBSTITUTE EQUIPMENT, LOSS OF USE, CLAIMS OF ANY THIRD PARTIES, OR ANY OTHER DAMAGES ARISING FROM MIROIR'S BREACH OF THIS LIMITED WARRANTY OR THE USE OF THE PRODUCT, REGARDLESS OF THE FORM OF ACTION WHETHER IN CONTRACT, TORT (INCLUDING NEGLIGENCE) OR ANY OTHER LEGAL OR EQUITABLE THEORY, EVEN IF MIROIR HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. IN NO EVENT WILL MIROIR'S TOTAL CUMULATIVE LIABILITY EXCEED THE PRICE PAID BY CONSUMER FOR THE PRODUCT.

Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. If you have any questions concerning this statement of limited warranty please email Miroir at miroirusa.com for any more questions.

One (1) Year Limited Warranty

European Union (EU)

Miroir ("Miroir") warrants to you, the original retail purchaser ("Consumer"), that this product ("Product") will under normal use operate substantially in accordance with the accompanying documentation for a period of one (1) years from date of original purchase. Consumer's sole and exclusive remedy, and Miroir's sole and exclusive responsibility under this warranty will be, at Miroir's option, either to repair or replace the defective Product during the one (1) years limited warranty period so that it performs substantially in accordance with the accompanying documentation on the date of your initial purchase. The foregoing warranty is limited and is not applicable to: (i) normal wear and tear; (ii) defects or damage caused by misuse, accident (including without limitation collision, fire and the spillage of food or liquid), neglect, abuse, alteration, unusual stress, modification, improper or unauthorized repair, installation, wiring, or testing, improper storage, use in an unapproved device or if the serial number has been removed; (iii) use not in accordance with the documentation; and (iv) damage caused by the equipment with which the Product is used.

To obtain warranty service for any Product that is subject to the foregoing warranty, Consumer must contact Miroir, provide proof of purchase and a description of the issue. Consumer shall bear the cost of returning the Product for repair or replacement under this limited warranty. Any Product returned without proof of purchase will not be honored under this limited warranty.

The limited warranty extends only to Consumer and is not assignable or transferable to any subsequent purchaser or user. THE LIMITED WARRANTY SET FORTH ABOVE IS PROVIDED IN LIEU OF ALL OTHER WARRANTIES AND MIROIR HEREBY DISCLAIMS ALL OTHER WARRANTIES OF ANY KIND, WHETHER EXPRESS, IMPLIED, STATUTORY OR OTHERWISE, INCLUDING WITHOUT LIMITATION ANY WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR USE OR PURPOSE, NON-INFRINGEMENT, QUALITY AND TITLE. MIROIR DOES NOT WARRANT THAT THE PRODUCT IS ERROR FREE OR THAT IT WILL FUNCTION WITHOUT INTERRUPTION. To the extent Miroir may not, as a matter of applicable law, disclaim certain implied warranties, the duration of any such implied warranty shall be limited to the shorter of the one (1) years limited warranty period or the minimum time period permitted under such law.

IN NO EVENT WILL MIROIR BE LIABLE FOR ANY SPECIAL, INDIRECT, INCIDENTAL, PUNITIVE OR CONSEQUENTIAL DAMAGES OF ANY NATURE WHATSOEVER INCLUDING BUT NOT LIMITED TO LOSS OF PROFITS OR REVENUES, LOSS OF DATA, LOSS OF USE OF THE PRODUCT OR ANY ASSOCIATED EQUIPMENT, COST OF ANY REPLACEMENT GOODS OR SUBSTITUTE EQUIPMENT, LOSS OF USE, CLAIMS OF ANY THIRD PARTIES, OR ANY OTHER DAMAGES ARISING FROM MIROIR'S BREACH OF THIS LIMITED WARRANTY OR THE USE OF THE PRODUCT, REGARDLESS OF THE FORM OF ACTION WHETHER IN CONTRACT, TORT (INCLUDING NEGLIGENCE) OR ANY OTHER LEGAL OR EQUITABLE THEORY, EVEN IF MIROIR HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. IN NO EVENT WILL MIROIR'S TOTAL CUMULATIVE LIABILITY EXCEED THE PRICE PAID BY CONSUMER FOR THE PRODUCT.

If you have any questions concerning this statement of limited warranty please email Miroir at miroirusa.com for any more questions.

miroir

www.miroirusa.com

L710S.07.2023

© 2023 Miroir USA, LLC. All rights reserved. Miroir and the Miroir Logo are owned by Miroir USA, LLC. All other trademarks are the property of their respective owners. Miroir USA, LLC assumes no responsibility for any errors that may appear in this manual. Information contained herein is subject to change without notice.