




37.384 mm



05. 06. 01.

Innovation, Science and Economic Development (ISED) Canada Regulatory Compliance
CAN ICES-310-MMS-310

This device complies with Industry Canada license-exempt RSS standards. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Radiation Exposure Statement:
This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment.

Declaration d'exposition aux radiations:
Cet équipement est conforme aux limites d'exposition aux rayonnements IC établies pour un environnement non contrôlé.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

For more information on FCC compliance, please go to www.fcc.gov.

You assume all risk and responsibility in relation to the installation and performance of Keypad and any third party components and services used in relation to the lock.

Please follow these suggestions and safeguards to decrease the chances of damage to your Level Keypad and to lessen the risk of harm or injury:
- Use Keypad for its intended purposes only.
- Do not crawl, perforate, drop, throw, or try to deform Keypad or battery.
- Do not short external contacts or circuits, expose your Keypad or battery to water, liquids, or open flames or to substances, or dispose of them in fire, solvents, or water.
- Do not use Keypad or battery if they aren't working properly or have been damaged or cracked.
- Dispose of Keypad and battery in accordance with local requirements.
Battery life varies with usage.
Caution: This product comes with small parts and parts with sharp edges that may cause injury or create a choking hazard. To avoid injury or damage, keep away from children.
Revision 1.0

Welcome home.

90.603 mm



02. 03. 04.

A.

C.

D.

E.

F.

What you need:

1. Level Bolt, Level Lock, or Level Lock - Touch Edition
2. Phillips screwdriver
3. Compatible iOS® or Android™ phone

Box contents

- A. Level Keypad
- B. Mounting bracket
- C. 2 AAA batteries
- D. 2 Screws
- E. 2 Wall anchors
- F. Double-sided tape

Follow in-app instructions

Scan this QR code and use the Level app to install your Level Keypad.

QR Code
15.25 mm

