

	TRACK#	25289	PRINTED COLORS				NON-PRINTED COLORS			
		05.09.2019		CYAN		MAGENTA		GREEN		OUTLINE
				YELLOW		BLACK				
				WHITE		GREY				
				FMS 425		FMS 200				
										
										
										
MX2JGYC										
BJ Holiday Mesh Snowman										
ROUND										
	MBD.									
	uniquely qualified.									

size: 19.68 x 17.32 INCH



100%
MONEY-BACK
GUARANTEE



47 Inch Pre-Lit SNOWMAN

FOR INDOOR OR OUTDOOR USE
PRE-LIT WITH 50 WARM WHITE
LED LIGHTS

UL LISTED OUTDOOR ADAPTOR
WITH 5FT CORD

INCLUDES 6 HOURS ON/
18 HOURS OFF TIMER

EASY ASSEMBLY

THIS IS NOT A TOY.
FOR DECORATIVE PURPOSES ONLY.
LEARN MORE AT
BerkleyJensen.com



Distributed by:
BJ's Wholesale Club
25 Riverwalk Drive
Westborough, MA 01581
Distributed 1/2020 0341 1204
Made in China




INSTRUCTION MANUAL

47 INCH PRE-LIT SNOWMAN

ARTICLE # 217720


Thank you for purchasing the 47 inch Pre-Lit Snowman. This product is not a toy.
For decorative purposes only. Please read these instructions entirely before using.
Note: Use this product only with the transformer supplied.
Do not connect directly to a main outlet without the transformer.
LED bulbs in this set are not replaceable.



1. Take the snowman out of the package.
Assemble the two half parts of the body by inserting the tubes or hook through the circle on each side as shown in the picture above (from bottom to top).



2. Now the body will be stable.



Connect the hook (located on the two opposite side of the body) to make the whole body steady.

3. Put the snowman's upper body onto the bottom one.



4. Put the snowman's hat and arms on the body.



5. Assembly is now complete. If using outdoors on a lawn, secure the snowman by inserting the 4 lawn stakes through the supports and into the soil.