LASEREFFECKER

L1 Pro 使用说明书



重要提示 抽出三脚架调节高度(焦距),确保调节激光发射镜片与被雕刻物体表面距离为**200mm**(用赠送的木尺测量),焦距尺寸调节不对会出现雕刻不均匀,或者雕刻无痕迹的情况。

产品及配件清单(标配)



磁吸式可折叠亚克力遮光保护板(需另外购买)

购买地址: www.laserpecker.net



产品介绍

基础款

- 主机+三脚架(标配)
  1.type-c接口（外部电源接入）
  2.蓝牙连接指示灯
  3.电源开关
  4.蓝牙连接指示灯
  5.激光发射孔
  6.三脚架安装孔

专业款

- 自动对焦电动支架(需另外购买)
  购买地址: www.laserpecker.net
  1.开关机/自动对焦按键
  2.手动调节上升按键
  3.手动调节下降按键
  4.主机供电接口
  5.红外测距视窗
  6.风扇（用于吹散烟雾）
  7.type-c接口
  （外部电源接入）



豪华款

- 烟雾过滤系统保护罩(需另外购买)
  购买地址: www.laserpecker.net
  1.主机供电接口
  2.开关机键
  3.type-c接口
  （外部电源接入）
  4.风扇排风口
  5.可过滤蓝光半透明保护罩



基础款 组装操作示意图



重要提示

抽出三脚架调节高度(焦距)。
确保调节激光发射镜片与被雕刻物体表面距离为200mm(用赠送的木尺测量)。
距离不准确会导致雕刻不均匀,
或者雕刻无痕迹的情况。

专业版 组装操作示意图



重要提示

客户最关注了文字测距方案,
受被测物体颜色大小、表面光泽等因素影响,
测距准确度会存在差异。为确保雕刻效果良好,
以下情况请用官方赠送的亚克力黑板板辅助测距:

1. 物体被测面积小于100*100mm。
2. 被测物体表面凹凸不平。
3. 被测物体表面有明显的方点式结构
   类似布料、海绵等材质
4. 透明材料、高反光材料、纯黑色材质。

豪华款 组装操作示意图

重要提示

1. 保护膜为适合放入厚度小于10mm的物品
2. 厚度大于10mm的物品请用三面保护方式摆放

操作说明

1.下载APP

- 方式一：在华为应用、应用宝、苹果商店等应用市场搜索“激光喷木刀”来下载。
- 方式二：通过右侧二维码选择安卓/ios下载APP应用程序。
- 方式三：在官网 www.laserpecker.cn 下载APP应用程序。
- 注意：下载安装APP后，请仔细阅读APP内的警告及注意事项，以确保能够正常使用本产品。

扫码下载APP

2.接入电源

连接一个接口为TYPE-C的5V/2A以上的适配器，建议使用本产品自带的电源适配器或者和GC2.0认证的充电器，带给电源请务必充分的电量，至少是需要。

3.连接蓝牙

接入电源后，指示灯开始以蓝色色，表示设备处于蓝牙配对状态，在app上点击连接蓝牙，指示灯变成常亮蓝色，表示连接成功。

4.选择雕刻内容

在APP主页选择需要雕刻的内容并雕刻

技术支持

本产品自们支持全球线上技术支持服务，若您在使用过程中遇到任何的问题。

请Email至 laserpecker@hngin.com，我们将会尽快回复您。

制造商： 深圳市镭科科技有限公司

电 话 ：+86 0755-28913864

产品规格书

尺寸	65*61*53mm
重量	190g
激光源	500 mW SHARP 405 nm （光斑直径0.1*0.1mm）
激光源输功率比	功率输出范围可设定1%-100%
光组	铝合金阳极氧化
支框市轴	蓝牙4.0
支持文档格式	G-Code和jpg
APP连接方式	蓝牙连接
APP操作系统	支持iOS 9.0+/Android 5.0+
电源输入	type - c (5V，2A)
工作温度范围	0℃ - 65℃
工作湿度范围	5℃ - 80℃（非凝结雾）
安规认证	IEC 60825-1（激光一级安全认可） CE,RoHS,FCC,FDA CDRH认证 IEC 60825-1（澳大利亚）TELEC(MIC)
专利申请	七项专利

免责声明

感谢您购买激光雕木刀。本文将提及的内容成系列您的安全及合法权益与责任。使用本产品前，请仔细阅读本文以确保对产品有了正确的认识。

关切实遵守使用照本文说明节警告提示指导，可帮助您对正确周围人员带来伤害，切节能LaserPecker保障服务性能质量。

一旦使用者产品，即视为您已经仔细阅读完本声明与警告信息，理解，认可和接受本声明的全部条款的内容。

您承担使用本产品与相关带来的结果与全部责任。

您承诺仅处于正常目的使用本产品，并且同意本条款以及隐内利益（Hingin）制定的任何相关条例，政策和指南。我对将本为（LaserPecker）对于直接或者间接使用本产品的造成的任何，包括但不限于因遵循任何指令而造。

使用者应避免在结束个用于本文提及的所有安全指南。

版权说明

本文与及所涉及的硬件、驱动程序、控制指导和APP软件以及本说明文档的版权均为（深圳市镭科科技有限公司（LaserPecker）所有。（以下均简称一或用以代名称或称“镭科科技”），如果涉及，拥有对已侵权。请勿任何形式，https://www.laserpecker.cn 软件最新的产品信息。

LaserPecker是镭科科技注册的商标，如非授权，严禁盗用。

如LaserPecker用户个人使用外，严禁任何未公开的和已经发布以任何目的复改和传播本软件的部分或者，如有违反，镭科科技将保留对其使用法律责任的权利。

本文出现的产品名称，品牌等，均为其所属公司的商标或注册商标。

注意事项

1 开始安装LaserPecker前，请优先检查设备完好，激光镜面干净无污损。

2 安装前您，开始使用LaserPecker之前，请先参照使用说书与固定好主机，三脚架，木尺，激光镜片，并安装好各固定功能的配件或支撑物件，避免因安装不当导致等物损失。

3 请务必使用使用说书与书指示的电源为激光电源种类（规格为5V/2A的适配器）切设备供电。

4 在启动激光开始雕刻之前，请确保做好安全防护措施，例如可以通过佩戴护目镜以及面向雕刻，佩戴防护面以及面向激光源的皮肤，特此不给予的物品以防止激光照射在此处产生更对他伤，特别注意使用反射物品，以防引发火灾。

5 在激光发出过程中物品的时候，切勿移动设备，以免导致设备因自性保护而停止工作，甚至因被雕刻物品被过快燃影响到雕刻作品的最终效果。

6 如果一定要移动设备或被雕刻物品，请先开始雕刻前或者把总雕刻完成后再操作，切勿在激光工作过程中移动设备或者物品。

7 由于激光具有一定危险性，因此切勿让未成年人，残疾和不具备自我保护意识的人员近距工作中的设备。

8 使用本产品雕刻物品前，请带佩戴雕刻物体表面光的情况等中不会吸放有毒有害的气体，以免发生中毒事故。

9 如果雕刻过程中发现有异味或者产生，请使用风扇自时散散或者放置在空敞通风的地方换气。

10 使用本产品雕刻物品前，要带佩戴雕刻的物品是否具有安全材械蛋白材物质，这类物品要特别注意安全防护（建议阅读相关材料雕刻区域求展后再操作）

11 切勿使用LaserPecker直接用于人体或者宠物皮肤，谢谢，以免造成不可逆转的损伤。

12 您可使用应用LaserPecker使用说的书中的 了解了如何正确地操作本产品，及获取免费声明内容。

警告

请务必使用产品之前仔细阅读本文档，了解您的合法权益，责任和安全须知。

1 警告，在操作LaserPecker设备之前，请务必认真完读本操作内容，产品保守操作规程。

2 警告，本设备使用激光发光源（镜面对镜材），该激光辐射可能会引起以下事故：
1）点燃周边的易燃物；2）激光不当过程中，因激光直射对患者的手指可能由产生灼伤的情况与事气体，有毒气体可能又导致的产生伤害，特别是对眼睛的伤害，可能会导致永久性的视力损伤，甚至是失明的情况。因此设备使用前，并佩戴防护用具（如护目镜，保护镜，防护面罩或者防雾镜材等），严禁在工作过当设备周围围有易燃易爆物，易爆物品，同时务必保持工作环境通风良好。

3 警告，激光工作过程可能存在风险，用户应确保考虑被雕刻的物体材质适应激光的工作。

4 警告，设备工作电压5V2A，应使用合适规格的适配器供电，严禁超负荷使用或电开裂时试外，日在客户选配原装外壁带的电源（如因连线）受破损物体或外力的碰撞下，不可以插上电源，否则会发生非常危险的触电风险。

5 警告，客户应向适配雕刻品质，请带佩戴雕刻物体表面光的情况等中不会吸放有毒有害的气体，以免发生中毒事故。

6 如果雕刻过程中发现有异味或者产生，请使用风扇自时散散或者放置在空敞通风的地方换气。

9 使用本产品雕刻物品前，要带佩戴雕刻的物品是否具有安全材械蛋白材物质，这类物品要特别注意安全防护（建议阅读相关材料雕刻区域求展后再操作）

10 切勿使用LaserPecker直接用于人体或者宠物皮肤，谢谢，以免造成不可逆转的损伤。

11 因LaserPecker激光组件功率有限，所不能直接对金属、玻璃、陶瓷和石头等非常坚硬的材质进行雕刻

12 您可使用应用LaserPecker使用说的书中的 了解了如何正确地操作本产品，及获取免费声明内容。

保修条款-注意事项

- 产品质保期限为一年，在人为造成的产品质量问题，在收货日的15日内享有免费售后更换的质量保障，收费日的15日后享保修期服务，只需支付快递费用。
- 针对非中国大陆地区销售的产品，请务必咨询当地销售渠道经销商商代理，因不同国家地区对家用激光雕刻机的安全及合法权益与责任，技术及售后存在存在较大差异，请务必咨询当地销售渠道，确保您的国家合地区销售的产品在您的国家地区享有当地的保修服务。
- 在非因我们科技导次保修服务，对正确的操作方法，因使用不当造成的产品损坏，我们科技将收取合理的维修费用，同时我们会保持工作环境通风良好。
- 任何更换或维修后的产品，维保有效产品新供的保修期限或与于更换后30天的保修，确认科技将给予再首年以右的次保。
- 激光设备为消耗易损品，如出现质，加工材质，加工环境高度概况，也不在保修范围内。
- 本注意与使用者解释，加工材质，加工环境高度概况，也不在保修范围内。

©2019 深圳镭科科技有限公司 版权所有

LASERPECKER

L1 Pro Instruction manual



Important notes: The tripod in the package is stretchable, please pull out enough length from the bottom of each foot, to ensure the distance from mirror plane of the laser to the surface of engraved item is 200mm. Otherwise the engraving may fail.

List of product and accessories (standard)



Magnetic absorption foldable acrylic light shield(to be purchased separately)

Purchase address:www.laserpecker.net



Product introduction

Basic

- Main machine + tripod (standard configuration)
  1.Type-C connection (external power connection)
  2.Blue connection light
  3.Power switch
  4.Blue connection light
  5.Laser emission mirror
  6.Tripod installation hole



Pro

- Auto-focus electric stand (to be purchased separately)
  1.On/off/auto-focus button
  2.Manual adjustment of up button
  3.Manual adjustment of down button
  4.Main machine power supply interface
  5.Infrared distance measuring window
  6.Fan (for blowing smoke)
  7.Type-c interface
  (external power supply access)



Deluxe

- Smoke filter system protective cover
  (to be purchased separately) purchase address
  1.Main machine power supply interface
  2.On/off key
  3.Type-c interface
  (external power supply access)
  4. Fan exhaust port
  5. Translucent protective cover capable of filtering blue light

Basic assembly operation diagram



Important notes:

Pull out the tripod to adjust the height (focal length) to ensure that the distance between the laser emitting mirror and the surface of the object to be etched is 200mm (measured with a free wooden ruler). Inaccurate distance will lead to uneven etching or no trace of etching.

Pro Assembly operation diagram



Important notes:

Assemble operation diagram, folded state, unfolded state, hinge, long press on / off, short press autofocus, power on, this product adopts optical distance measurement scheme, influenced by factors such as the size of the area of the object to be measured and the reflectivity of the surface, there will be differences in the effect of engraving on different objects, in order to ensure a good etching effect, please use the official reflective distance measuring plate to assist distance measurement by covering the object in the following cases: 1. The measured area of the object is less than 100*100mm 2. The surface of the measured object is uneven. 3. The surface of the measured object has a high shade-like structure, similar to cloth, sponge and other materials. 4.Transparent material, highly reflective material, pure black material.

Deluxe Assembly operation diagram

Important notes:

1、The protective cover is suitable for putting articles with thickness less than 10mm.

2、Use a tripod to sculpt items with a thickness greater than 10mm.

Operation instructions

1.Download app

- Option1.You can search "LaserPecker" in apple APP store, google play store and other app markets to get the APP.
- Option2.You can download the APP in a suitable way by using the following QR code.
- Option3.You can download APP application program at www.laserpecker.net
- Attention: After downloading and installing the APP, please read the warnings and precautions in the APP carefully to make sure the normal use of this product.

2.Connect the power

Supply and prepare a 5V/2A or more adapter with TYPE-C interface. It is recommended to use the power adapter provided with this product or charger with QC2.0 or more certification, mobile power supply, or other forms of power supply, as shown in the following schematic diagram.



3.Connecting Bluetooth

After connecting Bluetooth to the power supply, the indicator light starts flashing blue, indicating that the device is in a Bluetooth pairing mode. Click Connect Bluetooth on app, and the indicator light turns into a constant bright blue, indicating successful pairing.

3.Select the etching content

Select the etching content and select the content to be etched on the app homepage to start etching.

Technical Support

We support global online technical support services for this product. If you encounter any problems in the use process,there are some ways you can get help form us:

You can leave messages on our website: https://www.laserpecker.net
or contact us by Facebook Page：@laserpecker
or official supportive email:laserpeckerlin@gmail.com

Instruction manual

Size	65*61*153mm
Weight	190g
Laser source	10+1*4 5W/7.4V 40.5nm Blue DUAL Laser 10+1*4 5W/7.4V 455nm Blue Laser Module（150mm）
Laser source output power	Power output range can be set 1%-100%
Appearance	Anodizing of aluminum alloy
Space	grid
File transfer	Bluetooth 4.0
Supporting document formats	G-Gode and jpg
APP Connection mode	Bluetooth connection APP
operating system	Support IOS9.0 + / Android5.0 +
power input	type-c (5V, 2A)
operating temperature range	0℃ ~ 45℃
safety certification:	ICE：60825-1 (laser level) 1 safety specification), CE, ROHS, FCC, FDA CDRH registration, IEC：60825-1 (laser level 1), TELEC(MIC)
patent application	Seven patents

Laser Warning

1. Warning: Before operating LaserPecker, please read this operation manual carefully and strictly abide the operation specifications.

2. Warning: Class IV Laser (Intense Laser Radiation) is used in this equipment, which may cause the following accidents:

- Ignition of flammable materials in the surroundings.

- Other radiation, harmful gas, toxic gas or odorous gas may be generated due to the different direct irradiation of the laser during the working process.

- Direct radiation of laser will cause human injury.

- Therefore, the operator must keep a distance from the equipment, and wear protective equipment (goggles, protective covers, protective clothing or fire fighting equipment, etc.). Staying flammable and explosive objects around the workbench and equipment is strictly forbidden. Keep the working environment with good ventilation.

3. Warning: There may be some risks in the laser working process. Please consider that the engraved object is suitable for laser operation.

4. Warning: The working voltage is 5V2A. Please power by a suitable adapter. Operating under overload or unstable voltage is strictly forbidden.
Please do not plug in if the ground wire of power supply (such as patch board) does not work effectively, otherwise there will be a dangerous risk of electric shock.

5. Warning: The product is equipped with precise and dangerous laser components. Please do not place the product near the electrical appliances with strong electromagnetic, which may cause electromagnetic interference to the product.
The laser will be flashed out when the laser source is turned on. Please avoid direct exposure to the laser beam.

6. Warning: Please do not place any irrelevant total reflection or diffuse reflection objects in the equipment, to avoid laser reflection on human bodies or flammable objects.

7. Warning: Please make sure that the emission caused by laser irradiation on the engraved objects meet local laws and regulations before using the product.

Guidelines for safe operation and attentions

1. Please check the equipment and make sure the laser mirror is clean and unfainted before the installation of LaserPecker.

2. Installation specifications: Please fix the main unit with the reference of operation manual (using accessories or supporting objects with fixed functions such as protective covers, tripods, electric brackets, etc.) before the operation of LaserPecker, to avoid any damage due to unstable placement.

3. Please supply power to the equipment according to the power and power (5A2V adapter) indicated in the operation manual.

4. Please make sure to take safety protection measures before turning on the laser to engrave, such as wearing goggles to prevent laser from damaging eyes, wearing protective clothing to prevent laser from damaging skin, removing irrelevant objects to prevent unnecessary damage due to laser irradiation, especially removing flammable and explosive objects to prevent fire.

5. Please do not move the equipment after the laser is turned on and engraving is started to avoid stopping working due to self-protection, or even the final effect of the engraved work due to the displacement of the engraved object.

6. Please move the equipment or the engraved object before or after the engraving if it has to be removed. Do not move the equipment or object during the laser work.

7. Please do not allow minors, children or those who are not self-protective to approach the equipment at work because of the risk of laser.

8. Please exam the engraved object will not release toxic and harmful gases to avoid poisoning accidents during the engraving process.

9. Please use a fan to blow the odorous smoke away during the engraving or operate in a spacious and ventilated place.

10. Please exam the total reflection or diffuse reflection characteristics of the engraved object before engraving, and pay more attentions to the safety protection (It is recommended to blacken the engraved area with a white board pen before engraving).

11. Do not use LaserPecker to directly irradiate the skins or eyes of people or pets to avoid irreversible damage.

12. Due to the limited power of LaserPecker laser components, it is not possible to engrave hard materials such as metals, glass, ceramics and stones (some materials can be engraved after being blackened with a whiteboard pen, heated with a transfer layer or processed with thermal transfer paper).

13. You have read the LaserPecker Operation Manual carefully and understand how to operate this product correctly, and agree the disclaimer.

Disclaimer

Thank you for purchasing the LaserPecker.

The contents mentioned s this article relate to your safety, legal rights and responsibilities.Please read this it carefully to ensure that you have the correct setting for the product before using.Any operation which is not abiding and following this manual and warning may cause injury to you or others around the product, or damage to LaserPecker or other surrounding objects.You are deemed to have read the disclaimer and warning carefully, understood and accepted all the terms and contents of this statement since you use the product.You will promise to undertake full responsibility for using this product and the possible consequences.You will promise to use this product for normal purpose, and agree the terms and any relevant regulations, policies and guidelines formulated by Ninghi Technology.

LaserPecker is not responsible for any damage, injury or any legal liability caused by direct or indirect use of this product.Users should follow all safety guidelines including, but no limited to, this article.

Copyright Statement

This article, and all the involved hardware, drivers, control programs and APP software, as well as the copyright of this documentation, are owned by Shenzhen Ninghi Tech Co., Ltd (Referred to as "Ninghi Tech"). Any update will be without prior notice.

Please visit the official website https://www.laserpecker.net for the latest product information.

LaserPecker is a registered trademark of Ninghi Tech. Any unauthorized use is strictly forbidden.Any falsifying and disseminating the contents of this operation manual for any purpose without our company's authorization is strictly forbidden, except the personal use of LaserPecker users. If there is a breach, Ninghi Tech will reserve the right to take legal responsibility for its use.

Warranty terms - Notes

- This product does not contain any user replaceable components. In any scenario, please do not attempt to disassemble or remove it,perpower by yourself or solve the problem.
- There is a very dangerous laser source component in the electronic shell of this product. When the main machine of LaserPecker is turned on and a beam is emitted, you must avoid direct exposure to the laser beam.
- This product meets the requirements of class II laser products. Under normal use, it operates in accordance with the specifications, otherwise it will cause damage to the skin or eyes. However, in the actual working state of laser pecker, for the sake of safety, it is still necessary to keep vigilance and avoid looking directly at the laser.
- We support global online technical support services for this product. If you encounter any problems in the use process, please email LaserPecker@163.com and we will reply to you as soon as possible. Customer service time: 9:30-19:30 from Monday to week.
- The information in this manual is subject to change without notice and does not constitute a commitment of the company.Please refer to our website (https://www.LaserPecker.net) for the most immediate updates.
- The copyright of this manual belongs to the software and hardware involved in this product, and belongs to Shenzhen Ninghi Technology Co., Ltd. (hereinafter referred to as "Ninghi Technology").
- Avoid children, minors, pets and mobile objects that may contact LaserPecker to approach or touch the product.

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

This device must be used in accordance to most general RF exposure requirements. The device can be used in portable exposure condition without restriction.

©2019 Shenzhen NinghiTechnology Co., Ltd. all rights reserved

LASERPECKER

L1 Pro 取扱説明書



重要なヒント 三脚台を取り外して高さ（焦点距離）を調節し、**レーザー発射レンズ**が**彫刻される物体表面**との距離を２００mmに調整する**高さを設定する**（型番**LPCeramic**の場合も工芸品）焦点が**工芸品**が**密着**すると**彫刻**も、**また**は**彫刻箇所**しの状況が**出る**。

製品及びパーツのリスト（標準の配置）

磁気式折り畳みのアクリル遮光パネル

（別途購入必要）購入サイト：www.laserpecker.net



製品紹介

基本セット

- **本体＋三脚台(標準の配置)**
  1.type-cインターフェース口（外部電源接続用）
  2.ブルートゥース接続指示灯
  3.電源スイッチ
  4.状態指示灯
  5.レーザー発射穴
  6.三脚台取付用穴



専門セット

- **自動焦点調整の電動ブラケット(別途購入必要)**
  購入サイト：www.laserpecker.net
  1.スイッチ(自動焦点調整ボタン
  2.主動下降調整ボタン手
  3.主動上昇調整ボタン
  4.USB輸出インターフェースロ
  5.赤外線距離測定窓
  6.筋風機（煙を取らす用）
  7.typ-cインターフェース口
  （外部電源接続用）入



豪華セット

- **煙遮断システム保護カバー(別途購入必要)**
  購入サイト：www.laserpecker.net
  1.USB輸出インターフェース
  2.スイッチ
  3.type-cインターフェース口
  （外部電源接続用）
  4.筋風機の排気口口
  5.プルーレイを通過する半透明保護カバー

基本セット組付操作の見取り図



重要なヒント

三脚台を取り外して高さ（焦点距離）を調整し、レーザー発射レンズが彫刻される物体表面との距離を２００mmに調整する高さを設定する（型番LPCeramicの場合も工芸品）焦点が工芸品が密着すると彫刻も、また彫刻箇所しの状況が出る。

専門セット組付操作の見取り図



重要なヒント

本製品は大型彫刻用芯方案を採用する

測定する物体の距離、表面反射率等要因の影響で距離測定の正確さには多少の差がある。当社的な実用効果を確保するために、以下の状況は正式な取り付ける前に製品測定パネルを使用して距離測定を確認する。

1.物体の測定面積は100*100mm以下

2.測定物体の表面はCDで表る被測物体表面（及び）

3.測定物体の表面には凸いたがある構造がある。例えば、スポンジ等みたいな材質

4.透明材料、高反射材料、超黒色の材質

豪華セット組付操作の見取り図

重要なヒント

1、保護カバーに入れる物品の厚さは10mmにおてである

2、厚さが10mmによの物品の場合は、三脚台を利用して距前にてください

操作説明

1.APPのダウンロード

- 操作方法1：アップルのAPP Store、Google Play Storeまたは当社のアプリ内で「LaserPecker」を検索し、アプリをダウンロード・インストールすることができます。
- 操作方法2：二次元コードをスキャンする簡単な方法でアプリをダウンロード・インストールすることもできます。
- 操作方法3：LaserPeckerの公式サイトwww.laserpecker.net.cnにアクセスしてアプリのダウンロードやインストールもできます。

注意：正常に本製品を使うために、APPをダウンロードし後にAPPにおける警告及び注意事項をご覧ください。

2.電源を入れる

1.ファンデ・フェースはTYPE-C(5V/2AL)とのアダプターを同意し、本製品付きの電源アダプター又は従者和QC2.0以上認証がある充電器、モバイル電源または社台形式の電源を点灯の、下記の状況で正常で使用ください。

3.ブルートゥースに接続する

電源を入れた後に自分が操作の点検すると自動がブルートゥースのペアリングモードにあることを表す、app下「アカ「アルートゥース接続」をクリックして自分は行ずっと考らになり、ペアリング成功を表す。

4.彫刻内容を選択する

APPホームページで前好きの内容を選んで前彫しはめる

技術サポート

本製品について、全世界でのオンライン技術サポートを提供しますから、使用ている間に何か問題がありましたらEmailで至laserpecker@hongyuan.cc迄送るよう お願いいたします。できるだけ早く返事する

メーカー：シンセンホイシン科技有限会社

電話番号：+8607755-28913864

製品規格表

寸法	65*61*53mm
重さ	190g
レーザーソース	500 mW SHARP 405 nm
レーザーソースの輸出パワー	パワー幅の0.1%調整は設定可能である1%-100%
外観	アルミ合金金属機殻七
ファイル転送	ブルートゥース4.0
ファイル格式	G-Code和jpg
APP接続方式	ブルートゥース接続
APP操作システム	type-c(5V、2A)
電源输出	iOSおよびAndroidおよびに適用する
推薦温度範囲	0℃-45℃
推薦湿度範囲	5℃-80℃（非凝縮態）
安全規範認証	ICE 60825-1レーザー一級安全規格(CE,RoHS,FCC,FDA CDRH準拠、和C 60825-1（レーザー印刷）、TELECMAC)
特許申請	七個特許有り

レーザー警告

1.警告：LaserPeckerの機器を操作する前に、この操作の内容を高刷に お読みください。操作前時を留守してください。

2.警告：この装置は4種類のレーザー（弱カなレーザー放射）を採用して、レーザーの放射は、次の事故を引き起こす可能性があります。1）周囲の可燃物を点火されること、2）レーザーが作業中に、レーザーに直射する反射物の直ににより、他の放射および有害ガス、有機ガス、または高圧ガスが発生する場合があります。3）レーザーが誤に反射されると、人体に損傷を与える可能性があります。したがって、オペレーターは機器から距離を取り、保護具（ゴーグル、保護カバー、保護服、または決の類など）を着用する必要があります。可燃性や毒物性作業台や機器の周りに極み重なる注意願い。同時に、作業現場をキッに使用してください。

3警告：レーザーが作業中にはリスクがある可能性があります。 ユーザーは、訪問されたオブジェクトの素材がレーザー操作に適していることを確実に検討してください。

4警告：このデバイスの動作周波は5Gのみです。訪問なアダプターを使用する必要があり、過負荷または予定安な電圧下での動作は禁じ止されています。 また、本製品の電源アダプターが供給される電源（電源タップなど）のアース線が効果的に機能しないといった前提の下では、電源を差し込むことは禁止です。さもないと、非常に危険な感電が発生します。

5警告：本製品は、非常に精密で先端なレーザー光源コンポーネントが装備されています。電磁干渉をさ起こす可能性があるため、強い電波下のある電化製品のなどに本製品を配置することは厳しく禁止されています。 レーザー光源をオンにするとき、レーザー光線が風塵で飛射されるため、ユーザーはレーザー光線に直接さるされないようにしてください。

6警告：人体や可燃物へのレーザー反射を避けるため、無関係な反射または拡散反射オブジェクトを本製品に配置することは厳に禁じられています。

7警告：この製品を使用してアイテムを彫刻する前に、彫刻されたり物体へのレーザー照射によって生じる様な物や周辺の環境および健康に悪影響を与えることを確認してください。

安全操作ガイドと注意事項

1.LaserPeckerをインストールする前に、装置が損傷していないことと、レーザーミラーの表面が汚れていないことを確認してください。

2インストール標本、LaserPeckerを操作する前に、製品説明書を使用してメインユニットを固定し（保護カバー、三脚、電気プラケットなどの固定機能を備えられていり作成品およびサポートを使用すると、予定なな配置による損傷を避けてください。

3.周囲説明書に記載されている電源仕様と電源の種類（5V/2Aアダプタ）に応じて、デバイスに電源を供給してください。

4.レーザーを起動して取材物質を前に、安全保護対策を必ず行ってください。 例えば、ゴーグルと防護服を着用して、LaserPeckerまたは周囲の物体を損傷する可能性があります。一度たの製品を使用するごとによう、危害事故と警告事項を よく読み、この声明当中ての条件と内容を理解し、承認し、受け入れたくみなされます。あなたは、この製品の使用と起こりうる結果に対して全責任を負うことを約束します。お客様は、この製品を適用の目的にのみ使用することを約束し、これらの条件およびAPPsおよび第三方と間違する規則、ガイドライン元同意するものとします。 LaserPeckerは、本製品に中なる損害、傷害、または この製品の直接的または間接的な使用によう生じた財産性を持っています。ユーザーは、この記事を含むがこれらに限られないすべての安全ガイドラインに従う必要があります。

著作権表示

このドキュメントと、関連するハードウェア、ドライバー、制御プログラム、APPソフトウェア、およびこの説明書の著作権は、Shenzhen Hingle Tech Co., Ltdが所有しています（以下のシンテンシなど、合社名称は前一ボに「当社グループ」と呼ばれる）予告なしに変更される場合があります。最新の製品規前については、公式ウェブサイトhttps://www.laserpecker.net等ご覧ください。

LaserPeckerは、精神テクノロジの登録商標であり、承認されていない場合に、 不正使用は固く禁じられています。 LaserPeckerユーザーや第3代に使用する場合を除き、当社の許可なく自行を行なって、この製品説明書の内容を出ボんしたりこのようすることは固く禁じられています。 違反した場合、当社テクノロジーは法律を使って責任を追及する権利を保留します。 この記事に記載されている製品名、プランドなは、それぞれの所有権者の権利または登録商標です。

保証条件・注意事項

この製品には、ユーザーが交換可能なコンポーネントは含まれていません。どんなシーンであっても、LaserPeckerを分解したり取りたしたりしないでください。

本製品の電子ハウジングには非常に危険なレーザー光源コンポーネントがありますが、LaserPecker本体の電源が入っている場合は、ビームが放射された後、レーザービームに直接さらされないでください。

この製品は、最初のタイプのレーザー製品の要件を満たしています。通常の使用条件下では、仕様に従って動作します。そうしない、皮膚や目に損傷を引き起こす可能性があります。レーザーシールドや保護の動作が故障では、安全であるために、目を直接主要する必要があります。

ビジョンレーザー。

この製品のグローバルオンラインテクニカルサポートスをサポートしています。使用中に問題が発生した場合は、laserpecker ⊕ 163.comにメールしてください。できるだけすぐご連絡いたします。カスタマーサービス時間：月曜日から日曜日09：30-19：30。

このマニュアルの規制は予告なく変更される場合があり、このマニュアルの規制は会社のコミットメントを構成するものではありません。最初のアップデートについては、当社のWebサイト（https://www.laserpecker.net/）を参照してください。

このマニュアルの著作権は、製品に含まれるソフトウェアおよびハードウェアの権利であり、Shenzhen Yuying Technology Co., Ltd.（以下[当社]と呼びます）に属します。

免責事項

LaserPeckerを お買い上げいただき ありがとうございます。この記事に記載されている内容は、あなたの安全と法的権利と責任に関するものです。この製品を使用する前に、この記事をよく読んで、製品の設定方法ついてを確認してください。本書の前と書類に変化に応じない場合、あなたや周囲の人員に怪我をしたり、LaserPeckerまたは周囲の物体を損害する可能性があります。一度たの製品を使用するごとによう、危害事故と警告事項をよく読み、この声明当中ての条件と内容を理解し、承認し、受け入れたくみなされます。あなたは、この製品の使用と起こりうる結果に対して全責任を負うことを約束します。お客様は、この製品を適用の目的にのみ使用することを約束し、これらの条件およびAPPsおよび第三方と間違する規則、ガイドラインに同意するものとします。 LaserPeckerは、本製品に中なる損害、傷害、または この製品の直接的または間接的な使用によう生じた財産性を持っています。ユーザーは、この記事を含むがこれらに限られないすべての安全ガイドラインに従う必要があります。

©2019 シンセン市ハイシン科技有限会社 版権所有

この製品にアクセスしたり触れたりするために、レーザーベッカーと接触する可能性のあるデバ、未成年者、ペット、および弱い物体を避けてください。