

AX⁴

ON-THE-GO WIRELESS SPEAKER



MODEL # WL15011

AIRBUDS[®]

USER MANUAL

Includes: AX⁴ Wireless Speaker,
Micro USB charging cable

Thank you for choosing AX⁴ wireless speaker.

For continuous maximum performance, please read the following instructions carefully.

Keep this manual handy for future reference.

POWER YOUR SPEAKER ON/OFF

Hold the **PLAY/PAUSE BUTTON** for 2 seconds. An audio chime will confirm the speaker has powered on/off.

PAIRING SPEAKER


1. Make sure that your AX⁴ Wireless Speaker is within 30' (10m) of your Bluetooth device.
2. Verify that you turned on Bluetooth on your mobile device.
3. Open the Bluetooth menu on your mobile device, and select "AX⁴" from the list of discovered Bluetooth devices.

An audio cue will play when your device is paired.

RECONNECTING SPEAKER

When you power on your AX⁴ Wireless Speaker, it will automatically reconnect to the device it was paired with previously.

SPEAKER CONTROLS



SAFETY PRECAUTIONS/WARNINGS

IF YOU HAVEN'T USED YOUR SPEAKER IN A WHILE OR PLAN TO GO LONG PERIODS OF TIME WITHOUT USING IT, BE SURE TO CHARGE THE UNIT ONCE A MONTH TO PREVENT DAMAGE TO THE LITHIUM-ION BATTERIES OVER TIME. DO NOT CHARGE THE SPEAKER FOR MORE THAN 10 HOURS AT A TIME.

DO NOT ATTEMPT TO PIERCE, STRIKE, OR APPLY STRONG PRESSURE WITH SHARP OR HEAVY OBJECTS. STRONG IMPACT OR SHOCKS COULD CAUSE IRREVERSIBLE DAMAGE TO THE UNIT. AVOID PROXIMITY TO HIGH FREQUENCIES AND STRONG MAGNETIC DEVICES WHEN POSSIBLE.

DROPPING OR MISHANDLING THE SPEAKER MAY CAUSE IRREPARABLE DAMAGE TO THE UNIT AND ITS BATTERIES.

KEEP SPEAKER AWAY FROM HEATING APPLIANCES AND SOURCES OF ELECTRICAL NOISE, SUCH AS FLUORESCENT LAMPS OR MOTORS. KEEP HANDS DRY AND CLEAN WHEN TOUCHING THE SPEAKER AND BUTTONS. DO NOT CLEAN SPEAKER WITH CHEMICAL SOLVENTS.

KEEP SPEAKER AWAY FROM SMALL CHILDREN AT ALL TIMES OR ENSURE STRICT SUPERVISION BY AN ADULT AT ALL TIMES. THE UNIT CONTAINS SMALL PARTS AND MAY POSE A CHOKING HAZARD.

DO NOT EXPOSE SPEAKER OR ANY ELECTRICAL PARTS TO EXTREMELY HIGH OR EXTREMELY LOW TEMPERATURES OR HIGH PRESSURE. DO NOT EXPOSE SPEAKER TO TEMPERATURES ABOVE 60°C. DO NOT EXPOSE SPEAKER TO FIRE, DIRECT SUNLIGHT, DUST, HIGH LEVELS OF HUMIDITY, OR OTHER HOT LOCATIONS AS THIS MAY CAUSE THE BATTERY TO GENERATE HEAT, IGNITE, OR EXPLODE. USING THE SPEAKER IN THIS MANNER MAY ALSO RESULT IN A LOSS OF PERFORMANCE OR A SHORTENED PRODUCT LIFE EXPECTANCY.

DO NOT ATTEMPT TO DISASSEMBLE OR MODIFY THE SPEAKER IN ANY WAY. IMMEDIATELY DISCONTINUE USE IF THE UNIT HAS ANY VISIBLY EXPOSED PARTS OR APPEARS MALFUNCTIONAL IN ANY WAY. IF THIS DOES OCCUR, ISOLATE THE SPEAKER IN A SAFE PLACE AND CONTACT THE AIRBUDS CUSTOMER SUPPORT TEAM AT **SUPPORT@AIRBUDS.COM**

FCC WARNING STATEMENT

WARNING: CHANGES OR MODIFICATIONS TO THIS UNIT NOT EXPRESSLY APPROVED BY THE PARTY RESPONSIBLE FOR COMPLIANCE COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

NOTE: THIS EQUIPMENT HAS BEEN TESTED AND FOUND TO COMPLY WITH THE LIMITS FOR A CLASS B DIGITAL DEVICE, PURSUANT TO PART 15 OF THE FCC RULES. THESE LIMITS ARE DESIGNED TO PROVIDE REASONABLE PROTECTION AGAINST HARMFUL INTERFERENCE IN A RESIDENTIAL INSTALLATION. THIS EQUIPMENT GENERATES, USES AND CAN RADIATE RADIO FREQUENCY ENERGY AND, IF NOT INSTALLED AND USED IN ACCORDANCE WITH THE INSTRUCTIONS, MAY CAUSE HARMFUL INTERFERENCE TO RADIO COMMUNICATIONS.

HOWEVER, THERE IS NO GUARANTEE THAT INTERFERENCE WILL NOT OCCUR IN A PARTICULAR INSTALLATION. IF THIS EQUIPMENT DOES CAUSE HARMFUL INTERFERENCE TO RADIO OR TELEVISION RECEPTION, WHICH CAN BE DETERMINED BY TURNING THE EQUIPMENT OFF AND ON, THE USER IS ENCOURAGED TO TRY TO CORRECT THE INTERFERENCE BY ONE OR MORE OF THE FOLLOWING MEASURES:

- ☐ REORIENT OR RELOCATE THE RECEIVING ANTENNA.
- ☐ INCREASE THE SEPARATION BETWEEN THE EQUIPMENT AND RECEIVER.
- ☐ CONNECT THE EQUIPMENT INTO AN OUTLET ON A CIRCUIT DIFFERENT FROM THAT TO WHICH THE RECEIVER IS CONNECTED.

☐ CONSULT THE DEALER OR AN EXPERIENCED RADIO/TV
TECHNICIAN FOR HELP.

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES.
OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:
(1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND
(2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED,
INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE
OPERATION.

THE DEVICE HAS BEEN EVALUATED TO MEET GENERAL
RFEXPOSURE REQUIREMENT. THE DEVICE CAN BE USED IN
PORTABLE EXPOSURE CONDITION WITHOUT RESTRICTION.

COMMON PROBLEMS AND SOLUTIONS

SMART DEVICE CANNOT FIND BLUETOOTH SPEAKER

CHECK THAT SPEAKER POWER IS SWITCHED ON. IF “AX4” HAS NOT BEEN FOUND AFTER SWITCHING POWER ON, RESTART BOTH THE SPEAKER AND SMART DEVICE.

PROBLEMS WITH BLUETOOTH SPEAKER WHILE IN USE

RE-CONNECT TO SMART DEVICE AFTER TURNING OFF AND RESTARTING SPEAKER. CHECK CHARGE STATUS OF SPEAKER, THEN TURN ON AND RE-CONNECT VIA BLUETOOTH TO DEVICE.

SPEAKER FREQUENTLY DISCONNECTS OR MAKES NOISE WHEN CONNECTED

THE BLUETOOTH SPEAKER POWER STATUS IS PROBABLY LOW AND NEEDS TO BE RECHARGED. THERE MAY ALSO BE AN OBSTRUCTION BETWEEN SMART DEVICE AND BLUETOOTH SPEAKER, OR THE DISTANCE MAY BE BEYOND THE SIGNAL RANGE.

**DO NOT RETURN THIS PRODUCT TO THE STORE
IF YOU HAVE MISSING OR DAMAGED PARTS.**

CALL US OR SMS @ 646.351.1700 IMMEDIATELY!

EXTENSIVE TROUBLESHOOTING

MISSED A STEP? BEFORE ATTEMPTING TO REPAIR, TRY THESE ALTERNATIVE STEPS:

CAN'T PAIR SPEAKER TO MOBILE DEVICE? CHECK THAT THE SPEAKER IS CHARGED AND IN PAIRING MODE.

CONFIRM THE BLUETOOTH SETTINGS ON YOUR MOBILE DEVICE AND VERIFY "AX 4" HAS BEEN SELECTED FROM LIST OF DISCOVERABLE BLUETOOTH DEVICES.

IF AX4 SPEAKER IS NOT ON THE LIST OF DISCOVERABLE DEVICES, MAKE SURE IT IS WITHIN 30 FEET OF YOUR MOBILE DEVICE.

STILL HAVE PAIRING QUESTIONS? NEED HELP?

CONTACT OUR SUPPORT TEAM AT:
WWW.AIRBUDS.COM/SUPPORT
1-646-351-1700 (MON-FRI, 9AM-6PM EST)
SUPPORT@AIRBUDS.COM

REGISTER YOUR AX4 SPEAKER:
WWW.AIRBUDS.COM

TECHNICAL SPECIFICATIONS:

PLAYTIME: up to 3 hours

BUILT-IN BATTERY: 3.7v300 mAh lithium

CHARGE TIME: 2-3 Hrs

RANGE: 30 feet / 10 meters

BLUETOOTH : 5.3

OUTPUT POWER: 3 Watt

SPEAKER: 4 Ω 3W*1

WIRELESS V 5.3 SUPPORT: L2CAP/A2DP (AVCT/AVDTP/AVRCP). Can receive AUDIO signal and control the AUDIO device

IP GRADE: IPX4

FREQUENCY RESPONSE: 2.4 GHz

 @AIRBUDS

 AIRBUDS_AUDIO

 @AIRBUDS_AUDIO

WWW.AIRBUDS.COM



ON-THE-GO WIRELESS SPEAKER



WORLD FAMOUS WARRANTY

AT AIRBUDS, WE BELIEVE IN OUR PRODUCTS. THAT'S WHY WE BACK THEM ALL WITH A LIMITED LIFETIME WARRANTY AND PROVIDE FRIENDLY, EASY-TO-REACH SUPPORT.

QUESTIONS? WE'RE ALL EARS AND THUMBS FOR TECH SUPPORT!



TEXT / CALL / EMAIL
646.351.1700
SUPPORT@AIRBUDS.COM



© 2023 AFH INDUSTRIES INC. ALL RIGHTS RESERVED. AIRBUDS IS A REGISTERED TRADEMARK OF AFH INDUSTRIES INC. OTHER TRADEMARKS AND TRADE NAMES ARE THOSE OF THEIR RESPECTIVE OWNERS. MANUFACTURED AND SERVICED BY AFH INDUSTRIES INC. 110 WEST 34TH STREET, 7TH FLOOR, NEW YORK, NY 10001 • FOR PATENTS: AIRBUDSACC.COM/PATENTS • CONTENTS AND COLORS MAY VARY FROM ILLUSTRATED. THE BLUETOOTH WORD MARK AND LOGOS ARE OWNED BY THE BLUETOOTH SIG. INC. FOR AGES 12+. THIS IS NOT A TOY. **MADE IN CHINA**

AFH

CONFIDENTIAL ARTWORK

DESIGNER: JERRY
COMPANY: AFH INDUSTRIES
MODEL # WL15011

PRODUCT: AIRBUDS NEW GIFT BOX WALGREENS 2021
FILE NAME: WL15011_Airbuds_AX4_Speaker_Manual.ai

SPEC INFORMATION

12 Page Booklet
Saddle Stitch (Stapled)

COLORS



CMYK

BOOKLET SIZE

Closed: 3" x 4.25"
Open: 6" x 4.25"
SCALE: 100%

PAPER / SUBSTRATE

PAPER STOCK: 80g GlossPaper