



HIGH PERFORMANCE FOLDABLE
MINI BLUETOOTH HEADSET

产品名称：歌尚E88A蓝牙耳机
主要功能：蓝牙(通话)+AUX
AUX功能：不开机插上即可使用；开机后插入AUX线自动关闭蓝牙功能
开机状态：5分钟无设备连接自动关机

有效范围：约12米
工作频率：2.402~2.480GHz
电池规格：3.7V/1200mAh（内置可充电锂电池）
充电电压：DC4.2-5.5V
灵敏度：102±3dB/mW

喇叭直径：40mm

包装清单

- 一个蓝牙耳机主机
- 一根USB充电线
- 一根AUX-in音频线
- 一本说明书

按键说明

1.“-”短按减音量/长按上一曲

3.“乙”开启/关闭/暂停/播放

功能说明

开机：长按“ ”三秒钟以上，设备启动自动进入蓝牙模式，LED指示灯蓝色长亮。

关机：长按“弋”三秒钟以上，LED指示灯熄灭，设备关闭。

按键指引

1.接通电话：来电时短按“ ”

2.挂断电话：通话中短按“ ”

3.回拨最后一次号码：双击“ ”

4.播放音乐：正常状态下短按“ ”,自动打开智能设备播放音乐。

5.通话后继续播放：有来电时，自动暂停播放中的音乐，通话结束后，需要短按“ ”继续播放。

蓝牙模式

1.首次配对：开机自动进入蓝牙模式，语音提示：“Power on Pairing”,LED指示灯蓝色长亮，1秒后如若搜索不到最后一次与之连接的蓝牙设备，耳机自动进入蓝牙配对模式，LED指示灯蓝红快速交替闪烁，打开智能设备的蓝牙功能，开启搜索并选择设备“GS”，无需密码，配对成功后语音提示“Connected”,LED指示灯蓝色长亮。

2.后续配对：开机后会自动搜索并连接最后一次与之配对的设备。

3.最大音量警示音：“didi”。

4.省电模式：匹配状态持续5分钟无任何操作，耳机自动关机；插入AUX-in线自动切断供电。

5.国际通用Micro USB充电口。

AUX-in 播放模式

在任意模式下，插入AUX-in线，耳机自动关机，切换到AUX-in功能，此时无需耗电。

TF卡播放模式

关机情况下，插入TF卡，短按开机按钮三秒左右，蓝牙耳机自动进入TF卡播放模式。

开机情况下，插入TF卡，蓝牙耳机自动进入TF卡播放模式。同时按下“+ -”切换TF卡模和蓝牙模式。

***注意：TF卡最大支持容量为16GB,如使用超过16GB的TF卡，有可能导致系统无法播放音乐**

LED灯状态

充电状态	红色LED指示灯长亮，满电时，指示灯熄灭
开机状态	蓝色LED指示灯长亮
关机提示	LED指示灯熄灭
配对状态	红蓝LED指示灯交替闪烁
连接成功	蓝色LED指示灯长亮

注意事项

- 蓝牙耳机进入配对模式后若无配对连接操作，请关闭设备避免电量损耗。
- 搜索蓝牙耳机时，不要进行其他操作，以免程序出错。
- 在使用中请选择适当音量，以防对耳朵造成伤害。
- 请注意蓝牙耳机的良好使用环境，以防对耳机造成伤害。
- 长时间未使用耳机，请先将耳机充满电后再使用。
- 本产品充电时适配电压为5V电源，请勿使用非5V充电电压为本产品充电，违反此操作导致产品燃烧损坏或其他安全事故，本公司概不负责！

Product Name: Wireless Kids ANC Headphone
Function: Bluetooth (call)and AUX
AUX function: It can be used without powering on,and will automatically power-off after using AUX cable.
Power on status: Auto power-off after disconnected for 5 minutes.

Specifications

Working Range:around 12m
Frequency Response:2.402-2.480GHz
Battery Voltage:3.7v/1200mAh
Battery Charging Voltage:DC4.2-5.5V

Sensitivity:102±3 dB/mW
Impedance:32ohm
Speaker diameter:40mm

Packing list

- A Bluetooth Headphone
- An USB charging data cable
- An AUX-in audio cable
- A manual

Button Function

1.“-” Volume down:short press
Move previous:long press

2.“+” Volume up:short press
Move next:long press

3.“ ”Power on/Power off,Pause/play

Function Description

1.Power on:Long press“ ”for more than 3 seconds,the headphone turn on and enter Bluetooth Mode,Blue LED is on.

2.Power off:Long press“ ”for more than 3 seconds,the LED indicator light is off and the headphone

Button Guide

1.Hang on:Short press“ ”button when being called.

2.Hang up:Short press“ ”button when calling.

4.Play music:Normally short press“ ”button to turn on the smart devices automatically to play music.

5.Continue to play music after the call:When there is an incoming call,the music will be automatically suspended. After the call,you need to short press the“ ”button to continue playing.

Bluetooth mode

1.First pairingIt will enter the Bluetooth mode automatically when the"GS"is switched on,then voice prompts,"Power on Pairing",blue LED **is on**,and if the last connected device could not be found after 1s,the"GS"will automatically enter the Bluetooth pairing mode,and you willfind that LEDlight flashed between red and blue,at this

then search the device named "GS"to get connected without a password,after pairing successfully,voice prompts "Connect ed",the blue LED is on.

2.Subsequent pairing:after powering on,it will automatically

3.Warning voice of maximum volume:"Didi"

4.Power saving mode:headset will automatically power off after pairing continuously for 5 minutes;it will cut off powel supply automatically after using Aux-in cable for power saving.

5.International general Micro USB charging port.

AUX-in Mode

In any modes,insert the AUX-in line,the headset automatically shut down,and switch to AUX-in function without power consumption.

TF card playback mode

When powering off,insert TF card,short press the power button about three seconds,the Bluetooth headset automatically enter the TF card play mode.

When powering on,insert TF card,Bluetooth headset automatically enter the TF play mode.
Press both“+ -” at the same time to switch between

***Note:The maximum support capacity of TF card is 16GB.If using the card more than 16GB,the system maybe can not play music.**

LED light status

Charging	The red LED is on,when full charged,the indicator ligh is off.
Powering on	Blue LED flashes
Poweringoff	Red LED flashes and finally turn to off
Pairing	Blue and red LED flashes alternately
Connected	Blue LED is on

Note

1.Please turn off the device to avoid power consumption if no pairing operation taken after bluetooth headset entering into the pairing mode.

2.Please do not make other operations when searching bluetooth in case of procedure error.

3.Please adjust volume appropriately to avoid doing harm to the ears.

4.Please pay attention to choose a good surroundings for bluetooth headset use to avoid causing damage to the headset.

5.Please get bluetooth headset full charged firstly when it has not being used for a long time before.

6.Please only use an adapter with the out put of 5V to charge this product,otherwise,may cause product damage or other satety problems.The company will not be responsible for any combustion damage or other safety incidents caused by the violation of this operation.

FCC Caution: This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -Reorient or relocate the receiving antenna. -Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.			
--	--	--	--