

REMOTE CONTROL
FUNCTION

- Press it once to enter into standby state. Press it again the unit will switch on.
- Press it to mute the unit
- Press it to enter into AUX mode
- Press it to enter into USB&TF mode
- Press it to open 3D output,press it again to cancel
- When Playing USB or TF card,press it to select single & All cycle,the display screen will show "ONE & ALL" cycleplay
- Press it to enter into FM mode
- When playing FM,press it to enter into automatic scan and then save program
- In order to get the best receiving effect,manual search for next FM channel
- In order to get the best receiving effect,manual search for previous FM channel
- Press it to change the modes between AUX/, TF CARD/USB/ FM/Bluetooth orderly
- Press it to adjust Treble/Bass volumn
- Adjust wireless micphone's volume when wireless micphones is connected
- Press it to increase the volume
- Press it to decrease the volume
- 1.When playing USB/TF ,press this button to select previous song.
2.When playing Bluetooth,press this button to select previous song,simultaneously open the Bluetooth setting on your device
- 1.When playing USB/TF ,press this button once to pause,press again to continue playing.
2.When playing Bluetooth,this is play/pause button,simultaneously open the Bluetooth setting on your device
- 1.When playing USB/TF ,press this button to select next song.
2.When playing Bluetooth,press this button to select next song,simultaneously open the Bluetooth setting on your device
- Bass volume decrease
- Bass volume increase
- When playing USB/TF/FM,select the song and play directly
- Press it to enter into bluetooth mode and wait for the match and connection
- Press it to rematch the Bluetooth

REMOTE




WINGS
HI-FI SYSTEM CLASSIC

USER MANUAL
2.1 CH SPEAKER



THE SKETCH MAP



SPECIFICATIONS

1. Built OCL amplifier, Compatible for Computer, VCD,CD,LD. Walkman and so on
2. Magnetic shielded treatment designed, able to be configured with TV sets or computers;
3. Creating a larger dynamic range in the low frequency, a smoother middle frequency, and a pure and harmonious high frequency;

OPERATION

1. Please connect the sound sources and powers in accordance with the sketch map ;
2. When all of the units are connected correctly, turn on the power switch;
3. Open your sound sources, then adjust the volume knobs of the different channels for a satisfied personalized effect;
4. After your use, please turn off the power supply switches.

ATTENTION

1. Please turn the volume knob to the minimum position before your operation to prevent any damage to the speakers due to the instant impact ;
2. Please avoid being exposed or put in humid environment;
3. Please do not open the back cover of the main speaker in case of getting an electric shock or breaking the warranty regulations;
4. Please turn off the power switch and release the plugs if you probably do not use it within a long period.


COMPOSITION

*Subwoofer	1pc	*Satellite speaker	2pcs
*Signal input cable	1pc	*Operation manual	1pc
*Remote	1pc	*Microphone	1pcs

FUNCTION MANUAL

1.VOLUME SET

- VOL-: Total volume reduction
- VOL+: Total volume addition
- TREBLE-: High volume reduction
- TREBLE+: High volume addition
- BASS-: Bass volume reduction
- BASS+: Bass volume addition



2.INPUT

Press this button for 2 seconds for "TURN ON", then it is for"INPUT" signal selection. Press this button again for 2 seconds for "TURN OFF".

3.PREV/FM-

- 1.When playing USB/TF /Bluetooth,press this button once to previous song.
- 2.When playing FM,press this button once to change the frequency modulation.press this button for 2 seconds for automaticseaching the channel and then memorized it.

4.PLAY/PAUSE

- 1.When playing USB/TF /Bluetooth,press this button once to start playback & pause.
- 2.When playing FM,press this button for 2 seconds to automatically search the channel and then memorized it;press this button again to stop automatically searching channel.
- 3.When playing bluetooth,press this button 2 seconds to start playback & pause.

5.NEXT/FM+

- 1.When playing USB/TF /Bluetooth,press this button once to next song.
- 2.When playing FM,press this button once to change the frequency modulation. Press this button for 2 seconds for automatic seching the channel and then memorized it.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.