


FUTURE

F40i

F40i Li

INTELLIGENT AMP



MOOER

F40i & F40i Li INTELLIGENT AMP

Quick Guide
快速指导
Schnellstart



MOOER
iAmp App



55 Amps



69 Effects



Drum
Grooves



Looper



Rechargeable
Built-in Battery



MOOER
Cloud



Bluetooth



Wireless F.S.



Circular
Touchscreen



Two Line-out Jacks
For Connecting



High-quality
OTG Recording


This is a quick guide.

For more detailed manual, please enter www.mooeraudio.com to download.


If you need any help and tech support, please contact: support@mooeraudio.com

感谢您选择魔耳公司的产品, 该使用指南将帮助您快速了解如何使用本产品, 如需了解更详细的信息,
请登陆魔耳官网 www.mooeraudio.com 下载完整版说明书。


PACKAGE CONTENTS



F40i / F40i Li*1



USB-C Cable*1




Power Adapter*1




Quick Guide*1

DEVICE CONNECTIONS



Front Panel



1. Connect guitar, bass, or other instruments to the INPUT jack.
2. Connect headphones to the Headphone Output jack.
3. Connect a smartphone to the REC jack for OTG recording.



Rear Panel

4. 48V Power Switch – enable only when using a condenser microphone.
5. MIC/INST Input – for microphone, guitar, bass, or other instruments.
6. MIC GAIN – slowly increase gain when connecting a microphone until you achieve a rich and dynamic signal.
7. LINE OUT – connect to monitor speakers or a mixer system.
8. Power Input – connect using the original 19V 2.5A adapter (also charges the device).

QUICK OPERATIONS



Long press this button to power ON/OFF.



Rotate the Value Encoder to switch presets or adjust parameter values.



Rotate the Master Knob to control overall volume.



Press this button to enter/exit the Tools Menu.



Tap this button repeatedly to set preset/drum machine BPM.



Press this button to enter/exit the Tuner Interface.




Press this button to enter the Preset Interface or switch between four presets in the same group.

iAMP USER GUIDE


1. Download & Install

- Search for “iAMP” in app stores and install.





2. Connect to the Amp

- Open iAMP, select Future Series, tap Search Device, and connect to F40i when it appears.





3. Effect Chain & Tone Library

- In the Effect interface, adjust factory preset tones and modify effect types/parameters.
- In the Library interface, quickly select style-based presets and save them for use in Effect.





4. Mic/Inst

- Tap the Mic/Inst icon at the bottom.
- Presets include vocal effects, acoustic guitar effects, bass effects, etc.
- Tap Use to apply a preset; tap the preset name again to deselect.




5. MOOER AI

- Tap the center icon at the bottom to access AI functions.
- Enter your tone requirements in the dialogue box, and the AI system will generate tones for preview or download.




6. MOOER Cloud


- **Upload:** Share your presets for others to use.
- **Clouds:** Download presets and MNRS tone files shared by others.




包装内容



F40i / F40i Li*1



USB-C连接线*1




电源适配器*1




快速指导*1

设备连接



面板



- 1、吉他、贝斯或其他乐器可接入INPUT接口；
- 2、耳机可接入耳机输出接口；
- 3、手机可接入REC接口进行OTG内录；



背板

- 4、48V供电拨档开关，仅电容麦克风需开启；
- 5、MIC/INST，麦克风/吉他、贝斯或其他乐器接口；
- 6、MIC GAIN，麦克风增益，接入麦克风慢慢拧大到合适位置，获得一个动态饱满的信号即可；
- 7、LINE OUT，可接入监听音箱或调音台系统；
- 8、电源接口，使用19V 2.5A原装电源适配器接入，同时可进行充电。

快速操作



长按此按键可开机/关机



旋转Value编码器可切换预设以及改变参数值



旋转Master旋钮可调节音量大小



按压此按键进入/退出工具界面



以一定的速率按压此按键可设置预设/鼓机BPM



按压此按键进入/退出调音表界面




按压此按键可进入预设界面或切换同组四个预设

iAMP 操作指南


1. 下载安装

- 在各大应用软件商店搜索“iAMP”下载安装。





2. 连接音箱

- 打开iAMP, 选择Future系列, 点击Search device搜索设备, 列表出现F40i后, 点击它连接。





3. 效果链 & 音色库

- 在Effect界面, 自带出厂预设音色, 可调节各种效果类型及参数;
- 在Library界面, 可快速选择音乐风格的预设, 并保存到Effect使用。





4. Mic/Inst

- 点击下方Mic/Inst图标进入；
- 自带预设音色，包含人声效果、原声吉他效果、贝斯效果等；
- 点击Use使用该预设，点击预设名称则不使用预设。




5. 魔耳 AI

- 点击下方中间的图标进入AI功能；
- 在对话框输入你的音色需求，AI系统帮你生成音色效果，可试听或下载。




6. 魔耳音色云


- **Upload:** 可上传你的预设音色分享给他人使用；
- **Clouds:** 在这里可以下载使用他人上传分享的预设音色和MNRS采样音色。




LIEFERUMFANG



F40i / F40i Li*1



AUSB-C Kabel *1




Netzteil*1




Schnellanleitung*1

ANSCHLÜSSE



Vorderseite



1. Schließen Ihre Gitarre, Bass oder anderen Instrumente an die INPUT Buchse an.
2. Schließen Sie Kopfhörer an die Kopfhörerausgangsbuchse an.
3. Schließen Sie für OTG Aufnahmen ein Smartphone an die REC Buchse an.



Rückseite

4. 48V Schalter – Phantomspeisung. Aktivieren Sie diesen Schalter nur für Kondensatormikrofone.
5. MIC/INST Eingang – für Mikrofon, Gitarre, Bass oder andere Instrumente.
6. MIC GAIN – Vorverstärkung für Mikrofone. Erhöhen Sie bei angeschlossenem Mikrofon langsam die Verstärkung, bis Sie ein kräftiges, dynamisches Signal hören.
7. LINE OUT – Anschluss für Aktivlautsprecher oder ein Mischpult.
8. Stromversorgungseingang – schließen Sie hier das originale 19 V / 2,5 A Netzteil an (dieses lädt auch den Akku im Gerät).

BEDIENUNG



Tippen Sie hier, um Bluetooth zu aktivieren / deaktivieren.

Tippen Sie hier, um die Kopplung zum kabellosen Fußschalter zu aktivieren/deaktivieren.

Tippen Sie hier, um das Stimmfenster zu öffnen.

Tippen Sie hier, das Drum-Computer Menü zu öffnen.



Drücken Sie lange auf den POWER Knopf, um das Gerät ein-/ auszuschalten.



Drehen Sie den VALUE Knopf, um zwischen Presets umzuschalten und Parameterwerte anzupassen.



Drehen Sie den Master Knopf, um die Gesamtlautstärke anzupassen.



Drücken Sie den TOOLS Knopf, um das Tools Menü zu öffnen / zu verlassen.



Drücken Sie wiederholt auf die TAP Taste, um die BPM für das Preset / den Drum-Computer einzugeben.



Drücken Sie die TUNER Taste, um die Stimmfunktion aufzurufen / zu beenden.




Drücken Sie PRESET Taste, um das Preset Menü zu öffnen, oder um zwischen den vier Presets in einer Bank umzuschalten.

iAMP ANLEITUNG


1. Herunterladen und installieren

- Suchen Sie im App Store nach "iAMP" und installieren Sie die App.





2. Stellen Sie die Verbindung zum Verstärker her

- Öffnen Sie iAMP, wählen Sie Future Series aus, tippen Sie auf Search Device und stellen Sie die Verbindung zum F40i her, wenn dieser angezeigt wird.





3. Effektkette & Soundbibliothek

- In der Effect Ansicht können Sie Werks -Presets anpassen und Effekttypen / -parameter ändern.
- Im Library Fenster können Sie schnell auf nach Style sortierte Presets zugreifen und diese für die Verwendung im Effektfenster speichern.





4. Mic/Inst

- Tippen Sie im unteren Bereich auf das Mic /Inst Symbol.
- Die Presets umfassen Gesangseffekte, Effekte für Akustikgitarren, Bassgitarren usw.
- Tippen Sie auf Use, um ein Preset anzuwenden; tippen Sie erneut auf den Preset-Namen, um die Auswahl aufzuheben.




5. MOOER AI

- Tippen Sie auf das Symbol unten in der Mitte, um auf KI-Funktionen zuzugreifen.
- Geben Sie Ihre Soundvorstellungen in der Dialogbox ein. Das KI-System erzeugt dann Sounds zu Anhören und zum Herunterladen ins Gerät.



6. MOOER Cloud

- **Hochladen:** Teilen Sie Ihre Presets mit anderen Nutzern.
- **Clouds:** Laden Sie Presets und MNRS Sound-Dateien herunter, die von anderen Nutzern geteilt wurden.



FCC warning statements:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Hereby declare that a localized Japanese version of the user manual will be provided and included with the product upon its official launch and distribution in the Japanese market. The technical specifications, safety instructions, and operational procedures in the Japanese manual will remain consistent with the certified English version