



Installation

1. The product hole size, measured in millimeters, as shown below:




2. Product installation height space, unit: mm, as shown below:




Installation

3. Place the product into the mounting hole, as shown below:



4. Lock the three nuts at the bottom, as shown below:



Product Failure Table

Fault phenomenon	Possible causes and solutions
Cannot turn on	1. The power supply is not connected. 2. The wire is disconnected or the plug is not inserted properly.
The horn has no sound.	1. The volume may have been adjusted to the minimum setting. Try turning it up and try again. 2. Playback enters pause mode. Press to resume playback 3. The product is in headphone mode. Please disconnect the headphones.
Bluetooth cannot connect	1. It is already connected to another Bluetooth device. Long press to disconnect the current Bluetooth connection and try again. 2. Out of effective range. Please do not connect this product beyond a range of 10 meters. Do not attempt to connect through obstacles.
The wireless charging speed is slow	1. The temperature of the product body is too high. Please wait until the temperature of the product body drops to room temperature before starting to use the device. 2. The wireless charging induction area is not aligned. Move the phone to the center position.

Product Warranty

Wireless charger product after-sales service strictly in accordance with Law of the PRC on the Protection of the Rights and Interests of Consumers, and Product Quality Law of the People's Republic of China Adopted to provide After-sales service.
The services are as follows:
1. Within 7 days from the next day after purchase (sign for), if this product has performance failure, you can enjoy free return or exchange service after being tested and determined by the after-sales service center;
2. Within 15 days from the next day after you purchase (sign for), if this product has performance failure, you can enjoy free exchange or repair service after being tested and determined by the after-sales service center;
3. Within 1 year from the next day after you purchase (sign for), if this product has performance failure, you can enjoy free repair service after being tested and determined by the after-sales service center.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.
Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.
RF Exposure Information
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.


Manufacturer: GCteq Wireless (Shenzhen) Co., Ltd
Website: <http://www.gcteq.com>

Checked
Certificated of qualification




GF-20
User Manual

Product features



Product diagram



Specifications

Product Name	Embedded multi-functional coffee table board
Product model	GF-20
Input	DC 29V/3A
Output	15W Max
Standard	Qi 2.0 MPP15W
Charging induction lifting	When the phone is aligned and placed in the wireless charging area, the wireless charging pad automatically rises; After the phone is removed, the wireless charging pad automatically descends
Type-C output	20W Max
USB-A output	18W Max
A+C output	15W Max
Sofa atmosphere light strip	RGB colorful light strip(Optional)
Auxin port	3.5mm Auxin
vibrator output	20W
tweeter output	10W*2
Woofer output	25W
Bluetooth name	Mag-Table
Bluetooth Protocol	5.3
Bluetooth broadcast interconnection	Support interconnection among 5 products

Product button functions

1. Tablet button

Button icon	Button Function
	Long press the button to raise/lower the cup holder.
	Long press the button to disconnect/connect Bluetooth. Double-click the button to enable or disable Bluetooth broadcast interconnection.
	Short press the button to switch between different color ambient lights on the cover.

2. knob button

Button icon	Button Function
	Short press the button to pause/play the song. Long press the button to power on/off the audio system.
	Press the button briefly and adjust the song volume by rotating the knob Long press the button to restore all functions to their factory settings.
	Press the button briefly and adjust the vibration intensity of the vibrator by rotating the knob
	Press the button briefly and adjust the treble effect of the audio by rotating the knob
	Press the button briefly and adjust the bass effect of the audio by rotating the knob
	Press the button briefly and rotate the knob to switch to the previous/next song

Product instructions

1. Rotary knob button


Operation instructions	Diagram
Long press the button " " to turn on the audio system.	
Turn the knob counterclockwise to reduce the corresponding function effect	

2. Rotate the knob

Operation instructions	Diagram
Turn the knob clockwise to increase the corresponding function effect	
Turn the knob counterclockwise to reduce the corresponding function effect	

3. Wireless charging

- After aligning the phone with the wireless charging area, the wireless charging pad automatically rises.



CAUTION
Do not place metal phone cases or metal objects in the wireless charging area.

4. Precautions for product use

Keep Dry
Keep the surface dry to prevent damage or malfunction.

Pinch Hazard
Keep hands away from cup holder gaps to avoid pinching injuries.

Do not press forcefully
Do not press the cup holder area forcefully excessive hand pressure may cause product damage.