




Model No.V-307

Tips: Please use the brand specification charger.

Main Machine



- Please store and use this product in a normal temperature environment.
- Do not expose this product to rain or moisture for a long time.
- Do not throw it away to avoid product damage caused by falling.
- Do not disassemble, repair or modify this product by yourself.
- Please charge the power with the rated voltage of the machine
- At high volume for a long period of time, it may cause hearing damage. When listening to radio, avoid to excessive volume and excessive

Note: Battery should not be exposed to sunlight, fire or overheated environment.

band



USB cable



Wired microphone headset

1. Press and hold "⏻" button for 2 seconds with a voice of welcoming to use Callvi products.
Note: Insert the Wired Microphone to Mic port directly, the machine will power on automatically.
2. Press and hold "⏻" button for 2 seconds
Note: No any operations within 60 mins, the machine will power off automatically.

If the TF card or USB disk have the music files, the machine automatic play the music, If no music files in TF card or USB disk, the machine will enter into Bluetooth Mode.

Music format: MP3



1. Turn on the main machine, enter into the Bluetooth mode with the voice of "Bluetooth is waiting for connection".
2. On your Bluetooth device, search and click the corresponding model V-307 for connection. After Bluetooth connecting, the machine can play the music that is transmitted by your Bluetooth device.

Note: If the machine has successfully connected the Bluetooth device once, the machine will connect the Bluetooth device automatically by next time.

Recording Files : Insert TF card or USB disk to the machine, and insert the wired microphone to the Mic port, press and hold M button for 2 seconds to enter into Recording mode. Press and hold M button for 2 seconds to stop recording.

Delete the Recording Files: when playing the current recording files, press play and pause button for 2 seconds to delete the current recording file.

1. Use the standard accessory USB cable, one end is plugged into the main machine, the other end is plugged into the charger or computer USB port, when the battery is charged full, the red light is always on.
2. When the machine is plugged into TF card or USB disk, use the standard accessory USB cable, one end is connected with the machine, the other end is connected with computer, it enters into Card Reader mode, it can copy or delete the music file of TF card or USB disk.

Cannot play when turn on the machine	Check whether the battery have the power or not
No music sound when playing	Check whether the music files of TF card or USB disk are MP3 format or not
	Check whether the volume is adjusted or not
	Check whether the plays are in pause mode or not
No sound when amplifying	Check whether the wired microphone is plugged into MIC slot correctly or not
	Check whether the wireless microphone have pairing the device correctly or not
Can't search for FM radio channel / search for less FM radio channel / with much noise	Check if the surrounding environment is too tight or remote
	Confirm whether the environment is covered by FM signal
If the faults are still unresolved, please contact the local dealer in time	

2. Replacement service: During the replacement period (within seven days from the date of purchase), there is a non-human failure when it is in normal use. Please keep the product,

- Exceeding the warranty period.
- Product damage caused by unexpected factors or human behavior.
- Product failure or damage caused by force majeure factors such as earthquakes, fires, floods, lightning strikes, etc.
- Unauthorized disassembly, repair or modification without the permission of the company.

Product Name	Wired Voice Amplifier
Max output power	10W
Output impedance	2 Ω
Frequency Response	150Hz ~ 13000Hz
Charging Voltage	DC 5V / 500mA
Charging Time	3 -4 hours
Battery	Rechargeable 18650 type Lithium battery 3.7V/1200mAh
Working Temperature	-10 $^{\circ}$ C to 45 $^{\circ}$ C
Working time	Music mode: 4 to 5 hours MIC mode: 8 to 10 hours
Main machine size	78 x 98 x 39 mm
Unit weight	200g (battery included)

When purchasing this product, please fill out this card carefully and keep it in a safe place.

Model No.	
Purchase Date	
User Name	
User Address	
User Telephone	
Postcode	
Problem Description	
Dealer Company Name	
Company Address	
Person in charge	
Company Telephone	
Postcode	
Company Stamp	

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction