

SCORE524MP3 USER MANUAL



COMPONENT



NUMBER	NAME	SUBSTANCE	NOTE
1	CONTROLLER	Device Control unit	
2	SCOREBOARD EQUIPMENT	SCORE and PLAY TIME DISPLAY	
3	COMMUNICATION CABLE	CONTROLER and SCOREBOARD Connection unit	
4	DC POWER ADAPTER (SCORBOARD)	POWER : DC12V, 5A	Do not connect to the controller

How To Install



Connect the communication cable to the earphone jack.
(Numbers are displayed on the LCD screen.)



After connecting the DC power(A), connect the communication connector(B).
And POWER SWITCH(C) ON.

- If normal operation, the number is displayed on the LCD of ① and the DISPLAY of ② is ON
- If it does not work, check the fastening state of the connector, and repeat ① → ②.

*** Do Not Connect the Adapter(DC12V) to the controller**

(It may cause the product to Broken.)

Controller description



- Team Select
- Insert the SD card into the ① position and press the PLAY② button for 3 seconds.
- ③ After selecting with the Up / Down button, press the PLAY② button to select the home team.
- ③ Press the Up / Down button to select it and press the PLAY② button to select the away team
After completing the selection, press the PLAY② button three times to register the team name and return to the game screen.



Controller Discription



[Basketball operation order]

- Initial screen (game waiting time)
- Press the Quarter button (1 quartile).
- Use the ATT button to display the strike ticket.
- Press the BUZZ button to announce the start of the game.
- Press the Start / Attack start button to start the game.
- Press the Foul / Time out button appropriately to continue the game.
- When the game is over, proceed to the next quarter after a one minute break.
- If you want to change the game time, change each time and save it with SAVE button.

- Set attack time (If you SAVE after setting the desired time, it will be applied.)
- Short press (Score RESET)
- Long press (initialize game)
- After sports select button press, select the desired game.



- Press the SPORTS SELECT button again to complete the selection.

SPORTS SELECT



- Press the Sports Select button and select the appropriate Sports. Once you have selected an sport, press the Sports Select button again, The number is displayed and works.

NO	Sports	Function	Discription
1	SP 1	Futsal	Game Time 2 round 10 minute
2	SP 2	Shuttle Run	21 step, in the step separate 10 Buzzer sound.
3	SP 3	Volleyball	5Set,(1~5 Set point) time out 1 minute
4	SP 4	Kin Ball	3 Team play system, play time 10 minute
5	SP 5	Wrestling	2 round 3minute play
6	SP 6	Basketball	4 quarter 10minute play, 24 second attack time apply
7	SP 7	Badminton/Ping-pong	Score / Set / Set score control
8	SP 8	Judo	1 round 5 minute play
9	SP 9	Net Ball	4 quarter 10minute play, 120 second attack time apply
10	SP10	Hand ball	Game Time 2 round 30 minute, foul and time out

FCC compliance information

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment under FCC rules.

This appliance and its antenna must not be co-located or operation in conjunction with any other antenna or transmitter. A minimum separation distance of 20 cm must be maintained between the antenna and the person for this appliance to satisfy the RF exposure requirements.