




41-41-5MHz-20MHz-16QAM-16QAM-41373-41490-0#0-1#99-PASS




41-41-5MHz-20MHz-16QAM-16QAM-41373-41490-0#0-50#50-PASS




41-41-5MHz-20MHz-16QAM-16QAM-41373-41490-0#0-100#0-PASS




41-41-5MHz-20MHz-16QAM-16QAM-41373-41490-25#0-100#0-PASS




41-41-5MHz-20MHz-64QAM-64QAM-39683-39800-1#0-0#0-PASS




41-41-5MHz-20MHz-64QAM-64QAM-39683-39800-12#0-0#0-PASS



41-41-5MHz-20MHz-64QAM-64QAM-39683-39800-25#0-0#0-PASS




41-41-5MHz-20MHz-64QAM-64QAM-39683-39800-25#0-100#0-PASS




41-41-5MHz-20MHz-64QAM-64QAM-41373-41490-0#0-1#99-PASS




41-41-5MHZ-20MHZ-64QAM-64QAM-41373-41490-0#0-50#50-PASS




41-41-5MHZ-20MHZ-64QAM-64QAM-41373-41490-0#0-100#0-PASS



41-41-5MHZ-20MHZ-64QAM-64QAM-41373-41490-25#0-100#0-PASS



41-41-10MHz-15MHz-QPSK-QPSK-39703-39823-1#0-0#0-PASS




41-41-10MHz-15MHz-QPSK-QPSK-39703-39823-25#0-0#0-PASS



41-41-10MHz-15MHz-QPSK-QPSK-39703-39823-50#0-0#0-PASS



41-41-10MHz-15MHz-QPSK-QPSK-39703-39823-50#0-75#0-PASS



41-41-10MHz-15MHz-QPSK-QPSK-41395-41515-0#0-1#74-PASS




41-41-10MHz-15MHz-QPSK-QPSK-41395-41515-0#0-36#39-PASS




41-41-10MHz-15MHz-QPSK-QPSK-41395-41515-0#0-75#0-PASS



41-41-10MHz-15MHz-QPSK-QPSK-41395-41515-50#0-75#0-PASS



41-41-10MHz-15MHz-16QAM-16QAM-39703-39823-1#0-0#0-PASS




41-41-10MHz-15MHz-16QAM-16QAM-39703-39823-25#0-0#0-PASS



41-41-10MHz-15MHz-16QAM-16QAM-39703-39823-50#0-0#0-PASS



41-41-10MHz-15MHz-16QAM-16QAM-39703-39823-50#0-75#0-PASS




41-41-10MHz-15MHz-16QAM-16QAM-41395-41515-0#0-1#74-PASS




41-41-10MHz-15MHz-16QAM-16QAM-41395-41515-0#0-36#39-PASS




41-41-10MHz-15MHz-16QAM-16QAM-41395-41515-0#0-75#0-PASS



41-41-10MHz-15MHz-16QAM-16QAM-41395-41515-50#0-75#0-PASS



41-41-10MHz-15MHz-64QAM-64QAM-39703-39823-1#0-0#0-PASS




41-41-10MHz-15MHz-64QAM-64QAM-39703-39823-25#0-0#0-PASS




41-41-10MHz-15MHz-64QAM-64QAM-39703-39823-50#0-0#0-PASS



41-41-10MHz-15MHz-64QAM-64QAM-39703-39823-50#0-75#0-PASS



41-41-10MHz-15MHz-64QAM-64QAM-41395-41515-0#0-1#74-PASS




41-41-10MHz-15MHz-64QAM-64QAM-41395-41515-0#0-36#39-PASS




41-41-10MHz-15MHz-64QAM-64QAM-41395-41515-0#0-75#0-PASS



41-41-10MHz-15MHz-64QAM-64QAM-41395-41515-50#0-75#0-PASS



41-41-10MHz-20MHz-QPSK-QPSK-39705-39849-1#0-0#0-PASS




41-41-10MHz-20MHz-QPSK-QPSK-39705-39849-25#0-0#0-PASS



41-41-10MHz-20MHz-QPSK-QPSK-39705-39849-50#0-0#0-PASS



41-41-10MHZ-20MHZ-QPSK-QPSK-39705-39849-50#0-100#0-PASS



41-41-10MHZ-20MHZ-QPSK-QPSK-41346-41490-0#0-1#99-PASS




41-41-10MHZ-20MHZ-QPSK-QPSK-41346-41490-0#0-50#50-PASS




41-41-10MHz-20MHz-QPSK-QPSK-41346-41490-0#0-100#0-PASS




41-41-10MHz-20MHz-QPSK-QPSK-41346-41490-50#0-100#0-PASS



41-41-10MHz-20MHz-16QAM-16QAM-39705-39849-1#0-0#0-PASS




41-41-10MHz-20MHz-16QAM-16QAM-39705-39849-25#0-0#0-PASS



41-41-10MHz-20MHz-16QAM-16QAM-39705-39849-50#0-0#0-PASS




41-41-10MHz-20MHz-16QAM-16QAM-39705-39849-50#0-100#0-PASS



41-41-10MHz-20MHz-16QAM-16QAM-41346-41490-0#0-1#99-PASS




41-41-10MHz-20MHz-16QAM-16QAM-41346-41490-0#0-50#50-PASS




41-41-10MHz-20MHz-16QAM-16QAM-41346-41490-0#0-100#0-PASS



41-41-10MHz-20MHz-16QAM-16QAM-41346-41490-50#0-100#0-PASS



41-41-10MHz-20MHz-64QAM-64QAM-39705-39849-1#0-0#0-PASS



41-41-10MHz-20MHz-64QAM-64QAM-39705-39849-25#0-0#0-PASS



41-41-10MHz-20MHz-64QAM-64QAM-39705-39849-50#0-0#0-PASS




41-41-10MHz-20MHz-64QAM-64QAM-39705-39849-50#0-100#0-PASS



41-41-10MHz-20MHz-64QAM-64QAM-41346-41490-0#0-1#99-PASS



41-41-10MHz-20MHz-64QAM-64QAM-41346-41490-0#0-50#50-PASS




41-41-10MHz-20MHz-64QAM-64QAM-41346-41490-0#0-100#0-PASS



41-41-10MHz-20MHz-64QAM-64QAM-41346-41490-50#0-100#0-PASS



41-41-15MHz-15MHz-QPSK-QPSK-39725-39875-1#0-0#0-PASS




41-41-15MHz-15MHz-QPSK-QPSK-39725-39875-36#0-0#0-PASS



41-41-15MHz-15MHz-QPSK-QPSK-39725-39875-75#0-0#0-PASS



41-41-15MHz-15MHz-QPSK-QPSK-39725-39875-75#0-75#0-PASS



41-41-15MHz-15MHz-QPSK-QPSK-41365-41515-0#0-1#74-PASS




41-41-15MHz-15MHz-QPSK-QPSK-41365-41515-0#0-36#39-PASS




41-41-15MHz-15MHz-QPSK-QPSK-41365-41515-0#0-75#0-PASS




41-41-15MHz-15MHz-QPSK-QPSK-41365-41515-75#0-75#0-PASS



41-41-15MHz-15MHz-16QAM-16QAM-39725-39875-1#0-0#0-PASS




41-41-15MHz-15MHz-16QAM-16QAM-39725-39875-36#0-0#0-PASS



41-41-15MHz-15MHz-16QAM-16QAM-39725-39875-75#0-0#0-PASS



41-41-15MHz-15MHz-16QAM-16QAM-39725-39875-75#0-75#0-PASS




41-41-15MHz-15MHz-16QAM-16QAM-41365-41515-0#0-1#74-PASS



41-41-15MHz-15MHz-16QAM-16QAM-41365-41515-0#0-36#39-PASS




41-41-15MHz-15MHz-16QAM-16QAM-41365-41515-0#0-75#0-PASS




41-41-15MHz-15MHz-16QAM-16QAM-41365-41515-75#0-75#0-PASS



41-41-15MHz-15MHz-64QAM-64QAM-39725-39875-1#0-0#0-PASS




41-41-15MHz-15MHz-64QAM-64QAM-39725-39875-36#0-0#0-PASS




41-41-15MHz-15MHz-64QAM-64QAM-39725-39875-75#0-0#0-PASS



41-41-15MHz-15MHz-64QAM-64QAM-39725-39875-75#0-75#0-PASS



41-41-15MHz-15MHz-64QAM-64QAM-41365-41515-0#0-1#74-PASS




41-41-15MHz-15MHz-64QAM-64QAM-41365-41515-0#0-36#39-PASS




41-41-15MHz-15MHz-64QAM-64QAM-41365-41515-0#0-75#0-PASS



41-41-15MHz-15MHz-64QAM-64QAM-41365-41515-75#0-75#0-PASS



41-41-15MHz-20MHz-QPSK-QPSK-39728-39899-1#0-0#0-PASS




41-41-15MHz-20MHz-QPSK-QPSK-39728-39899-36#0-0#0-PASS



41-41-15MHz-20MHz-QPSK-QPSK-39728-39899-75#0-0#0-PASS



41-41-15MHZ-20MHZ-QPSK-QPSK-39728-39899-75#0-100#0-PASS




41-41-15MHZ-20MHZ-QPSK-QPSK-41319-41490-0#0-1#99-PASS




41-41-15MHZ-20MHZ-QPSK-QPSK-41319-41490-0#0-50#50-PASS



41-41-15MHz-20MHz-QPSK-QPSK-41319-41490-0#0-100#0-PASS



41-41-15MHz-20MHz-QPSK-QPSK-41319-41490-75#0-100#0-PASS



41-41-15MHz-20MHz-16QAM-16QAM-39728-39899-1#0-0#0-PASS




41-41-15MHz-20MHz-16QAM-16QAM-39728-39899-36#0-0#0-PASS



41-41-15MHz-20MHz-16QAM-16QAM-39728-39899-75#0-0#0-PASS



41-41-15MHz-20MHz-16QAM-16QAM-39728-39899-75#0-100#0-PASS




41-41-15MHz-20MHz-16QAM-16QAM-41319-41490-0#0-1#99-PASS




41-41-15MHz-20MHz-16QAM-16QAM-41319-41490-0#0-50#50-PASS




41-41-15MHz-20MHz-16QAM-16QAM-41319-41490-0#0-100#0-PASS




41-41-15MHz-20MHz-16QAM-16QAM-41319-41490-75#0-100#0-PASS



41-41-15MHz-20MHz-64QAM-64QAM-39728-39899-1#0-0#0-PASS



41-41-15MHz-20MHz-64QAM-64QAM-39728-39899-36#0-0#0-PASS




41-41-15MHz-20MHz-64QAM-64QAM-39728-39899-75#0-0#0-PASS




41-41-15MHz-20MHz-64QAM-64QAM-39728-39899-75#0-100#0-PASS




41-41-15MHz-20MHz-64QAM-64QAM-41319-41490-0#0-1#99-PASS




41-41-15MHz-20MHz-64QAM-64QAM-41319-41490-0#0-50#50-PASS




41-41-15MHz-20MHz-64QAM-64QAM-41319-41490-0#0-100#0-PASS




41-41-15MHz-20MHz-64QAM-64QAM-41319-41490-75#0-100#0-PASS



41-41-20MHz-20MHz-QPSK-QPSK-39750-39948-1#0-0#0-PASS




41-41-20MHz-20MHz-QPSK-QPSK-39750-39948-50#0-0#0-PASS



41-41-20MHz-20MHz-QPSK-QPSK-39750-39948-100#0-0#0-PASS



41-41-20MHz-20MHz-QPSK-QPSK-39750-39948-100#0-100#0-PASS



41-41-20MHz-20MHz-QPSK-QPSK-41292-41490-0#0-1#99-PASS




41-41-20MHz-20MHz-QPSK-QPSK-41292-41490-0#0-50#50-PASS




41-41-20MHz-20MHz-QPSK-QPSK-41292-41490-0#0-100#0-PASS



41-41-20MHz-20MHz-QPSK-QPSK-41292-41490-100#0-100#0-PASS



41-41-20MHz-20MHz-16QAM-16QAM-39750-39948-1#0-0#0-PASS



41-41-20MHz-20MHz-16QAM-16QAM-39750-39948-50#0-0#0-PASS



41-41-20MHz-20MHz-16QAM-16QAM-39750-39948-100#0-0#0-PASS