

95 毫米

70 毫米


## 快速入门指南

D8 骑行记录仪




扫描下载“录风者”APP

### 一，产品清单




\*安装前请确认配件齐全，如有缺失请联系客服。

### 二，按键与标识



### 三，安装与使用

- \*因出厂配16G的内存卡已安装到设备中，所以无需在插卡。
- 手机扫描封面二维码下载“录风者”APP。
  - 开机：设备连接USB接口即开机，记录仪指示灯亮。
  - 连接APP：点击“添加记录仪”>选择“行车记录仪”>记录仪安装完成即可点击“下一步”>连接WiFi>跳转进入手机设置界面>进入WiFi设置界面>点击“D8/D6...”开头的wifi名（如下图所示）>输入密码“12345678”>连接成功返回APP。



- 查看实时画面，连接成功即可查看。
- 查看回放，进入“实时画面”>点击“记录仪文件”。
- 下载视频，进入“记录仪文件”>点击右上角选择按钮>选中视频下载。
- 设置参数，点击“记录仪设置”>点击所要设置的参数即可。  
⚠ 请及时保存重要视频，以防循环录制覆盖。
- 安装底座：将底座支架孔和主机孔对齐，用内六角螺丝（M3x18）配合螺母固定。
- 安装车把支架：1.底座支架和车把支架用两颗内六角螺丝（M3x5）固定。2.硅胶垫\*2分别贴在车把支架的上下两个半圆弧中。3.车把支架套上车把用内六角螺丝（M4x20）固定即可。
- 安装后视镜支架：1.用开口扳手将车辆后视镜取下。2.底座支架和后视镜五金支架用两颗内六角螺丝（M3x5）固定。3.套在车辆后视镜镜杆上装回固定调整好角度即可。

- ⑩ 安装安全帽支架：  
1.底座支架和安全帽底座支架用一颗内六角螺丝（M3x5）固定。  
2.安全帽底座海绵贴在支架上。  
3.在安全帽上找到合适的位置粘贴即可。

\*以上三种安装方式根据需求和条件任选一种使用。



安装视频教程

### 四，注意事项

- 连接WiFi时不能正常上网使用，仅限于查看记录仪视频。WiFi使用期间ios可用流量，安卓暂不支持。
- 如自配内存卡，最大支持64G，请选择可靠品牌：雷克沙，金士顿，三星铠侠。使用不匹配或读写速度不够的内存卡，可能会导致设备出现卡机、视频花屏、掉帧、无法读取播放等问题。
- 首次连接记录仪，在APP功能设置里将存储卡操作格式化。

70 毫米


D8 Dashboard Camera

## Quick Start Guide




Scan and download the “Viidure” app

### 1.Product List




\*Please confirm that all accessories are complete before installation. If there are any missing parts, please contact customer service.

### 2.Buttons and Markings



### 3.Installation and Usage

- \*Since the 16GB memory card that comes with the factory has already been installed in the device, there is no need to insert the card.
- Scan the QR code on the cover with your phone to download the “Viidure” app.
  - Power on: The device is turned on when connected to the USB interface, and the recorder indicator light is on.
  - Connect APP: Tap “Add Camera”. > Once the dash cam is physically installed, tap “Next”. > “Connect Wi-Fi”, the app will redirect you to your phone’s Settings. > In Settings, go to Wi-Fi. Find and tap the Wi-Fi network named “D8/D6...” (as shown in the image below). Enter the password: “12345678”. > After a successful connection, return to the app to proceed.



- View the real-time screen, connect successfully to view.
- To view the playback, go to “Real time Screen”> click on “Camera Files”.
- Download the video, go to “Camera Files”> click the selection button in the upper right corner> select the video download.
- Set parameters, click on “Camera Settings”> click on the parameters you want to set.  
⚠ Please save important videos in a timely manner to prevent them from being overwritten by repetitive recording.
- Installation base: Align the base bracket hole with the host hole, and fix it with an internal hexagonal screw (M3x18) and nut.
- Install handlebar bracket: 1. The base bracket and handlebar bracket are fixed with two internal hexagonal screws (M3x5). 2. Two silicone pads are attached to the upper and lower semi-circular arcs of the handlebar bracket. 3. Install the handlebar bracket onto the handlebar and fix it with an internal hexagonal screw (M4x20).
- Install the rearview mirror bracket: 1. Use an open-end wrench to remove the vehicle’s rearview mirror. 2. The base bracket and rearview mirror hardware bracket are fixed with two internal hexagonal screws (M3x5). 3. Install and fix the mirror rod on the vehicle’s rearview mirror to adjust the angle.

- ⑩ Install the safety helmet bracket:  
1. The base bracket and safety helmet base bracket are fixed with an internal hexagonal screw (M3x5)  
2. The foam on the base of the safety helmet is attached to the bracket.  
3. Find a suitable position on the safety helmet and stick it on.

\*Choose one of the above three installation methods according to your needs and conditions.



Installation video tutorial

### 4.Precautions

- Unable to access the internet normally when connected to WiFi, limited to viewing recorder videos. During WiFi usage, iOS has available data, but Android does not currently support it.
- If equipped with a memory card that supports up to 64GB, please choose compatible brands: Reyroth, Kingston, Samsung Armor. Using memory cards that are not compatible or have insufficient read and write speeds may cause device issues such as lagging, video glitches, frame drops, and inability to read and play.
- Connect the recorder for the first time and format the memory card operation in the APP function settings.

### 五，常见问题及解决对策

| 常见问题    | 解决对策                                               |
|---------|----------------------------------------------------|
| 无法加入网络  | 长按记录仪按键强制关机，然后在手动开机，等待设备灯闪时将手机靠近设备，尝试重新连接WiFi。     |
| 指示灯红灯长亮 | 1.查看内存卡是否装上。<br>2.在APP里格式化内存卡。<br>3.内存卡已损坏或者未正确插入。 |
| 视频漏录    | 1.在紧急录像里面查看是否有视频。<br>2.紧急录像里面覆盖掉了。                 |
| 视频跳录    | 内存卡有问题，在APP中格式化内存卡。                                |

### 六，频段参数

- 工作频段：2412.0-2462.0 MHz最
- 大射频功率：16.53dbm

### 5.Common Problems and Solutions

| Frequently Asked Questions              | solution                                                                                                                                                                                               |
|-----------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Unable to join the network              | Press and hold the recorder button to forcefully shut down, then manually turn on the device, wait for the device light to flash, and bring the phone close to the device to try reconnecting to WiFi. |
| The red indicator stays on continuously | 1. Check if the memory card is properly inserted.<br>2. Format the memory card in the official app.<br>3. Replace the card if it is damaged.                                                           |
| Video omission                          | 1. Check if there is any video in the emergency folder.<br>2. The emergency video was covered.                                                                                                         |
| Video missing /skipping                 | Format the memory card in the official app. Replace the card if it is damaged.                                                                                                                         |

### 6.Frequency Band Parameters

- Operating Frequency Band:2412.0-2462.0MHz
- Maximum Radio-Frequency Power: 16.53 dbm

### 7.Information to User

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Important: Change or modifications not expressly approved by the manufacturer responsible for compliance could void the user’s authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference, and  
(2) this device must accept any interference received, including interference that may cause undesired operation.\*

This equipment complies with FCC radiation exposure limits set for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and any part of your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.