


front

Know about the Sensor



(1)

1




Button(Hidden)
Press and hold the button for 5 seconds until the LED blinks, the device will enter pairing mode

LED(Hidden)

Blinking: The device enters pairing mode
Off: The device is under standby status

(2)

2



Detect point
It should be contacted to the ground where you want to detect.


(3)

Quick Installation Guide

Note: The Smart Life app should be installed and registered an account first (Smart Life can be searched in APP Store or Google Play). Then make sure the Gateway is added and on-line before the next.

1.Power on the sensor

Remove the insulation sheet




(4)

back


2.Make device to enter pairing mode

Press and hold the button for 5 seconds until the LED blinks.ks.



(5)

Waiting for a few seconds, this device is added successfully and you may rename it. Click "Done" to finish the setting.




Then put it at the place where you want to detect.

(6)

4.Battery Change

The sensor works with a replaceable CR2032 3.0V battery. If you received the low battery alarm on app, please refer to below step and replace the battery (note battery positive and negative).


①Open the cover with the pry bar tool;




A.Put pry bar into the slot
B. Rotate the pry bar

(7)

②Replace the battery



③Close the cover and please note the correct direction



Align the slot.

(8)

FCC Warning

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.