



**For the best experience,  
charge your doorbell before setup**







**To charge doorbell:** Plug one end of the charging cable into the micro USB port on the back of your doorbell. Connect the other end to a standard USB power adaptor (like your phone charger).

## What's included

- A** Roku Wire-free Video Doorbell SE
- B** Roku Enhanced Chime SE
- C** USB charging cable
- D** Screw back plate
- E** Back plate
- F** Corner kit
- G** Wire caps (x3)
- H** Short screws (x3)
- I** Extension wires (x2)
- J** T8 screwdriver
- K** Long screws (x3)
- L** Plastic anchors (x3)
- M** Adhesive strip
- N** Jump wire

## What you'll need

- Your smartphone



**1** Light sensor


**2** Lens

**3** Motion sensor


**4** Microphone

**5** Doorbell button


**6** Speaker



**Doorbell  
FRONT**



**Doorbell  
BACK**



**Chime**

**7** Micro USB charging port

**8** Power button

**9** Screw terminals

**10** Status light

**11** Setup button

**12** Speaker

## Let's get started

### STEP 1: Download the Roku Smart Home app

Scan the QR code below to download the Roku Smart Home app on your smartphone. Sign in with your Roku account or create one.

#### You'll need



Smartphone & app



Message & data rates may apply.

Continue on back ➔

## STEP 2: Install your doorbell & chime

In the Roku Smart Home app, tap the “+” button, then “**Add Device**” to find “**Wire-free Video Doorbell**.” Follow the instructions to install your camera and complete setup.

### Recommended location

Install your doorbell less than 6.5 feet above ground level.



## What's that light mean?

| Doorbell      | State         |
|---------------|---------------|
| WHITE - Solid | Charging      |
| BLUE - Solid  | Fully charged |

| Chime             | State                   |
|-------------------|-------------------------|
| RED - Flashing    | Connecting to doorbell  |
| YELLOW - Flashing | Waiting for connections |
| BLUE - Flashing   | Connecting to network   |
| BLUE - Solid      | Connected               |



## More features are waiting

Unlock the full potential of your doorbell with a **Roku Smart Home Subscription**.

Learn more at  
[go.roku.com/rokusmarthome](https://go.roku.com/rokusmarthome)

## Need help?



Setup videos



Common questions



Tips and tricks

Visit [go.roku.com/doorbells](https://go.roku.com/doorbells)

### Roku

© 2023 Roku, Inc. All rights reserved. Roku, the Roku logo, Roku Smart Home, and the Roku Smart Home logo are the trademarks or registered trademarks of Roku, Inc.



# Roku™

## Wire-free Video Doorbell & Chime SE

## Quick Start Guide

