




FUNCTION INTRODUCTION OF REMOTE CONTROL

FULL FUNCTION RADIO CONTROL




INSTALLATION OF REMOTE CONTROL MODEL BATTERY

Model is equipped with a 7.4V 600m Ah Li-Po battery (included). First, twist the buckle to open the battery cover, then correctly connect the battery following the diagram. Place the battery into the compartment. Close the battery cover and twist the buckle to lock the cover. Tighten the cover screw to avoid children easy access.

INSTALLATION OF REMOTE CONTROL BATTERY

The remote control requires 2 X 1.5V AAA non-rechargeable batteries. Open the battery cover by loosening the cover screw. Place the batteries into the compartment observing the correct polarity. Replace the battery cover and tighten the cover screw.



Battery Installation Instructions:


1. Remove rechargeable battery from package and install correctly in machine following included guidelines.
2. The rechargeable battery should be removed from the machine before recharging.
3. Recharge battery only under adult supervision.
4. Do not use rechargeable AAA batteries in the remote control
5. Do not combine old and new AAA batteries in the remote control.
6. Use the same type or brand of new AAA batteries in the remote control
7. Place AAA batteries in the remote control observing the correct polarity
8. Use caution to avoid short-circuit of the battery terminals in the remote control

336 Hydraulic Excavator OPERATING INSTRUCTIONS




BUCKET, STICK, BOOM AND BODY CONTROL

INDIVIDUAL MOVEMENT




MODEL DRIVING CONTROL



336 Hydraulic Excavator OPERATING INSTRUCTIONS




MODEL DRIVING CONTROL



REMOTRE CONTROL FREQUENCY PAIRING AND POWER ON


This product is equipped with a remote control with a frequency of 2.4GHz. When a user operates the product for the first time, please install batteries into the model and the remote control. Then power on the unit, then the remote control. A series of beeps will indicate that the frequency pairing has been completed and the model is ready to operate.



LIGHT AND SOUND CONTROL



LIGHT FUNCTIONS



The operating model can generate lights and sounds. Press the sound switch to turn on the lights and sounds, press the switch again to turn them off.



SOUND FUNCTIONS



We reserve the right to make technical and design-related changes

