




VK-6117AW Air Purifier

Read & Save Instructions Before First Use

Layout of Content

- Specifications 1
- Package Contents 1
- Safety Information 2
- Know Your Purifier 3
- Before first use 4
- Control Panel: Touch Pad 6
- Filter Replacement & Clean11
- Troubleshooting14
- Warranty Terms15

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ¡“ Reorient or relocate the receiving antenna.
- ¡“ Increase the separation between the equipment and receiver.
- ¡“ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ¡“ Consult the dealer or an experienced radio/TV technician for help.

To satisfy FCC / IC RF exposure requirements, a separation distance of 20 cm or more should be maintained between the antenna of this device and persons during device operation.

To ensure compliance, operations at closer than this distance is not recommended.

FCC ID: 2AU03-TA-300

Safety Information

To reduce the risk of fire, electric shock, or other injury, follow all instructions and safety guidelines.

General Safety

- **Only** use your air purifier as described in this manual.
- **Do not** use without removing the plastic wrap from the filter. The purifier will not filter air, and may overheat, causing a fire hazard.
- **Do not** use your air purifier outdoors.
- Keep your air purifier away from water, and wet or damp areas. Never place in water or liquid.
- **Do not** use in excessively humid areas.
- Keep your air purifier away from heat sources.
- **Do not** use where combustible gases, vapors, metallic dust, aerosol (spray) products, or fumes from industrial oil are present.
- Keep 5 ft / 1.5 m away from where oxygen is being administered.
- Supervise children when they are near the air purifier.
- **Do not** place anything into any opening on the air purifier.
- **Do not** sit or place heavy objects on the air purifier.
- Keep the inside of the air purifier dry. To prevent moisture buildup, avoid placing in rooms with major temperature changes or underneath air conditioners.
- **Always** unplug your air purifier before servicing (such as changing the air filter).

- **Do not** use your air purifier if it is damaged or not working correctly, or if the cord or plug is damaged. **Do not** try to repair it yourself. Contact **Customer Support** (support@tredyhome.com).
- **WARNING: Do not** use this air purifier with solid-state speed controls (such as a dimmer switch).
- Not for commercial use. Household use **only**.

Power and Cord

- Keep air purifier near the outlet it is plugged into.
- **Never** place the cord near any heat source.
- **Do not** cover the cord with a rug, carpet, or other covering. **Do not** place the cord under furniture or appliances.
- Keep the cord out of areas where people walk often. Place the cord where it will not be tripped over.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved
- Children shall not play with the appliance.
- Cleaning and user maintenance shall not be made by children without supervision.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

WARNING: To Reduce The Risk Of Fire, Electric Shock Or Injury To Persons, Do Not Use Replacement Parts That Have Not Been Recommended By The Manufacturer (e.g. Parts Made At Home Using A 3D Printer)



**READ AND SAVE THESE
INSTRUCTIONS**

THIS APPLIANCE HAS A POLARIZED PLUG(one blade is wider than the other).To reduce the risk of electric shock,this plug is intended to fit in a polarized outlet only one way.If the plug does not fit fully in the outlet,reverse the plug.If it still does not fit,contact a qualified electrician to install the proper outlet.

DO NOT ATTEMPT TO MODIFY THIS PLUG OR DEFEAT THIS SAFETY FEATURE IN ANY WAY.

Know Your Purifier

Welcome using our company air purifier ,before use please read this manual carefully to operate the product correctly.




- 1 Touch-Control Panel
- 2 Air Outlet
- 3 Body
- 4 Sensor
- 5 Air Inlet
- 6 H13 True HEPA 4-stage Filter
- 7 Base Cover

Before first use


Important Notice:

Don't start the air purifier until you remove the Plastic Packaging from the filter.


Step-1: Put the appliance upside down on a soft cloth to void scratching, Grasp the handle of the base cover with your hand, pull it out firmly, and remove it.




Step-2: Take out the new filter and remove the Plastic Packaging.




Step-3: Place the unpacked filter correctly back into the air purifier.



Step-4: Align the base cover to the air purifier, be sure it's closed tightly.




Control Panel: Touch Pad



1). Plug and turn on the machine

All lights will be ON for 1 second and you hear a beep, all lights then stay OFF .



2). On / Off button

Press  button, Speed at level 1 (Low) .

3). Fan Speed Adjustment

The fan speed light indicates at which fan speed the appliance is operating. Press Speed button  to adjust fan speed level, 1~3 refers to **Low** , **Medium** , **High level**.

4). Auto mode

At Auto mode, the fan speed will be automatically adjusted according to AQL level as below:

AQ Color	Blue	Orange	Red
Speed mode	1(Low)	2(Medium)	3(High)
AQ level	Good	Moderate	Poor

Note: The sensor only detects the airborne particles and air quality color displayed by this machine only for reference.

4). Sleep Mode

When you use the appliance in Sleep Mode, it works very quietly. All the buttons (If filter life expiration reminder) will be at half brightness.

Press any other buttons(except '🌬️' and '🔌' buttons) to exit the sleep mode.

5). Turbo Speed Mode

Press '🌀' button to enter the Turbo speed mode, and the motor is working at the highest speed

6). Setting timer

You can set a timer for 2, 4, 8 hours.

1. Press '🕒' repeatedly to select a time. The timer will start automatically.

Note:The timer indicators will light up when active.

2. Once the timer has finished, the air purifier will power off.

3. To cancel a timer, press '🕒' until all timer indicators are off.

Note: You can change the fan speed at any time while the timer is on.

7). Keylock mode

1. Press '🔒' button 3 seconds to activate Keylock mode , all buttons are locked at this mode; If your house has young child, we suggest use this mode.

2. To cancel the keylock mode, just press and hold '🔒' button for 3 seconds.

8). Filter replacement light

When indicator '🌬️' lights, it means that you should check the filter if it need to be cleaned or replaced.

Note: The filter's lifetime is based to your house air quality and using time.

Using the appliance in a humid environment will reduce the lifetime of the filter.


9). Memory Function

When the air purifier is plugged in, it will remember its previous fan speed setting.

10). Connect to WiFi



At the standby mode, long press '🔌' for 5 seconds, when indicator '📶' light flashes quickly ,then enter WiFi network pairing mode. Please connect your smart phone to WiFi and operate it according to following steps.

Note: If purifier has been successfully connected to WiFi, '📶' indicator will stay on.




Scan QR code to
download the APP.

- 01** Register account or Log in with existing account.





- 02** Add device.



- 03** Click “Small Home Appliances”, Then choose “Air Purifier”.

- 04 Connect to Wi-Fi network.
Input wifi password.

Note: After connection, the default setting mode is EZ Mode .




- 05 Change to "AP Mode ".


During  quick blinking status, press  button for 5 seconds, the  icon will blink slowly....

Notice: While  icon do not blink, please press  for 5 seconds to enter into quick blinking status.


- 06 Connect mobile phone to the device's hotspot(SmartLife-XXXX).



07 Adding device...



08 Device added successfully.



Filter Replacement & Clean

1. Filter Replacement

When Should I Replace the Air Filter ?

It is recommended to change the air filter every 6–8 months. However, you may need to change your filter sooner or later depending on how often you use your air purifier. It is important to watch out for the following signs of expired filter:

- Increased operating noise
- Decreased airflow
- Clogged filter
- Increased presence of odors

NOTE:


- The environment in which the air purifier being used may also extend or shorten the lifetime of the the air filter. Using your air purifier in an environment of relatively high pollution may mean you will need to change the air filter more often.
- If the air pollution in your environment is very high, there is a possibility that the filters may not be completely effective and may need to be replaced before  lights up.
- Remember to reset the air purifier after changing the air filter.

How to replace the Air Filter ?

1. Switch off the appliance and unplug it. (a)




2. Put the appliance upside down on a soft cloth to void scratching, Grasp the handle of the base cover with your hand, pull it out firmly, and remove it. (b)




3. Remove the old filter. (c)

(c)




4. Remove the packaging material of the new filter. (d)

(d)




5. Put the new filter back into the appliance. (e)

(e)




6. Align the base cover to the air purifier, be sure it's closed tightly. (f)

(f)



7. Put the plug in the wall socket and switch on the appliance again. (g)

(g)




8. Reset Filter's lifetime.

The filter lifetime should be reset if '⏸' lights up, after replacing the new filter, you need to reset filter lifetime.

- 1). Plug in the air purifier and turn it on.
- 2). Press and hold '⏸' for 3 seconds.
- 3). The light '⏸' will turn off, indicating that the reset is complete.

(h)



Filter replacement force mode


When using the air purifier in an environment of heavy pollution, the lifespan of the air filter may be significantly reduced. You can change the filters even if '⏸' does not light up. Follow the steps below to perform a hard reset.

- 1). Replace the air filters as mentioned in the Filter Replacement section.
- 2). Plug in the air purifier and keep in working mode.
- 3). Press and hold '⏸' for 3 seconds, after hearing the buzzer "Ding", the '⏸' indicator will flash 3 times and then turn off, the reset is finished.

2. Keep Filter Clean

In order to keep your purifier working with more efficiency and life-time, clean the filter (pre-filter side only) every 2 weeks with the Instruction Below:

- 1). Clean out any dust, hair, or furs remain on the pre-filter by using the vacuum hose.
- 2). Clean out any dust, hair, or furs remain on the bottom cover by using the vacuum hose.
- 3). DO NOT wash the filter with any water or liquid.



Troubleshooting

This chapter summarises the most common problems you could encounter with the appliance. If you are unable to solve the problem with the information below, contact the Consumer Care Centre in your country.

Problem	Cause	Solution
Air purifier does not power on.	Unit is not plugged into an electrical outlet.	Connect the plug to a powered electrical outlet.
	Outlet is not working properly.	Try plugging the air purifier into a different outlet.
	Power button has not been pressed after plugging in the air purifier.	Press '  ' once to turn on the air purifier.
	Power cord is damaged.	Immediately discontinue use and contact Customer Support .
	Air purifier is defective or malfunctioning.	
Air purifier does not respond to button controls.	Air purifier is not plugged into an outlet.	Connect the plug to a powered electrical outlet.
	Air purifier is defective or malfunctioning.	Immediately discontinue use and contact Customer Support.
Air purifier makes an unusual noise while operating.	Filter is dirty.	Replace the air filter as instructed in the Filter Replacement section.
	Filter does not fit properly.	Properly place filter as noted in the Before first use and Filter Replacement sections.
	Foreign object inside the unit.	Immediately discontinue use and contact Customer Support . DO NOT attempt to open the air purifier.
	Filter packaging has not been removed.	Remove filter from packaging before use.
Significantly reduced airflow.	Filter packaging has not been removed.	Remove filter from packaging before use.
	Fan speed is low.	Press '  ' to adjust fan speed.
	Filter needs to be replaced.	Replace the air filters as instructed in the Filter Replacement section.
	Not enough clearance on all sides of the purifier.	Ensure there is at least 38 cm (15 inches) of clearance on all sides of the purifier.
Poor air purification quality.	Filter needs to be replaced.	Replace the air filters as instructed in the Filter Replacement section.
	Room is too large for the air purifier's applicable area.	Ensure the room is smaller than (200 ft ²).
	Air inlet or outlet is blocked.	Remove objects blocking air inlet or outlet.
	Filter not properly placed in housing.	Properly place filters as noted in the Before first use and Filter Replacement sections.
Filter reset button is still illuminated after replacing the air filter.	The air purifier has been reset incorrectly.	See the Filter Replacement section on how to properly reset the unit.
Air purifier turns on, then suddenly turns off.	Air purifier is defective or malfunctioning.	Immediately discontinue use and contact Customer Support . DO NOT attempt to open the air purifier for self-servicing.
Air purifier beeps repeatedly after being powered on or plugged in.		

Warranty Terms

- 1) This product is warranted for one year from the date of purchase (12 months, 365 days); the warranty is limited to defects in the materials of the product and manufacturing defects.
- 2) The following conditions are not in the scope of maintenance:
 - a) This product has exceeded the "12-month warranty".
 - b) Failure to provide valid purchase receipts; or alter valid purchase receipts without authorization; or the model and serial numbers on the product in purchase receipt do not match the actual product.
 - c) The label or serial number of the product is damaged or has been tampered, and the identity of this product can't be proved effectively.
 - d) Due to unexpected factors, improper use or other human factors (including water ingress, moisture, fall down, user operation errors, transportation, bumps, etc.) cause a defect or damage ; Failure or damage caused by natural disasters and force majeure so on (such as earthquakes, fires, etc.)
 - e) Disassembled, refitted or repaired by user or an unauthorized third party.
 - f) Not follow the instructions in this manual, or damage caused by not using the original parts of the product.
 - g) The purchaser has clearly be informed that the product is a disposed product, or samples that serve as commercial listings, or products that have been subjected to performance overload tests.
 - h) Wear of any part, or damage to plastics and other accessories.
- 3) All air freight and transportation costs are not covered by the warranty and must be borne by the customer.
- 4) In any case, the company or its authorized distributors will not grant any guarantee on time if it is beyond the control, or any special or indirect damage occurs, the company or its authorized distributors will not responsible for it. In addition to the above-mentioned clear warranty provisions, the company is not required to assume other forms of warranty responsibilities.

The electronic manual can be downloaded from the following website:
www.vorktech.com