USER GUIDE



WiFi Camera W1

WHAT'S IN THE BOX

Camera x1
Power Adapter x1
USB Power Cable x1
Mounting Sticker x3
Wire Tidys x5
User Guide x1

OVERVIEW



Status LED :

- The status LED steady on indicates a normal connection;
- The status LED slow blinking indicates the device is not connected;
- The status LED fast blinking indicates the device is ready to connect.

Reset Button:

Press and hold for 3 seconds to restore factory settings, enter the network configuration mode.

SD Card Slot :

The SD card needs to be prepared by the user. It supports up to 128 GB storage cards, and only supports class 10 SD cards.

HOW TO USE

App Download

Download the Mobile app to set up your camera, remotely control settings, view your pictures and videos, and more.

1. Seach the name **"Joysee"** in APP Store or Google Play.
2. Scan the QR code to download the App.

Download on the App Store

GET IT ON Google Play

Set Up The Camera

1. Connect the camera to power with the included power cable and power adapter.
2. Remove the **protective film** from the mounting sticker.

3. Please stick the installation sticker on the window and then secure the camera to it.
   Note: The type C port of the camera needs to be facing downward when installing.



Add Camera

1. Click on the home icon to access the Joysee APP, register and log in to your account.
2. Press the ⊕ button or choose "Add Device", enter the "Scan to Add Device" interface and use your phone to scan the QR code on the packaging , besides that, turn on your phone's Bluetooth, and on the add device page, your phone will automatically detect the device, and select the device icon.
3. Next, you can follow the APP's guidance to complete the network configuration.



Using The Camera

1. The next interface is the live view page and device settings page, you can adjust the production-related parameters through the settings.

FAQ

1 How to record on microSD card?

- Ensure the microSD card is installed in the correct direction;
- Format the microSD card in Girafit APP to enable recording;
- After the card is formatted, choose to record all-day or by incident only in the Manage Storage' menu;
- If the camera does not detect the microSD card, try formatting the card to FAT32 using a PC.

2 How to connect a camera to the internet?

- Press and hold reset button for 3 seconds to trigger pairing, the indicator light will go into blinking;
- Add the device on APP, select the corresponding WiFi name, the device supports 2.5G and 5G WiFi signal;
- After completing the pairing, the indicator light of the device is always on, and you can view the video on APP;

3 What should I do if the camera image is upside down?

- In the camera live broadcast interface, select "more," and you can flip the screen there.

4 Where can I rename the camera?

- Open the APP, enter the device live interface, select Settings-About Device-Device Name, where you can change the device name.

5 How accurate is the human detection?

- Built-in AI human detection with 99% accuracy.Plus human detection ignores distractions like swaying branches, ensuring you only get

6 How is the night vision effect?

- The device supports full-color night vision with AI, which has clearer night vision than general infrared night vision.

REGULATION

FCC Regulations

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This
Equipment generates,uses and can radiate radio frequency energy and,if not installed and used in accordance with the instructions,may cause harmful interference to radio
communications.However,there is no guarantee that interference will not occur in a Particular installation.If thise quipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
—Consult the dealer or an experienced radio/TV technician for help.
Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
This equipment should be installed and operated with minimum distance 20cm between the radiator&your body.

SPECIFICATIONS

Product Model	WDC01
Camera	3MP, FOV 100°
WIFI	2.4G
Video Resolution	2K
Night Vision	Full color night vision
Cloud Storage	Supported
Local Storage	SD Card (Max.128G)
Power Adaptor	Input : 100-240VAC 50/60Hz Output : 5V ⎓1A
Operation Environment	Temperature : -20°C~55°C Humiduty : 85% or less (non-condensing)

To claim your warranty or for any inquiries on product repairs, exchanges, upgrades or return, please feel free to contact our customer service and our professional agents would be glad to assist you.

Email : seviece@joystek.com