





快速安装指南

Quick Start Guide


HPRT Poooli L1/L2



开箱清单




HPRT Poooli L1/L2



安装指南




普通热敏纸卷



USB数据线

⚠ 注意:箱内实际内容以出货清单为准。

外观及组件



① 电源键

② 鹦鹉嘴配饰

③ USB接口

使用向导



电源键状态

长按三秒即可ON/OFF

- 常亮:待机状态/充电完成
- 慢闪:充电中
- 快闪:耗材不足,设备盖没有关紧,电量不足,打印头过热



充电状态

购买后第一次使用时

- 我们建议充满电后使用
- 可以使用电源适配器或电脑USB口充电
(出货时不配适配器)

注意:若使用电源适配器供电,则应购买并使用获得CCC认证并满足标准要求的电源适配器。



USB数据线

除专用充电线外也可使用手机充电线


- 建议使用专用充电线充电
- 使用5V/1A充电时大约需要90分钟

下载APP

扫描下方二维码下载安装APP:



连接设备



注册并登录APP, 点击添加设备, 通过搜索蓝牙连接设备, 或扫码连接设备。

APP设置



Bluetooth 5.0

蓝牙配对

- 当第一次连接成功后,下次启动应用时将自动连接
- 在连接状态下,双击电源键,即可断开连接状态



简单操作



APP设置

- 可以在设备管理中查看剩余电量、固件版本等信息

鹦鹉嘴配饰的拆装



• 拆卸

若想把鹦鹉嘴配饰拆下, 请按图示方向拿下即可。



• 安装

若想把鹦鹉嘴配饰装上, 请按图示方向利用磁铁的吸力将其吸附住即可。



耗材的更换




图1



图2




图3

- 将打印机如图1放置, 注意查看机身箭头指示。
- 参照图2所示, 向下推开上盖。
- 更换耗材时, 参照图3所示方向, 放入耗材。
- 确认耗材放置正确后, 请将上盖与下盖合上, 向上推动上盖恢复原状。

⚠ 打印机更换耗材时, 请勿触碰打印头以防过热烫伤。

官方耗材的种类

普通纸	不含双酚-A，留影最长可达22 年
三防纸	防水、防油、防PVC，不含双酚-A，留影最长可达22年
有底纸不干胶	不含双酚-A，具有较黏的胶水，没有固定规格，可自由设置打印长短
便利贴纸	不含双酚-A，有背胶，可随贴随摘
连续标签纸	不含双酚-A，具有较黏的胶水，没有固定规格，可作各种标签标识
* 若因未使用专用打印纸而产生机器故障，则无法享受三包政策。	

安全及注意事项



电池过热

电池管理及注意事项

- 充电完成时, 我们建议拔掉充电线。
- 为了避免火灾, 请不要在高温地点充电 (如汗蒸房、篝火附近等)。



充电器注意

打印头管理及注意事项

- 有可能因为充电不当而导致打印头损坏。
- 我们建议不要在高湿度或多灰尘地带使用啖哩。



烧伤危险

打印头过热

- 打印后, 请勿直接触碰打印头, 以防过热烫伤。



充电端口损坏现象

充电中的注意事项

- 请轻轻插入或拔出充电线, 以防用力过猛损坏充电端口。

保修条款

一、自出厂之日起,整机保修12个月。

二、存在以下情况之一者,不属于保修范围之内:

- 1、未经我公司及授权维修人员许可,擅自对产品进行拆卸,或产品序列号标贴被撕去及模糊不清,无法辨认;
- 2、由于固体颗粒刮伤热敏头片,引起的打印白线,则头片不属于保修范围;
- 3、使用非官方原装耗材而造成的机器问题,商家不予提供保修服务。
- 4、其他人为引起的故障。

三、保修期内,维修时所更换的产品零配件归我公司所有。

四、用户负责将产品寄送至我公司售后服务部或我公司授权的维修站点进行保修服务。

五、厦门汉印电子有限公司拥有本保修条款的最终解释权。

注意:若用户自行用错误型号电池更换会有爆炸危险,
请务必按照说明寄回维修站点处置用完的电池。

生产厂家:厦门汉印电子有限公司

返修地址:厦门市湖里区高崎南十二路艾德航空工业园2号楼4层

返修电话:400-806-9290

产品保修卡

尊敬的用户：

为了保障您的权益以及为您提供更优质的售后服务,请您在购买产品时仔细填写并保留此卡,进行保修服务时请与购买发票一同出示!

用户名称: _____

联系地址: _____ 省 _____ 市 _____ 区(县)

联系电话: _____

产品型号(序列号): _____

(请将不干胶条码标签贴于此)


经销商名称(盖章): _____

联系地址: _____

联系电话: _____

购买日期: _____ 年 _____ 月 _____ 日

Packing List




HPRT Poooli L1/L2



Quick Start Guide




Thermal Paper Roll



USB Cable

 Note: The packing materials are actually based on the order.

Appearance



- ① Power button
- ② Parrot mouth accessory
- ③ USB Port

Using Guide



Power button status

Long press 3 seconds to ON/OFF

- Light: Standby / charging completed
- Slow flash: Charging
- Fast flash: Supplies near end, cover open, low battery and the print head is overheated.



Charging

Use it for the first time after purchase

- Recommended to use after full charge.
- Can be charged using a phone adapter or connected to a computer.



USB Cable

In addition to the dedicated charger, you can also use the charging cable of mobile device.


- Recommended to use a dedicated charging cable to charge.
- It takes about 90 minutes to charge with 5V/1A.

Download APP

Scan the QR code below and install the app:



Connection



Click the “Connect Printer” button. Enter the printer search page to select the corresponding printer from the list of printers found via Bluetooth.

APP Setting



Bluetooth 5.0 Bluetooth pairing

- When the first connection succeeds, the next time you start the application that will connect HPRT Pooli L1/L2 automatically.
- In the connection state, double click the power button to disconnect the connection.





Simple operation APP setting

- You can view information such as remaining power, firmware versions in device management.

Disassembly



- **Dismantle**

If you want to remove the parrot mouth accessory , please according to the step take them down.



- **Install**

If you want to attach the parrot mouth accessory, use the magnet to adsorb the parrot mouth.



Replace Supplies




Figure 1




Figure 2




Figure 3

- Place Pooli as shown in figure 1, and look at the arrow.
- With reference to figure 2, push down the upper cover.
- When replacing supplies, place the supplies in reference to the direction shown in figure 3.
- If the supplies are properly placed, close the upper cover to the lower cover and push the upper cover back to its original shape.

⚠ When changing supplies , do not touch the print head in case of overheating.

Offical Supplies Types

Thermal paper	No bisphenol-A, saves photo for up to 22 years.
Three proofings	Waterproof, oil-proof, anti-PVC, no bisphenol -A, saves photo for up to 22 years.
Self-adhesive paper	No bisphenol-A, with a sticky glue, no fixed specifications, free to set the print length
Convenience sticker	No bisphenol-A, hasback glue, can be picked as soon as affixed.
Continuous paper	No bisphenol-A, has more sticky glue, does not have the fixed specification, can be used as a variety of tag identification
*Thermal paper of HPRT Pooli L1/L2 is a special piece of paper. *If the machine failure caused by the use of other paper, you will not be able to get the three guarantees.	

Safety



Battery overheating

Battery management and cautions

- When the charge is completed, please unplug the charging line.
- To avoid fire, do not charge at high temperatures(e.g. sweating rooms, bonfire accessories, etc.).



Charger attention

Print head management and cautions

- There may be damage to the print head due to improper charging.
- We recommend not to use HPRT Pooli L1 in high humidity or dusty areas.



Combustion hazard

Print head overheating

- After printing, do not touch the print head directly to prevent burn.



Charging port damage phenomenon

Charging cautions

- Please gently insert or unplug the chargingline to prevent excessive damage to the charging port.

FCC COMPLIANCE STATEMENT:

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications to this unit not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction.

厦门汉印电子有限公司

版本:1.1

地址:福建省厦门市同安区榕源路96号

电话:400-806-9290

官网:cn.hpert.com

MADE IN CHINA

Manufacturer: Xiamen Hanin Electronic Technology Co.,Ltd.

Address: No.96, Rongyuan Road, Tong'an District, Xiamen, China

E-mail: support@hpert.com

Web: www.hpert.com