





Handset Go User Guide



a. Handset Go hardware components




a. Handset Go software components

Desk Status




The Handset Go uses simple color coding to indicate desk availability.
The status light and display will change according to the current status.




Available

This desk is free for anyone to use: you can reserve it if you have a valid Floorsense Desk Pass.



Reserved

This desk is taken. Only the person who reserved this desk can use it.



Out of Order

This desk is disabled: it cannot be reserved by any user.


Reserving a Desk




You can reserve an available desk using your smartphone, if you have a valid Floorsense Desk Pass in your Apple Wallet or Google Wallet.



Place your smartphone on the  symbol on the Handset Go.



Your smartphone will detect the **Handset Go** and automatically present your **Floorsense Desk Pass**. If using an iPhone, you will need to confirm the booking with Face ID.



The desk status will change to **RESERVED**. Depending on your workplace settings, the display may also show the start and end time of your reservation.