

case to a suitable USB power source.

2. Flashing orange LED=Charging in progress

3. Steady orange LED=Charging complete

NOTE: Press the button next to charging port on charging case:

1. Steady orange LED=Charged

2. Flashing orange LED=Low power, need to recharge charging case.

3. No light=Battery is out.

HOW TO CHARGE YOUR EARBUDS

Now that your case is charged, you can take it with you and charge up your earbuds anywhere and anytime:

1. Insert both earbuds into the charging case until they click into place. The charging case will start to charge earbuds automatically. You will see an orange LED on earbuds light up for 8 seconds then turn off.

2. Steady orange LED on charging case=charging in progress

3. Blue LED on earbuds light up for 3 seconds=charging complete. And orange LED on charging case turns OFF.

NOTE: If charging case battery totally runs out, earbuds cannot turn on automatically when you lift them out from charging case, you still can press multifunction button on earbuds to turn them ON.

SPECIFICATIONS:

Bluetooth® version:

V5.0 (both sides), ultra-low consumption

Bluetooth® Mode:

A2DP1.3/HFP1.6/HSP1.2/AVRCP1.6/D11.3

Bluetooth® Frequency: 2.4GHZ

Bluetooth® Range: 32 feet (10 m) with no obstacles

BATTERY CAPACITY:

Earbud: 40mAh rechargeable Li-ion Battery

Charging dock: 350mAh rechargeable Li-ion Battery.

Charging time:

70 minutes for power case, 40 minutes for earbuds

Power case can fully charge earbuds up to 4 times on a single charge

TALK/PLAY TIME:

2.5 hours at medium volume (TWS connected),

3 hours (one earbud connected)

STANDBY TIME:

Single earbud mode: 100 hrs.

One Pair earbuds mode: 60 hrs.

FCC ID: 2AUZO-JT890

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

Bluetooth® Declaration ID: 115952

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc.



Distributed by Collective Goods
310 Interlocken Pkwy, Suite 120
Broomfield, CO 80021
collectivegoods.com



USER MANUAL

FUNCTIONS



TURNING ON/OFF EARBUDS

- After charging the case, lift the earbuds out and the power is automatically turned ON. You will hear "Power ON" and see the blue LED flashing.

- To turn OFF, place earbuds into the case until they click into place, you will see the orange LED light up for 10 seconds. The earbuds turn OFF and disconnect with your mobile device.
- To turn the earbuds OFF outside of the case, press the multifunction button on either earbud and hold it for 3 seconds, both earbuds will turn OFF.
- To turn ON only a single earbud, press the multifunction button on either earbud and hold it for 3 seconds. Follow the same step to turn ON the other earbud—they will be connected again automatically.

PAIRING BOTH EARBUDS

- The True Wireless Technology (TSW) enables you to use two earbuds paired via Bluetooth® to create a wireless dual-channel system to deliver a true stereo sound effect.
- Lift the earbuds out of the case to activate power. You will hear "Power ON" and see the blue LED flashing on both earbuds. Both earbuds will be connected automatically when you hear "left channel" and "right channel". Then the blue LED on left earbud turns OFF and the blue & orange LED will flash on the right earbud as it waits to pair with your device. You will hear "Pairing" from the right earbud.
 - Enable Bluetooth® on your mobile device, select "BUDS" from the list of available bluetooth® devices. You will hear

"connected" and the blue & orange LED on right earbud turns OFF. The streaming music will be played simultaneously on both earbuds.

Earbuds will automatically pair if they have already been paired to the same device. You only need to lift the earbuds out from the case and connection will be automatic.

The right earbud is set as master earbud by default.

When you put the left earbud back into the case, the right earbud is still connected to your device and continues to play music.

When you put the right earbud back into the case, the connection is interrupted. The left earbud then turns into "pairing mode" and you will need to select the same pairing name from the list of available Bluetooth® devices on your mobile device.

When you lift either earbud out of the case, the dual channel connection will rebuild automatically.

PAIRING ONE EARBUD

Lift one earbud out of the case to activate power, wait until you see the blue LED flashing and then it will change to blue & orange flashing. You will hear "Pairing". Select and connect "BUDS" from the list of available Bluetooth® devices. You will hear "Connected" and the blue & Orange LED turns OFF. If you lift another earbud out of the case, two earbuds will be

automatically connected (you will hear "left channel"—"right channel") and the streaming music will be played simultaneously on both earbuds.

LISTENING TO MUSIC

- After you successfully connect to your Bluetooth® device, select music to play. Pressing once on the multifunction button of either earbud will pause your music. Press again to resume play.
- Double click on the multifunction button of left earbud to skip to the previous song.
- Double click on the multifunction button of right earbud to skip to the next song.
- Volume is controlled from your device, not from the earbuds.**

MAKING AND RECEIVING CALLS

- Be sure the earbuds are connected to your mobile phone, and then you can make calls.
- If you choose to use only one earbud, either one is capable of receiving calls, since each has its own built-in mic.
- Answer calls by pressing the multifunction button quickly one time. To refuse a call, double click multifunction button.

HOW TO CHARGE THE CHARGING CASE

- Connect the provided Micro USB cable from your charging