

Label locates in the battery compartment, End users can easily see the label when replacing the battery
Permanent adhesive type is used to fix the label, the label drawing isn't removed easily.

